

[Manuals.plus](#) /

› [SRJTEK](#) /

› SRJTEK Touch Screen Digitizer Replacement Manual for Sky Devices Elite OctaMax 8 inch

SRJTEK Elite OctaMax

SRJTEK Touch Screen Digitizer Replacement Manual

For Sky Devices Elite OctaMax 8 inch Tablet

INTRODUCTION

This manual provides detailed instructions for the installation and care of your SRJTEK Touch Screen Digitizer Replacement for the Sky Devices Elite OctaMax 8 inch tablet. This product is designed to replace a broken or malfunctioning touch screen panel, restoring the functionality of your device. Please read all instructions carefully before proceeding with installation.

WHAT'S IN THE BOX

The package includes the following components:

- 1 x Touch Screen Digitizer for Sky Devices Elite OctaMax 8 inch Panel
- 1 x Repair Tool Kits (various tools for disassembly)
- 1 x Adhesive (for securing the new digitizer)





Image: Contents of the SRJTEK Touch Screen Digitizer Replacement package, including the digitizer and a set of repair tools.

PRODUCT OVERVIEW

The SRJTEK Touch Screen Digitizer is a high-quality replacement part designed specifically for the Sky Devices Elite OctaMax 8 inch tablet. It features a responsive touch panel and durable glass construction.



**For Sky Devices
Elite OctaMax**

Image: The replacement digitizer clearly labeled for Sky Devices Elite OctaMax, indicating specific model compatibility.



Image: Visual representation of the digitizer's key features, including HD effect, explosion-proof durability, smooth touch feel, and anti-fingerprint properties.



Flex Cable



Connector IC



With Home Button
(Home button without
fingerprint function)

Image: Close-up view of the digitizer's flex cable and connector IC, highlighting the home button functionality (without fingerprint sensor).

SETUP AND INSTALLATION

Replacing a tablet touch screen requires precision and technical knowledge. **We highly recommend professional installation** to avoid damage to your device or the new part. Ensure the flex cable is connected correctly to the motherboard.

[Installation Video Guide](#)

Video: A detailed replacement guide for the Sky Devices Elite OctaMax touch screen. This video demonstrates the steps involved in removing the old screen and installing the new digitizer.

Product Overview Video

Video: An overview of the SRJTEK touch screen digitizer for Sky Devices Elite OctaMax, showcasing its appearance and fit.




Image: A visual comparison showing a tablet with a cracked screen (Before) and the same tablet with a new, intact screen (After) following replacement.

OPERATING INSTRUCTIONS

After successful installation, power on your Sky Devices Elite OctaMax tablet. Test the touch functionality across the entire screen to ensure responsiveness and accuracy. Verify that all areas of the screen register touch input correctly.




Image: Depiction of the smooth and responsive touch experience provided by the new replacement screen, similar to the original.

CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your new touch screen digitizer, follow these care guidelines:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner. Avoid harsh chemicals or abrasive materials.
- **Protection:** Consider using a screen protector to prevent scratches and minor impacts.
- **Handling:** Avoid dropping the tablet or applying excessive pressure to the screen, as this can cause damage.
- **Temperature:** Do not expose the tablet to extreme temperatures, which can affect screen performance.

TROUBLESHOOTING

If you encounter issues after installation, consider the following common troubleshooting steps:

- **No Touch Response:** Ensure the flex cable is securely and correctly connected to the motherboard. A loose or improperly seated connection is a common cause.
- **Partial Touch Response:** Recheck the flex cable connection. Sometimes, a partial connection can lead to unresponsive areas.
- **Screen Flickering/Display Issues:** While this product is a digitizer (touch layer) and not the LCD (display layer), display issues might indicate a problem with the LCD connection or the tablet's internal components. If the LCD was disturbed during installation, ensure its connections are secure.
- **Physical Damage:** If the new digitizer was damaged during installation, it may need to be replaced. Handle with extreme care.

If problems persist, it is advisable to seek assistance from a professional repair technician.

SPECIFICATIONS

Attribute	Detail
Compatible Model	Sky Devices Elite OctaMax 8 inch Panel
Product Type	Touch Screen Digitizer Glass Replacement
Brand	SRJTEK
ASIN	B0BDFLJP34
Item Weight	6.7 ounces
Package Dimensions	10.59 x 7.72 x 1.26 inches
Country of Origin	China
Date First Available	May 24, 2022

WARRANTY AND SUPPORT

SRJTEK offers a **6-month after-sale service** for this product. If the item received has any problems, you can contact SRJTEK customer service for assistance. We are committed to providing a new replacement or a satisfied solution.

For further support or to explore other products, please visit the official SRJTEK store:

[Visit the SRJTEK Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BDFLJP34>

More documents and user manuals: <https://manuals.plus/>