

Replacement Remote for Auna Multimedia Micro Stereo HD Bluetooth Soundbar Speaker System

Generic Replacement IR Remote Control User Manual

For Auna Multimedia Micro Stereo HD Bluetooth Soundbar Speaker System

1. INTRODUCTION

This manual provides instructions for the Generic replacement infrared (IR) remote control, designed to operate specific functions of the Auna Multimedia Micro Stereo HD Bluetooth Soundbar Speaker System. This remote is a direct replacement for the original remote control.

Important Note:

- This replacement remote control may not support all functions of the original remote. Some advanced or specific features might not be accessible.
- Ensure your Auna Multimedia Micro Stereo HD Bluetooth Soundbar Speaker System model is compatible with this replacement remote. If your specific model number is not explicitly listed as compatible, this remote may not function correctly.
- This remote operates using infrared (IR) technology. Ensure a clear line of sight between the remote and the Auna system's IR receiver.

2. SETUP

2.1 Battery Installation

The remote control requires two (2) CR2 batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Gently slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two CR2 batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back view of the remote control, illustrating the battery compartment. The compartment cover is typically located on the lower half of the remote's back side.

Caution:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote control will not be used for an extended period.

3. OPERATING INSTRUCTIONS

Once batteries are installed, the remote control is ready for use. Point the remote directly at the Auna Multimedia Micro Stereo HD Bluetooth Soundbar Speaker System's IR receiver.






Image: Front view of the remote control, displaying its buttons. Key functions include Power, Mute, Volume Up/Down, Channel/Track navigation, Play/Pause, and Input/Function selection.

3.1 Basic Functions

- **Power Button ()**: Press to turn the Auna system ON or OFF.
- **Mute Button ()**: Press to mute or unmute the audio.
- **Volume Up/Down (VOL+/VOL-)**: Press to increase or decrease the volume level.
- **Play/Pause ()**: Controls playback for media.
- **Previous/Next Track (/)**: Navigates between tracks or channels.

- **Function/Input (FUNC):** Cycles through available input sources (e.g., Bluetooth, AUX, USB).
- **Sleep (SLEEP):** Activates or deactivates the sleep timer function.

Refer to your Auna Multimedia Micro Stereo HD Bluetooth Soundbar Speaker System's original manual for detailed information on specific functions and their operation.

4. MAINTENANCE

4.1 Cleaning the Remote

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's range decreases or it becomes unresponsive. Follow the battery installation steps in Section 2.1. Dispose of used batteries responsibly according to local regulations.

5. TROUBLESHOOTING

If the remote control is not functioning as expected, consider the following:

- **No Response:**
 - Ensure new batteries are correctly installed with the correct polarity.
 - Replace old batteries with fresh ones.
 - Check for any obstructions between the remote and the Auna system's IR receiver.
 - Ensure you are within the effective range of the remote control (typically up to 20 feet/6 meters).
- **Limited Functionality:**
 - As a replacement remote, some advanced functions of the original system may not be supported. This is normal for universal or replacement remotes.
 - Verify that your Auna system model is indeed compatible with this replacement remote.

6. SPECIFICATIONS

Model	Replacement Remote for Auna Multimedia Micro Stereo HD Bluetooth Soundbar Speaker System
Brand	Generic
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Power Source	2 x CR2 Batteries (not included)
Compatible Devices	Auna Multimedia Micro Stereo HD Bluetooth Soundbar Speaker System

7. WARRANTY AND SUPPORT

As a generic replacement product, specific warranty and support details may vary. Please refer to the seller or retailer from whom you purchased this remote control for information regarding warranty coverage,

returns, or technical assistance.

For issues related to the Auna Multimedia Micro Stereo HD Bluetooth Soundbar Speaker System itself, please consult the original manufacturer's documentation or support channels.

© 2023 Generic Replacement Remote Control. All rights reserved.