

[Manuals.plus](#) /

> [ION](#) /

> ION Block Rocker XL - Portable Bluetooth Outdoor Party Speaker, 220W, with Karaoke Microphone, Battery, 5 Speakers, Lights, Radio, USB Charging & App 220W water-resistant w/ microphone

ION B0BDGJL6CL

ION Block Rocker XL Instruction Manual

Brand: ION | Model: B0BDGJL6CL (iPA150A)

INTRODUCTION

The ION Block Rocker XL is a high-power, all-weather portable Bluetooth-enabled speaker designed for dynamic sound in various environments. It features a premium 5-speaker sound system, long-lasting battery, and versatile connectivity options, making it ideal for outdoor parties, karaoke, and public speaking.

Key Features

- **220W High-Power Sound:** Delivers dynamic, powerful omnidirectional sound through an 8" woofer, two 1" tweeters, and two 3" drivers.
- **Portable Bluetooth Speaker:** Stream and control music wirelessly up to 100 ft via Bluetooth 5.3.
- **Long-Lasting Battery:** Features a rechargeable battery providing up to 90 hours of power.
- **IPX5 Water-Resistant:** Designed to withstand splashes and rain, suitable for outdoor use.
- **Built-in Handles and Wheels:** Ensures easy transportability.
- **Integrated FM Radio:** Includes presets for listening to your favorite stations.
- **Karaoke Ready:** Comes with a microphone and 8ft cable for public speaking and karaoke.
- **ION Sound XP App Control:** Easily control lighting, sound functions, and radio directly from your phone.
- **Touch FX Technology:** Utilize 4 back-lit pads to trigger 40 unique sound effects and record your own.
- **BOOM Button:** Instantly boosts music and lighting effects for enhanced party atmosphere.
- **Wireless Stereo Link:** Connect an additional Block Rocker XL for even more sound.



The ION Block Rocker XL, showcasing its robust design and included microphone.

WHAT'S IN THE BOX

- Block Rocker XL Speaker
- Power Cable
- Microphone with Cable (8ft)
- Quickstart Guide

SETUP

Charging the Speaker

Before first use, fully charge the Block Rocker XL. Connect the included power cable to the AC IN port on the back

of the speaker and plug it into a power outlet. The battery indicator on the display will show charging status. A full charge provides up to 90 hours of use.

CONNECTIVITY COVERED



Rear view of the Block Rocker XL, highlighting the AC input for charging.

Connecting via Bluetooth

1. Power on the Block Rocker XL by pressing the Power button.
2. Ensure your device's Bluetooth is enabled.
3. On the Block Rocker XL, press the Bluetooth button to enter pairing mode. The Bluetooth icon on the display will flash.
4. On your device, select "Block Rocker XL" from the list of available Bluetooth devices.
5. Once paired, the Bluetooth icon will be solid, and you can begin streaming audio.

Microphone and Instrument Connection

- Plug the included microphone into the 1/4" MIC IN port.
- For an instrument, plug it into the 1/4" INST IN port.
- Adjust the MIC and INST volume knobs on the control panel as needed.

OPERATING YOUR BLOCK ROCKER XL

Using the Radio

Press the FM button to switch to FM radio mode. Use the Tune/Track buttons to scan for stations. You can save up to 6 preset stations by holding down one of the numbered Radio buttons (1-6) until the display flashes.

Sound Effects (Touch FX)

The Block Rocker XL features Touch FX Technology with 4 back-lit pads. Press the FX Select button to cycle through different sound effect banks (DJ Effects, Drum Hits, Crowd Noise, Party Sounds). Press an FX Rec button to record your own sound effects.

BOOM Button

Press the BOOM button to instantly boost the bass, volume, and lighting effects for a more impactful audio experience. The party lights will pulse to the beat of the music.

MAKE EVERY EVENT A SPECIAL OCCASION



**220
WATTS**

**5 PREMIUM
SPEAKERS**



**WIRELESS
STEREO-LINK**



FM RADIO



TOUCH FX



BOOM BUTTON



Bluetooth® 5.3

The Block Rocker XL enhances any gathering with its powerful sound and dynamic features.

ION Sound XP App Control

Download the ION Sound XP app from your device's app store to control various functions of your Block Rocker XL directly from your smartphone or tablet. This includes adjusting volume, EQ, lighting modes, and radio settings.



CONVENIENT CONTROL

CONTROL LIGHTING AND SOUND FROM YOUR PHONE



Control your Block Rocker XL conveniently with the ION Sound XP app.

Official Product Video

Your browser does not support the video tag.

Official product video showcasing the ION Block Rocker XL's features and capabilities.

MAINTENANCE

Cleaning

Wipe the speaker with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure all ports are dry before connecting any cables.

Storage

Store the Block Rocker XL in a cool, dry place away from extreme temperatures. If storing for extended periods, ensure the battery is fully charged and recharge it every 3 months to maintain battery health.

Water Resistance

The speaker has an IPX5 water-resistant rating, meaning it can withstand splashes and light rain. It is not designed to be submerged in water. Always ensure the port covers are securely closed when exposed to moisture.

MADE TO MOVE



90 HOUR BATTERY

Delivers long-lasting fun



IPX5 WATER-RESISTANT

Safe to leave in the rain or near the pool



BACK-LIT BUTTONS

For easy operation in the dark



HANDLES AND WHEELS

For easy transportation

The Block Rocker XL is IPX5 water-resistant, making it suitable for poolside or beach use.

TROUBLESHOOTING

No Power: Ensure the power cable is securely connected and plugged into a working outlet. Check if the battery needs charging.

No Sound: Check the volume levels on both the speaker and your connected device. Ensure the correct input source (Bluetooth, AUX, Mic, Inst) is selected.

Bluetooth Pairing Issues: Make sure the speaker is in Bluetooth pairing mode (flashing icon). Try unpairing and re-pairing the device. Ensure no other devices are connected to the speaker via Bluetooth. Move closer to the

speaker to ensure you are within the 100 ft range.

Distorted Audio: Reduce the volume on both the speaker and your device. Check for interference from other electronic devices.

Microphone Not Working: Ensure the microphone is securely plugged into the MIC IN port and its volume knob is turned up.

SPECIFICATIONS

Feature	Detail
Model Name	iPA150A
Speaker Type	Outdoor
Speaker Configuration	5 speakers (8" woofer, two 1" tweeters, two 3" drivers)
Speaker Maximum Output Power	220 Watts
Battery Life	90 Hours
Water Resistance	IPX5 (Splash-resistant)
Wireless Communication Technology	Bluetooth 5.3
Bluetooth Range	100 Feet
Connectivity Protocol	Bluetooth, AUX (1/8"), 1/4" Mic In, 1/4" Instrument In
Control Method	App, Touch
Item Weight	27.1 pounds
Product Dimensions	15.47 x 11.04 x 18.98 inches

WARRANTY AND SUPPORT

The ION Block Rocker XL comes with a **Limited Warranty**. For detailed warranty information, troubleshooting beyond this manual, or to contact customer support, please refer to the official User Guide or visit the ION Audio website.

[Download Official User Guide \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question