

[Manuals.plus](#) /

› [Apple](#) /

› Apple iPhone 14 Pro Max Clear Case with MagSafe Instruction Manual

Apple MPU73ZM/A

Apple iPhone 14 Pro Max Clear Case with MagSafe Instruction Manual

Model: MPU73ZM/A

INTRODUCTION

This manual provides comprehensive instructions for the Apple iPhone 14 Pro Max Clear Case with MagSafe. Designed by Apple, this case offers protection for your iPhone 14 Pro Max while showcasing its original design. It features integrated MagSafe technology for enhanced wireless charging and accessory attachment.

The case is crafted from a blend of optically clear polycarbonate and flexible materials, ensuring a precise fit and comfortable grip. A scratch-resistant coating is applied to both interior and exterior surfaces, and all materials are optimized to resist yellowing over time.

SETUP: INSTALLING THE CASE

1. **Prepare your iPhone:** Ensure your iPhone 14 Pro Max is clean and free of dust or debris.
2. **Align the case:** Hold the case with the camera cutout aligned with your iPhone's camera system.
3. **Insert one side:** Gently push one side of your iPhone into the case, starting with the volume button side or the power button side.
4. **Snap into place:** Carefully press the remaining edges of your iPhone into the case until it is fully seated and secure. The flexible materials allow for easy installation.



Image: The Apple iPhone 14 Pro Max Clear Case with MagSafe, showcasing its transparent design and integrated MagSafe ring on the back. The case is designed to fit precisely over the iPhone, providing protection while allowing the phone's color to show through.

OPERATING INSTRUCTIONS

MagSafe Functionality

The case features built-in magnets that align perfectly with your iPhone 14 Pro Max. This enables a secure attachment for MagSafe accessories and ensures efficient wireless charging.

- **Attaching MagSafe accessories:** Simply bring a MagSafe charger or accessory close to the back of your cased iPhone. The magnets will automatically align and secure the accessory in place.
- **Wireless Charging:** For wireless charging, leave the case on your iPhone and snap on your MagSafe charger, or place it on a Qi-certified charger. The case is designed to facilitate faster wireless charging.

Button Access

The case is designed with precise cutouts and covers for all buttons, ensuring they remain fully functional and easy to

press without obstruction.

MAINTENANCE AND CARE

- **Cleaning:** To clean your case, remove it from your iPhone. Use a soft, lint-free cloth, slightly dampened with water, to gently wipe both the interior and exterior surfaces. Avoid abrasive cleaners or solvents.
- **Scratch Resistance:** The case features a scratch-resistant coating. However, avoid contact with sharp objects or abrasive surfaces to maintain its appearance.
- **Preventing Yellowing:** The materials and coatings are optimized to prevent yellowing over time. Regular cleaning helps maintain clarity.

TROUBLESHOOTING

- **Case not fitting correctly:** Ensure your iPhone is the correct model (iPhone 14 Pro Max) and that no foreign objects are obstructing the fit. Remove and re-install the case carefully.
- **MagSafe accessories not attaching securely:** Verify that both the case and the accessory are clean and free of debris. Ensure the accessory is a genuine MagSafe product or compatible with MagSafe technology.
- **Wireless charging issues:** Confirm that your MagSafe charger or Qi-certified charger is functioning correctly. Ensure the charger is properly aligned with the MagSafe ring on the back of the case.
- **Dust or debris under the case:** Periodically remove the case and clean both your iPhone and the case to prevent dust accumulation, which can cause minor scratches over time.

SPECIFICATIONS

Brand	Apple
Model Number	MPU73ZM/A
Compatible Phone Models	iPhone 14 Pro Max
Material	Polycarbonate
Color	Clear
Product Dimensions	7.6 x 3.8 x 0.63 inches
Item Weight	2.71 ounces
Date First Available	September 7, 2022

What's in the Box

- 1x iPhone 14 Pro Max Clear Case with MagSafe

WARRANTY INFORMATION

This Apple product is covered by Apple's standard one-year limited warranty against defects in materials and workmanship. For detailed warranty terms and conditions, please refer to the official Apple website or contact Apple Support. Proof of purchase may be required for warranty claims.

CUSTOMER SUPPORT

For further assistance, technical support, or service inquiries regarding your Apple iPhone 14 Pro Max Clear Case with MagSafe, please visit the official Apple Support website or contact Apple Customer Service directly. You can find contact information and support resources at support.apple.com.

