



Manuals.plus /

› Moen /

› Moen Meena Chrome Single-Handle Bathroom Faucet (Model 84794) Instruction Manual

## Moen 84794

# Moen Meena Chrome Single-Handle Bathroom Faucet

Model: 84794

## INTRODUCTION

---

This manual provides detailed instructions for the installation, operation, and maintenance of your Moen Meena Chrome One-Handle Single Hole Modern Bathroom Sink Faucet, Model 84794. Please read all instructions carefully before beginning installation to ensure proper function and to prevent damage.



Figure 1: Moen Meena Chrome Single-Handle Bathroom Faucet, Model 84794.

## **INCLUDED COMPONENTS**

---

Verify that all components are present before beginning installation:

- Bathroom Faucet
- Installation Hardware
- Optional 3-hole deck plate (escutcheon)
- Push-down drain assembly
- Instruction Manual (this document)

## SETUP AND INSTALLATION

---

The Moen Meena faucet is designed for flexible installation, accommodating both single-hole and three-hole sink configurations with the included optional deck plate. Ensure you have the necessary tools before starting.

### Before You Begin


- Turn off the main water supply to the bathroom.
- Clear the area under the sink for easy access.
- Remove any existing faucet and clean the sink surface.

### Installation Steps

1. **Prepare the Sink:** If your sink has three holes, place the optional deck plate over the holes. Ensure the gasket is properly seated.
2. **Install the Faucet:** Insert the faucet body through the center hole (and deck plate, if used). From underneath the sink, secure the faucet with the provided mounting hardware. Tighten securely but do not overtighten.
3. **Connect Water Supply Lines:** Attach the hot and cold water supply lines from the faucet to your home's water supply valves. Use a wrench to tighten connections, ensuring no leaks.
4. **Install Drain Assembly:** Follow the instructions provided with the push-down drain assembly to install it into the sink drain hole. Ensure a watertight seal.
5. **Test for Leaks:** Slowly turn on the main water supply. Check all connections for leaks. Operate the faucet to ensure proper water flow and temperature control.

# Will this faucet fit my sink?

This faucet fits a one or three hole configuration.



**MOEN**<sup>®</sup>

Figure 2: The faucet is compatible with both one-hole and three-hole sink configurations.

Spout Reach  
4.5"



Height  
7.42"

Maximum Deck Thickness - 1.13"  
Deckplate Included

Drain Included  
Supply Lines Included

Connection Size - 3/8"

1 or 3 Hole Installation

Figure 3: Key dimensions for installation, including spout reach (4.5"), height (7.42"), maximum deck thickness (1.13"), and connection size (3/8").

## OPERATING INSTRUCTIONS

The Moen Meena faucet features a single handle for easy control of water temperature and flow.

- **Water Flow:** Lift the handle to increase water flow. Push down to decrease or turn off the water.
- **Temperature Control:** Move the handle to the left for hot water and to the right for cold water. Adjust the handle position between left and right to achieve the desired water temperature.



Figure 4: Demonstrating the single-handle operation for water flow and temperature.

## MAINTENANCE AND CARE

---

To maintain the appearance and functionality of your Moen Meena faucet, follow these care guidelines:

- **Cleaning:** Clean the chrome finish regularly with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or polishes, as these can damage the finish.
- **Aerator Maintenance:** If water flow decreases, the aerator may be clogged. Unscrew the aerator from the spout, clean any debris, and reattach.
- **Water Quality:** This faucet complies with the Federal Safe Drinking Water Act and NSF 61 standards, ensuring safe drinking water.



Figure 5: Moen faucets are certified to meet U.S. water safety standards.

## TROUBLESHOOTING

If you encounter issues with your faucet, refer to the following common solutions:

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator or partially closed supply valve.	Clean the aerator. Ensure both hot and cold water supply valves are fully open.
Leaking from Spout	Worn cartridge or debris in the valve.	Contact Moen customer support for a replacement cartridge or service.
Leaking at Base	Loose mounting nut or improper seal.	Ensure the mounting nut under the sink is tight. Check the gasket for proper seating.
No Hot/Cold Water	Supply valve closed or cross-connection issue.	Verify hot/cold supply valves are open. Consult a plumber if cross-connection is suspected.

## SPECIFICATIONS

---

Feature	Detail
Brand	Moen
Model Name	MEENA
Model Number	84794
Color	Chrome
Material	Metal
Finish Type	Polished
Mounting Type	Deck Mount
Number of Handles	1
Hole Count	1 (with optional 3-hole deck plate)
Installation Type	Single Hole
Maximum Flow Rate	1.2 Gallons Per Minute (Meets WaterSense criteria)
Spout Height	5.1 Inches
Spout Reach	4.4 Inches
Product Dimensions	6"D x 6"W x 7.42"H
Item Weight	3.8 pounds
Special Feature	Durable
Certifications	NSF 61, WaterSense

## WARRANTY INFORMATION

---

The Moen Meena Chrome Single-Handle Bathroom Faucet, Model 84794, is backed by Moen's Limited Lifetime Warranty. This warranty covers defects in material and manufacturing workmanship for the original consumer purchaser. For specific terms, conditions, and to make a warranty claim, please refer to the official Moen warranty documentation or contact Moen customer support.

## CUSTOMER SUPPORT

---

For further assistance, technical support, or to order replacement parts, please contact Moen customer service. You can typically find contact information on the official Moen website or within the packaging materials that came with your product.

