

[Manuals.plus](#) /

> [FULLJA](#) /

> FULLJA 15-inch Smart Digital Picture Frame Model 15E4-Z User Manual

## FULLJA 15E4-Z

# FULLJA 15-inch Smart Digital Picture Frame User Manual

Model: 15E4-Z

## INTRODUCTION

---

This manual provides detailed instructions for the setup, operation, and maintenance of your FULLJA 15-inch Smart Digital Picture Frame (Model 15E4-Z). Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your user experience. Keep this manual for future reference.

## PACKAGE CONTENTS

---

Upon unpacking, please verify that all items listed below are present and in good condition:

- 1x FULLJA 15-inch Smart Digital Picture Frame (Model 15E4-Z)
- 1x Power Adapter
- 1x Remote Control
- 1x Kickstand (for tabletop placement)
- Wall Mount Accessories
- 1x User Manual (this document)



Image: FULLJA brand logo.

# Smart Photo Displayer with **32G** Capacity

A Perfect Way to Showcase All Your Core  
Memories in One Place



Image: The digital picture frame illustrating easy sharing via app or email.

## PRODUCT OVERVIEW

The FULLJA 15-inch Smart Digital Picture Frame is designed to display your photos and videos with ease. Key features include:

- **15-inch IPS Display:** Provides clear picture display with 1024\*768 pixel resolution and a 4:3 aspect ratio.
- **Touch Screen:** Intuitive navigation and control directly on the screen.
- **2.4GHz WiFi Connectivity:** Enables instant sharing of photos and videos via the Vphoto APP or email.
- **32GB Built-in Storage:** Ample space for a large collection of photos and videos.
- **Motion Sensor:** Automatically wakes the frame when presence is detected and sleeps when not.
- **Flexible Placement:** Supports wall mounting or tabletop use, with automatic content rotation for portrait or landscape orientation.
- **Remote Control:** Convenient operation from a distance.

Remote Control&Touchscreen  
User-friendly for Setting Up

Tabletop or Wall Mount  
Easy to place Anywhere

Built-in 32G Storage  
A Great Deal of Storage  
Flexibility

A Gorgeous Digital Frame  
Perfect Gift to Others or  
Home Decoration



Image: Overview of the smart picture frame's features.

## SETUP

---

1. **Power Connection:** Connect the power adapter to the frame and plug it into a power outlet. The frame will automatically power on.
2. **Initial Setup:** Follow the on-screen prompts to select your language, time zone, and connect to a 2.4GHz Wi-Fi network.
3. **App Download:** Download the "Vphoto" application from the Google Play Store or Apple App Store on your smartphone.
4. **Frame Binding:** Open the Vphoto app and follow the instructions to bind your frame using the provided QR code or device ID. This step establishes the connection for remote photo/video sharing.
5. **Placement:** Position the frame using the kickstand for tabletop display or the included wall mount accessories for wall installation. The display content will automatically rotate based on the frame's orientation.

## A Perfect Gift for Friends, Family Members or Yourself



Image: Visual guide for initial setup and content uploading.

## OPERATING INSTRUCTIONS

---

### 1. Uploading Photos and Videos

- **Via Vphoto App:** After binding your frame, select photos or videos from your smartphone gallery within the Vphoto app and send them directly to the frame.
- **Via Email:** The frame has a unique email address. You can send photos and videos as attachments to this address, and they will appear on the frame.
- **Via SD Card/USB Drive:** Insert a compatible SD card or USB drive (up to 32GB) into the designated slot. The frame will detect the storage and allow you to import media.

*Note: Videos may have a size limit (e.g., 200MB). Ensure your Wi-Fi connection is stable for optimal transfer speeds.*

# Multiple Ways to Use



Image: The digital frame connected to a smartphone via the Vphoto app for content sharing.

## 2. Display Settings

- **Slideshow:** Customize slideshow intervals, transition effects, and playback order through the frame's settings menu.
- **Brightness:** Adjust screen brightness to suit your environment.
- **Auto-Rotation:** The frame automatically adjusts the display orientation (portrait or landscape) based on its physical position.
- **Clock/Calendar/Weather:** Access these features through the frame's interface.

## 3. Motion Sensor

The integrated motion sensor detects movement in the room. When motion is detected, the frame will wake up and display photos/videos. When no motion is detected for a set period, the frame will enter sleep mode to conserve energy. This feature can be enabled or disabled in the settings.



Image: The motion sensor activating the frame when people are present.

#### **4. Remote Control**

Use the included remote control to navigate menus, adjust settings, and control media playback without touching the screen.

# All-in-one Smart Picture Frame



Touch Screen &  
Remote Control



Music/Video



Clock /Calendar/  
Weather



WiFi



Motion Sensor &  
Auto Rotate



Split-screen/  
Full Screen Mode



Adjustable Brightness  
Auto on/Off



Slideshow

Image: Using the remote control to operate the digital picture frame.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and frame. Avoid abrasive cleaners or solvents.
- **Software Updates:** Periodically check for and install software updates to ensure optimal performance and access to new features.
- **Storage Management:** Regularly review and delete unwanted photos or videos to manage the 32GB internal storage.

## TROUBLESHOOTING

Problem	Possible Cause / Solution
Frame does not power on.	Ensure the power adapter is securely connected to both the frame and a working power outlet.

Problem	Possible Cause / Solution
Cannot connect to Wi-Fi.	<ul style="list-style-type: none"> <li>◦ Ensure you are connecting to a 2.4GHz Wi-Fi network. The frame does not support 5GHz networks.</li> <li>◦ Verify the Wi-Fi password is correct.</li> <li>◦ Restart your Wi-Fi router and the digital frame.</li> <li>◦ Ensure the frame is within range of your Wi-Fi router.</li> </ul>
Photos/Videos not uploading via app or email.	<ul style="list-style-type: none"> <li>◦ Confirm the frame is successfully connected to Wi-Fi.</li> <li>◦ Verify the Vphoto app is correctly bound to the frame.</li> <li>◦ Check the frame's unique email address for accuracy.</li> <li>◦ Ensure the file size for videos does not exceed the limit (e.g., 200MB).</li> <li>◦ Restart the app and the frame.</li> </ul>
Motion sensor not working.	Check the frame's settings to ensure the motion sensor feature is enabled. Ensure there are no obstructions blocking the sensor.
Screen is unresponsive.	Try restarting the frame. If the issue persists, perform a factory reset (note: this will erase all stored data).

## SPECIFICATIONS

Feature	Detail
Brand	FULLJA
Model Number	15E4-Z
Screen Size	15 Inches
Display Resolution	1024*768 IPS Display
Aspect Ratio	4:3
Connectivity Technology	Wi-Fi (2.4GHz only)
Memory Storage Capacity	32 GB
Control Method	Touch, Remote
Power Source	DC
Item Weight	5.2 Pounds
Item Dimensions (L x W)	11.3"L x 13.98"W
Frame Material	Plastic

## WARRANTY AND SUPPORT

The FULLJA 15-inch Smart Digital Picture Frame comes with a one-year limited warranty. For warranty claims, technical support, or any questions regarding your product, please contact FULLJA customer service. Refer to the contact information provided with your purchase documentation or visit the official FULLJA website.

