

[Manuals.plus](#) /

› [Admiral](#) /

› Admiral 43-inch FHD Smart LED Android 11 TV Instruction Manual ADL43FMSACP

Admiral ADL43FMSACP

Admiral 43-inch FHD Smart LED Android 11 TV Instruction Manual

Model: ADL43FMSACP | Brand: Admiral

1. INTRODUCTION

Thank you for choosing the Admiral 43-inch FHD Smart LED Android 11 TV. This television is designed to provide an immersive viewing experience with its Full HD (1080p) resolution, vibrant LED backlighting, and smart features powered by Android 11. Enjoy seamless access to your favorite streaming services, connect various devices, and cast content effortlessly with built-in Google Cast.

This manual provides essential information for the safe and efficient use of your new television. Please read it thoroughly before installation and operation, and keep it for future reference.



2. SAFETY INFORMATION

Please observe the following safety precautions to prevent fire, electric shock, or injury.

- **Power Source:** Ensure the TV is connected to an AC 240V, 50/60Hz power supply. Do not overload power outlets.
- **Ventilation:** Do not block ventilation openings. Allow adequate space around the TV for proper airflow to prevent overheating.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Cleaning:** Unplug the TV before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Placement:** Place the TV on a stable, level surface or mount it securely to a wall. Keep it away from direct sunlight, heat sources, and strong magnetic fields.
- **Children:** Supervise children to ensure they do not climb on the TV or furniture.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Admiral 43-inch FHD Smart LED Android 11 TV
- Remote Control
- TV Stands (2 pieces)
- Screws for TV Stands
- Power Cable
- User Manual (this document)

4. SETUP

4.1 Attaching the Stands

1. Carefully place the TV face-down on a soft, clean surface to prevent screen damage.
2. Align each stand with the corresponding slots on the bottom of the TV.
3. Secure each stand with the provided screws. Ensure they are tightened firmly.



Figure 4.1: Illustration of stand attachment (side view for reference).

4.2 Wall Mounting (Optional)

If you prefer to wall-mount your TV, please use a VESA-compatible wall mount kit (not included). The VESA mounting standard for this TV is 50 x 50 mm. Follow the instructions provided with your wall mount kit and ensure professional installation for safety.

4.3 Connecting Power

Connect the power cable to the TV's power input port and then plug the other end into a suitable AC 240V wall outlet.

4.4 Connecting External Devices

Your Admiral TV offers multiple connectivity options for external devices:

- **HDMI:** Connect Blu-ray players, game consoles, set-top boxes, or other HDMI-enabled devices. This TV has 3 HDMI ports.
- **USB:** Connect USB flash drives or external hard drives to play media files. This TV has 2 USB ports.
- **VGA:** Connect a computer or laptop using a VGA cable.
- **Bluetooth:** Connect wireless headphones, soundbars, or other Bluetooth accessories.
- **Wi-Fi:** Connect to your home wireless network for internet access and smart TV features.




Figure 4.2: Rear view of the TV with input ports.

5. OPERATING INSTRUCTIONS

5.1 Remote Control Overview

The included remote control allows you to operate all functions of your TV. Familiarize yourself with the buttons:

- **Power Button:** Turns the TV on or off.
- **Navigation Buttons (Up/Down/Left/Right/OK):** Navigate menus and select options.
- **Volume Up/Down:** Adjusts the volume level.
- **Channel Up/Down:** Changes TV channels.
- **Home Button:** Returns to the Android TV home screen.
- **Input/Source Button:** Selects input sources (HDMI, USB, VGA, etc.).
- **App Buttons:** Quick access to pre-installed apps like YouTube, Netflix, Prime Video.
- **Google Assistant Button:** Activates voice control.

5.2 Initial Power On and Setup

1. Press the Power button on the remote control or on the TV.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and sign in with your Google account.
3. Complete the channel scan if you are connecting an antenna or cable.

5.3 Navigating Android TV

The Android TV home screen provides access to apps, settings, and content recommendations. Use the navigation buttons on your remote to browse and select items.

5.4 Smart Features

- **Streaming Apps:** Access popular services like YouTube, Netflix, and Prime Video directly from the home screen or app menu.
- **Google Cast:** Cast content from your compatible smartphone, tablet, or computer directly to your TV. Ensure both devices are on the same Wi-Fi network.
- **Bluetooth:** Pair Bluetooth devices such as headphones or game controllers through the TV's settings menu.
- **Google Assistant:** Use voice commands to search for content, control smart home devices, and get information by pressing the Google Assistant button on your remote.

6. MAINTENANCE

6.1 Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, lint-free cloth to gently wipe the screen. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner (do not spray directly on the screen).
- Wipe the TV casing with a soft, dry cloth. Avoid using abrasive cleaners or solvents.

6.2 Software Updates

Your Android TV may receive software updates periodically. It is recommended to keep your TV's software up to date for optimal performance and security. You can check for updates in the TV's settings menu.

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Ensure the power cable is securely plugged into the TV and the wall outlet. Check if the outlet is working.
No picture, but sound is present	Check the input source. Ensure the external device is powered on and connected correctly. Try another HDMI cable.
No sound, but picture is present	Check the volume level. Ensure the TV is not muted. Check audio settings and external device audio output.
Remote control not working	Replace the batteries. Ensure there are no obstructions between the remote and the TV.

Problem	Possible Solution
Cannot connect to Wi-Fi	Ensure your router is on and working. Re-enter the Wi-Fi password. Try restarting the TV and router.
Google Cast not working	Ensure both the TV and the casting device are connected to the same Wi-Fi network. Check app compatibility.

8. SPECIFICATIONS

Below are the detailed specifications for the Admiral 43-inch FHD Smart LED Android 11 TV (Model ADL43FMSACP):

Feature	Detail
Screen Size	43 inches
Display Technology	LED
Resolution	1920 x 1080 (FHD)
Refresh Rate	60 Hz
Operating System	Android 11
Special Features	Google Cast, Smart TV functionality
Connectivity Technology	HDMI, USB, Bluetooth, Wi-Fi, VGA
HDMI Ports	3
USB Ports	2
Aspect Ratio	16:9
Product Dimensions (D x W x H)	8 cm x 95 cm x 55 cm
Item Weight	6.6 kg
Color	Black
VESA Mounting Standard	50 x 50 mm
Audio Output Mode	Stereo
Speaker Description	Dolby Sound System
Surround Sound Channel Configuration	5.1
Power Consumption	60 Watts
Voltage	240 Volts
Included Components	Remote Control

Feature	Detail
Compatible Devices	Laptop, Desktop Computer, Tablet, Game Console, Mobile Phone
Recommended Uses	Home Entertainment, Movie Watching, Gaming, Internet Browsing
Model Year	2024

9. WARRANTY AND SUPPORT

9.1 Product Warranty

This Admiral 43-inch FHD Smart LED Android 11 TV comes with a **two-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your purchase receipt as proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Admiral customer support:

- **Website:** Visit the official Admiral website for support resources and contact information.
- **Email:** [Insert Customer Support Email Here]
- **Phone:** [Insert Customer Support Phone Number Here]

When contacting support, please have your TV model number (ADL43FMSACP) and purchase details ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question