

[Manuals.plus](#) /

> [Vicco](#) /

> Vicco Tetra Cube Storage Unit with 4 Folding Boxes - Instruction Manual

Vicco 1926

Vicco Tetra Cube Storage Unit with 4 Folding Boxes

Model: 1926

INTRODUCTION

This manual provides detailed instructions for the assembly, use, and maintenance of your Vicco Tetra Cube Storage Unit. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

Please observe the following safety guidelines during assembly and use:

- Keep all small parts and packaging materials away from children.
- Assemble the unit on a clean, soft surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overload the shelves. The maximum weight capacity per shelf is 10 kg.
- For stability, consider anchoring the unit to a wall, especially if children are present. Wall anchoring hardware may not be included.
- Avoid climbing or standing on the unit.

PACKAGE CONTENTS

Verify that all components listed below are present before starting assembly:

- 1x Tetra Cube Storage Unit (disassembled panels)
- 4x Folding Storage Boxes
- 1x Assembly Instructions Manual
- 1x Hardware Pack (screws, dowels, connectors)




Image: Overview of all included components and their dimensions.

SETUP AND ASSEMBLY

Follow these steps to assemble your Vicco Tetra Cube Storage Unit:

1. Step 1: Unpack and Identify Parts

Carefully unpack all components from the packaging. Lay them out on a soft, clean surface to prevent damage. Refer to the parts list in your hardware pack and the diagram above to identify each panel and piece of hardware.

2. Step 2: Assemble the Main Frame

Connect the side panels to the top and bottom panels using the provided dowels and screws. Ensure all connections are flush and secure. Use a screwdriver (not included) to tighten screws firmly but do not overtighten.

3. Step 3: Insert Shelf Panels

Slide the horizontal and vertical shelf panels into the pre-drilled slots. Secure them with the remaining hardware as indicated in the detailed assembly diagram (refer to the separate assembly instructions sheet for specific hardware

placement).

4. Step 4: Attach Back Panel (if applicable)

If a back panel is included, align it with the rear edges of the unit and secure it using small nails or screws.

5. Step 5: Assemble Folding Boxes

Unfold each fabric box. Insert the rigid bottom panel into the base of each box to give it shape and stability.



Image: Folding boxes before and after assembly.

6. Step 6: Final Placement

Carefully move the assembled unit to its desired location. Insert the assembled folding boxes into the cube compartments.



Image: Fully assembled storage unit with boxes in a room.

USAGE

The Vicco Tetra Cube Storage Unit is designed for versatile storage and organization. Each cube compartment is suitable for the included folding boxes or other items.

- **Storage:** Use the folding boxes to store clothes, toys, books, or other household items. The open shelves can display decorative items or hold larger books.
- **Room Divider:** The unit can function as a room divider due to its finished appearance from all sides.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 10 kg per shelf to ensure stability and longevity of the unit.

MAINTENANCE

To keep your storage unit in optimal condition:

- **Cleaning:** Wipe the unit's surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the melamine coating.
- **Dusting:** Regularly dust the unit to prevent buildup.
- **Folding Boxes:** The fabric boxes can be spot cleaned with a mild detergent and damp cloth. Allow them to air dry completely. Do not machine wash.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

Problem	Solution
Unit feels wobbly after assembly.	Ensure all screws and fasteners are fully tightened. Check that the unit is on a level surface. If necessary, use shims under the feet. Consider wall anchoring for added stability.
Parts do not fit together.	Double-check the assembly instructions and diagrams to ensure you are using the correct parts and orientation for each step. Do not force parts together.
Missing hardware or damaged parts.	Contact customer support with your product model number and a description of the missing or damaged items.

SPECIFICATIONS

Feature	Detail
Brand	Vicco
Model Number	1926
Color	White
Overall Dimensions (W x D x H)	72 cm x 29 cm x 72.6 cm
Material	16 mm Particle Board with Melamine Coating
Maximum Weight Capacity (per shelf)	10 Kilograms
Special Feature	Highly durable
Included Accessories	4x Folding Storage Boxes

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the retailer where the product was acquired. Keep your proof of purchase for any warranty claims.

For further assistance, you may visit the Vicco brand store: [Vicco Brand Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BDP1QV28>

More documents and user manuals: <https://manuals.plus/>