



Manuals.plus /

› HAPPYGRILL /

› HAPPYGRILL Outdoor Rattan Daybed Patio Loveseat Sofa Set (Model HG1477) Instruction Manual

HAPPYGRILL HG1477

HAPPYGRILL Outdoor Rattan Daybed Patio Loveseat Sofa Set

Model: HG1477

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your HAPPYGRILL Outdoor Rattan Daybed Patio Loveseat Sofa Set. Please read these instructions carefully before assembly and use to ensure proper function and longevity of your furniture.



Image: The assembled HAPPYGRILL Outdoor Rattan Daybed with grey cushions and decorative pillows, situated on a balcony overlooking a body of water.

SAFETY INFORMATION

- Do not use this daybed in windy conditions without proper securing.
- Always assemble the daybed according to the instructions to prevent tip-over and ensure stability.
- Keep children away from the assembly area and ensure they do not play on or around the daybed unsupervised.
- Store the daybed indoors or cover it when not in use to protect it from adverse weather conditions and extend its lifespan.
- Do not exceed the maximum weight capacity of 800 lbs (approximately 363 kg).

PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Rattan frame components (various sections for the daybed base, backrest, and armrests)
- Seat cushions (2 pieces)
- Pillows (quantity may vary, typically 2-4)
- Assembly hardware (bolts, washers, nuts, Allen wrench)
- Instruction manual

SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended that two people assemble the daybed for ease and safety. Please follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts listed in the 'Package Contents' section are present.
2. **Assemble Frame Sections:** Begin by connecting the main frame sections. Insert bolts loosely at first. **Important: Do not fully tighten any bolts until all components are assembled and aligned.** This allows for flexibility to ensure all holes line up correctly.
3. **Attach Backrest and Armrests:** Secure the backrest and armrest components to the main frame. Again, insert bolts loosely.
4. **Final Tightening:** Once all frame components are connected and properly aligned, gradually tighten all bolts using the provided Allen wrench. Ensure all connections are secure but do not overtighten.
5. **Place Cushions and Pillows:** Position the seat cushions onto the rattan base. Arrange the pillows as desired.



Image: The rattan frame of the daybed without cushions, illustrating the structural components before cushion placement.

OPERATING INSTRUCTIONS

The HAPPYGRILL Outdoor Rattan Daybed is designed for comfortable outdoor and indoor relaxation. Its spacious design accommodates two people.

- **Placement:** Position the daybed on a flat, stable surface. For outdoor use, consider placing it in a shaded area or under a patio cover to protect it from direct sunlight and rain, which can prolong the life of the rattan and cushions.
- **Usage:** The daybed provides a comfortable seating or lounging area. The armrests and backrest offer support and enhance comfort.
- **Weight Capacity:** Adhere strictly to the 800 lbs weight limit to prevent damage and ensure safety.



Image: The daybed positioned in a lush garden, demonstrating its suitability for various outdoor environments.

MAINTENANCE

Regular maintenance will help preserve the appearance and extend the life of your daybed.

- **Rattan Frame:** The weather-resistant PE rattan can be cleaned with a soft cloth and mild soap and water. Rinse thoroughly and allow to air dry. Avoid harsh chemicals or abrasive cleaners.
- **Cushions and Pillows:** The cushion covers are designed with zippers for easy removal. They are waterproof and

can be hand-washed or machine-washed on a gentle cycle with cold water. Air dry only; do not tumble dry. Ensure cushions are completely dry before re-attaching to prevent mildew.

- **Storage:** During prolonged periods of non-use or severe weather, it is recommended to store cushions indoors and cover the rattan frame with a protective cover.

Dimensions




Image: A detailed view of the cushion, highlighting the zippered cover for easy removal and cleaning, and the tear-resistant fabric.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Difficulty Aligning Holes During Assembly:** Ensure all bolts are only finger-tightened initially. This allows for slight adjustments to the frame. Once all parts are in place, then proceed to fully tighten the bolts.
- **Cushions Sliding:** If cushions tend to slide, consider applying hook-and-loop fasteners (Velcro) to the underside of the cushions and the rattan frame to secure them in place.
- **Wobbly Frame:** Check that all bolts are securely tightened. If the issue persists, disassemble and reassemble, ensuring all connections are properly seated before tightening.
- **Water Absorption by Cushions:** While covers are waterproof, prolonged exposure to heavy rain can lead to some moisture absorption. Tilt cushions to drain water or bring them indoors during heavy precipitation.

SPECIFICATIONS

Feature	Detail
Brand	HAPPYGRILL
Model Number	HG1477
Product Dimensions (L x W x H)	61"D x 52"W x 27.5"H (155 cm D x 132 cm W x 70 cm H)
Seat Depth	52 inches (132 cm)
Seat Height	14.5 inches (37 cm)
Weight Limit	800 Pounds (363 kg)
Seating Capacity	2
Item Weight	53 Pounds (24 kg)
Frame Material	Alloy Steel
Rattan Material	PE Rattan
Cushion Fill Material	High-Density Sponge (Foam)
Upholstery Color	Grey (as per current model)
Assembly Required	Yes



Image: A detailed diagram illustrating the key dimensions of the daybed, including length, width, height, and cushion measurements.

WARRANTY INFORMATION

For specific warranty details, please refer to the warranty card included with your product or contact HAPPYGRILL customer service directly. Warranty coverage typically includes manufacturing defects under normal use conditions.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact HAPPYGRILL customer service. Contact information can typically be found on the product packaging, the manufacturer's website, or through your retailer.