Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yostyle Double Electric Breast Pump

Yostyle Double Electric Breast Pump User Manual

Model: Double Electric Breast Pump

1. Introduction

Thank you for choosing the Yostyle Double Electric Breast Pump. This manual provides essential information for the safe and effective use of your breast pump. Please read it thoroughly before first use and keep it for future reference.

The Yostyle Double Electric Breast Pump is designed to provide an efficient and comfortable milk expression experience. It features multiple modes and suction levels, a hands-free design, and is made from food-grade, BPA-free materials.

2. Safety Information

Important Safeguards:

- Always keep the pump and its components out of reach of children.
- Do not immerse the motor unit in water or other liquids.
- Use only the provided USB charging cable.
- Inspect all components before each use for any damage. Discard and replace damaged parts immediately.
- Do not use while bathing or showering.
- This device is for personal use only. Do not share with others.
- If you experience pain or discomfort, reduce suction or stop pumping. Consult a healthcare professional if pain persists.

3. Package Contents

The Yostyle Double Electric Breast Pump package includes the following items:

- 1 x LCD Screen Host (Motor Unit)
- 2 x Silicone Shields
- 2 x Milk Collection Bottles (180ml capacity each)
- 2 x Silicone Hoses
- 1 x USB Charging Cable
- 1 x User Manual



Image: All components included in the Yostyle Double Electric Breast Pump package.

4. Product Features

- **Efficient and Painless Pumping:** Supports simultaneous or single-side pumping, saving time. Soft silicone massage cushion mimics a baby's sucking rhythm for a gentle and comfortable experience.
- **Multiple Modes and Suction Levels:** Features 4 distinct modes (Prolactin, Massage, Suction, Bionic) and 9 adjustable suction levels to customize your pumping experience.
- **Anti-Backflow Design:** Equipped with a silicone valve to prevent milk from flowing back into the motor or tubing, ensuring hygiene and preventing secondary contamination.
- **Food-Grade Materials:** All milk contact parts are made from soft, food-grade, BPA-free silicone, free from harmful substances, ensuring safety for you and your baby.
- **Smart Design with LCD Screen:** Clear LED touch screen for easy operation and monitoring.
- **Rechargeable and Portable:** Built-in 2200mAh lithium battery with USB charging for convenient use anywhere.

- **Ultra-Quiet Operation:** Operates at less than 48dB, allowing for discreet pumping without disturbing others.



Image: Overview of the breast pump's control panel showing 4 modes and 9 suction levels.



Image: Illustration of the breast pump's low noise operation, less than 48dB.

5. Specifications

Feature	Detail
Materials	Polypropylene, ABS, Silicone (BPA-free)
Lithium Battery	3.7V / 2200mAh
Bottle Capacity	180 ml (recommended optimal pumping volume 120ml)
Charging Method	USB
Noise Level	Less than 48 dB
Modes	4 (Prolactin, Massage, Suction, Bionic)

Suction Levels	9
Shipping Dimensions	20.4 x 20 x 11.1 cm
Weight	650 grams

6. Setup

6.1. Before First Use

1. **Clean and Sterilize:** Disassemble all parts that come into contact with breast milk (silicone shields, bottles, silicone hoses). Wash them thoroughly with warm soapy water, rinse, and then sterilize using a sterilizer or by boiling in water for 5 minutes. Do not sterilize the motor unit or USB cable.
2. **Charge the Battery:** Connect the USB charging cable to the motor unit and a suitable USB power adapter (not included). Charge the pump fully before first use. The LED screen will indicate charging status.

6.2. Assembly

Follow these steps to assemble the breast pump:

1. Insert the silicone valve into the bottom of the breast shield connector.
2. Attach the silicone shield firmly to the breast shield connector.
3. Screw the milk collection bottle onto the bottom of the breast shield connector.
4. Connect one end of the silicone hose to the top of the breast shield connector and the other end to the motor unit's air outlet. For double pumping, repeat for the second set of components and connect both hoses to the Y-connector, then to the motor unit.
5. Ensure all connections are secure to prevent air leakage and maintain optimal suction.




Image: Assembly options for double and single pumping.



Image: Detailed view of the anti-backflow design and component assembly.

7. Operating Instructions

7.1. Powering On/Off

- Press and hold the power button () on the LCD screen to turn the pump ON or OFF.

7.2. Selecting Modes

The pump has 4 modes:

- **Prolactin Mode:** Gentle, rapid suction to stimulate milk let-down.
- **Massage Mode:** Rhythmic massage to prepare breasts for pumping.
- **Suction Mode:** Steady, deeper suction for efficient milk expression.
- **Bionic Mode:** Mimics a baby's natural sucking pattern.

Press the mode button (**M**) to cycle through the different modes. The active mode will be indicated on the LCD screen.

7.3. Adjusting Suction Levels

Each mode has 9 adjustable suction levels:

- Press the **+** button to increase suction strength.
- Press the **-** button to decrease suction strength.

Start with a low suction level and gradually increase it to a comfortable setting that allows for efficient milk flow without causing pain.

7.4. Pumping Session

1. Ensure your hands are clean.
2. Center the silicone shield over your nipple, ensuring a good seal against your breast.
3. Turn on the pump and select your desired mode and suction level.
4. Pump until milk flow slows or stops, typically 15-20 minutes per breast.
5. Turn off the pump and carefully remove the breast shield from your breast.
6. Disconnect the bottle(s) and store the milk appropriately.

8. Cleaning and Maintenance

Proper cleaning and maintenance are crucial for hygiene and the longevity of your breast pump.

8.1. After Each Use

1. **Disassemble:** Separate all parts that came into contact with breast milk (silicone shields, bottles, silicone hoses).
2. **Wash:** Wash these parts immediately in warm soapy water. Use a soft brush to clean all surfaces.
3. **Rinse:** Rinse thoroughly with clean water.
4. **Sterilize:** Sterilize the parts using a dedicated sterilizer or by boiling them in water for 5 minutes. Ensure parts do not touch the bottom or sides of the pot to prevent damage.
5. **Dry:** Air dry on a clean rack or use a clean cloth. Store in a clean, dry place.

Note: Do not wash or sterilize the motor unit or USB charging cable. Wipe the motor unit with a clean, damp cloth if necessary.

8.2. Charging



Image: Multiple power source options for charging the breast pump via USB.

- The pump is equipped with a 2200mAh rechargeable lithium battery.
- Charge the pump using the provided USB cable and a standard USB power adapter (e.g., phone charger, power bank, computer USB port).
- A full charge provides extended use. The battery indicator on the LCD screen shows the current charge level.

9. Troubleshooting

Problem	Possible Cause	Solution

No suction or weak suction	◦ Improper assembly ◦ Damaged silicone valve or shield ◦ Hose not connected properly ◦ Low battery	◦ Reassemble all parts, ensuring a tight seal. ◦ Check silicone valve and shield for tears or damage; replace if necessary. ◦ Ensure hoses are securely connected to both the motor unit and breast shield connectors. ◦ Charge the pump fully.
Pump not turning on	◦ Battery is depleted ◦ Power button not pressed correctly	◦ Charge the pump. ◦ Press and hold the power button firmly for a few seconds.
Milk flowing back into tubing	◦ Silicone valve not properly installed or damaged	◦ Ensure the silicone valve is correctly seated. ◦ Inspect the valve for any damage and replace if necessary. ◦ Clean the tubing if milk has entered it, then air dry completely.
Pain or discomfort during pumping	◦ Suction level too high ◦ Incorrect breast shield size ◦ Improper nipple alignment	◦ Reduce the suction level to a comfortable setting. ◦ Ensure the breast shield fits your nipple correctly. Consult a lactation consultant if unsure. ◦ Reposition the breast shield to ensure your nipple is centered.

10. Warranty and Support

Warranty information for this product is not explicitly provided in the product details. Please refer to the retailer's return policy or contact Yostyle customer support for specific warranty terms and conditions.

For further assistance or inquiries, please contact Yostyle customer service through the platform where you purchased the product.

© 2023 Yostyle. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BDRFQ6J2

More documents and user manuals: **https://manuals.plus/**