

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PATPET](#) /

› [PATPET Dog Shock Collar with Remote - Waterproof Dog Training Collar for Small Medium Large Dogs with Beep, Vibration and 16 Static Levels Shock One Collar Pink](#)

## PATPET B0BDRMNTTS

# PATPET Dog Shock Collar with Remote Instruction Manual

Model: B0BDRMNTTS | Brand: PATPET

## INTRODUCTION

This instruction manual provides detailed guidance for the safe and effective use of your PATPET Dog Shock Collar with Remote. Please read this manual thoroughly before operating the device to ensure proper training and care for your dog.



*The PATPET Dog Shock Collar with Remote, featuring a pink remote and collar unit.*

## PRODUCT OVERVIEW

---

### Key Components:

- Remote Transmitter
- Receiver Collar
- Adjustable Collar Belt
- Charging Cable
- Test Light Tool
- Contact Points (short and long)
- Conductive Silicone Covers

### Features:

- **3 Safe Training Modes:** Beep, Vibration, and 16 Static Levels.
- **IPX7 Waterproof Receiver:** Allows for training in various weather conditions and water activities.
- **Security Keypad Lock:** Prevents accidental activation of training modes.
- **Rechargeable and Long-Lasting Battery:** Remote lasts up to 27 days, receiver up to 11 days.
- **Adjustable Collar Belt:** Suitable for dogs weighing 10 lbs to 140 lbs.
- **1000ft Remote Range:** Provides extensive control distance for outdoor training.

## SETUP

---

### 1. Adjusting the Collar Strap

Ensure the collar fits snugly but comfortably around your dog's neck. It should be tight enough for the contact points to make proper contact with the skin, but not so tight as to cause discomfort. You can adjust the length and trim any excess strap.



The adjustable collar belt can be sized for dogs from 10 to 140 lbs.

Video: Demonstrates how to adjust the collar strap to the appropriate length for your dog.

## 2. Installing the Metal Contact Sheets

Attach the metal contact points to the receiver unit. For dogs with shorter coats, use the shorter contact points. For dogs with thicker or longer coats, use the longer contact points to ensure proper skin contact. You may also use the conductive silicone covers over the contact points for added comfort and protection.

Video: Instructions on how to properly install the metal contact sheets and conductive silicone covers onto the receiver collar.

## 3. Charging the Devices

Both the remote and the receiver collar are rechargeable. Use the provided charging cable to charge both units simultaneously. A red LED light indicates charging, and it will turn green when fully charged.



The remote offers up to 27 days of work time, and the receiver up to 11 days on a single charge.

Video: Guide on how to properly charge both the remote and the receiver collar.

## 4. Pairing the Remote and Receiver

To ensure the remote and receiver communicate effectively, they must be paired. Follow the steps in the video to successfully pair your devices.

Video: Step-by-step instructions on how to pair the remote transmitter with the receiver collar.

# OPERATING INSTRUCTIONS

## 1. Training Modes

The PATPET Dog Shock Collar offers three distinct training modes to suit various training needs:

- **Beep Mode:** Emits an audible tone. Ideal for initial training and gaining your dog's attention.
- **Vibration Mode:** Delivers a gentle vibration. Useful for reinforcing commands or as a mild deterrent.
- **Static Mode:** Provides a static stimulation with 16 adjustable levels. Use this mode cautiously and at the lowest effective level.

### 3 Training Modes



The remote offers Beep, Vibration, and Static modes for versatile training.

### 2. Adjusting the Shock Level

The static stimulation level can be adjusted from 1 to 16 using the knob on the remote. Always start with the lowest level and gradually increase it only if necessary, observing your dog's reaction.

*Video: Instructions on how to adjust the static shock level on the remote transmitter.*

### 3. Locking the Remote

To prevent accidental activation of training modes, especially when carrying the remote, utilize the keypad lock feature. This ensures your dog's safety and prevents unintended corrections.




The security keypad lock feature helps prevent accidental shock.

*Video: Demonstrates how to lock and unlock the remote to prevent accidental button presses.*

### 4. Remote Range

The remote transmitter has an effective range of up to 1000 feet, allowing for flexible training in various outdoor environments.



*The collar offers a remote range of up to 1000 feet for effective training.*

## MAINTENANCE

---

### Cleaning:

- Regularly clean the receiver collar and contact points with a damp cloth to remove dirt and debris.
- Ensure the charging port is dry and free of foreign objects before charging.

### Battery Care:

- Charge the devices fully before first use.
- Avoid overcharging or completely draining the battery to prolong its lifespan.
- If storing for an extended period, charge the devices every few months to maintain battery health.

### Storage:

- Store the collar and remote in a cool, dry place away from extreme temperatures.
- Keep out of reach of children and pets when not in use.



*The IPX7 waterproof receiver allows your dog to enjoy water activities without damaging the collar.*

## TROUBLESHOOTING

### **Collar Not Responding:**

- Ensure both the remote and receiver are fully charged.
- Check if the remote and receiver are properly paired. If not, re-pair them following the setup instructions.
- Verify that the collar is turned on and the remote is not in lock mode.
- Ensure the contact points are making proper contact with your dog's skin. Adjust the collar fit or use longer contact points if necessary.

### **Device Not Charging:**

- Check the charging cable for any damage.
- Ensure the charging cable is securely connected to both the device and the power source.
- Try a different power adapter or USB port.

### **Static Stimulation Not Working:**

- Use the provided test light tool to confirm the static function is operational.
- Ensure the contact points are firmly against your dog's skin.
- Increase the static level gradually to find an effective setting.

## SPECIFICATIONS

Attribute	Value
Brand Name	PATPET

Attribute	Value
Model Number	B0BDRMNTTS
Item Weight	9.1 ounces
Item Dimensions LxWxH	5.79 x 4.25 x 0.04 inches
Waterproof Rating	IPX7 (Receiver)
Training Modes	Beep, Vibration, Static (16 Levels)
Remote Range	Up to 1000 feet
Battery Life (Remote)	Up to 27 days
Battery Life (Receiver)	Up to 11 days
Suitable Dog Weight	10 lbs to 140 lbs
Color	Pink

## WARRANTY & SUPPORT

For warranty information, product support, or any inquiries, please visit the official PATPET store or contact their customer service directly. You can find more information and contact details on the [PATPET Amazon Store](#).

© 2023 PATPET. All rights reserved.