

PPLEE CR1023

PPLEE Alarm Clock User Manual

Model: CR1023

Brand: PPLEE

INTRODUCTION

This manual provides comprehensive instructions for setting up and operating your PPLEE Alarm Clock. Please read it thoroughly to ensure proper use and to take full advantage of all features.



Image: The PPLEE Alarm Clock displaying "12:00" with a smartphone connected for charging.

SETUP

Power Source and Battery Backup

The PPLEE Alarm Clock is primarily powered by an AC outlet (100-240V). The included power adapter must be connected for all functions (digital display, phone charging, dimmer, etc.) to operate.



Image: Rear view of the alarm clock highlighting the power input and battery compartment.

For battery backup, install 2 AAA batteries (not included) into the designated compartment. These batteries are solely for memorizing time and alarm settings during a power outage. The display will go blank, but the alarm function will still work. No need to reset time when power is restored.



Image: What's in the box - Alarm clock, user manual, power adapter, and power cable.

OPERATING INSTRUCTIONS

Time Setting (12H/24H & DST)

To set the time, press the "TIME/DST" button. The hour display will start flickering. Use the "+" or "-" buttons to adjust the hour. Press "TIME/DST" again to confirm the hour and move to minute setting. Adjust minutes with "+" or "-" and press "TIME/DST" to save.

To switch between 12-hour and 24-hour formats, press the "12/24H" button.

The clock also supports Daylight Saving Time (DST). Press and hold the "TIME/DST" button to activate or

deactivate DST.



Image: Examples of 12H, 24H, and DST time displays.

Alarm Setting (Dual Alarms, Volume, Snooze)

This alarm clock features dual alarms (Alarm 1 and Alarm 2) for different schedules.

1. To set Alarm 1, press the "ALARM 1" button. The hour display will flicker. Use "+" or "-" to set the hour, then press "ALARM 1" to confirm.
2. The minute display will then flicker. Use "+" or "-" to set the minutes, then press "ALARM 1" to save.
3. Repeat the process for Alarm 2 using the "ALARM 2" button.

Dual Alarm Clock

Set 2 Alarms Based on Schedules




Image: Visual representation of setting dual alarms for different wake-up times.

Alarm Volume Adjustment

The alarm volume can be adjusted to 7 different levels, ranging from 50dB to 120dB. Rotate the volume knob (located on the side/rear) to increase or decrease the alarm sound.

7 Volume Adjustable Digital Alarm



Image: A visual scale indicating the 7 adjustable volume levels for the alarm.

Snooze Function

When the alarm sounds, lightly touch the large "SNOOZE/NIGHT LIGHT" button on top to activate the 9-minute snooze function. The alarm will temporarily pause and sound again after 9 minutes.

Touch to Get 9 Mins Snooze

Slightly Touch to Get a Warm Beside Lamp



Image: Demonstrating the touch-sensitive snooze button on top of the clock.

Brightness Adjustment

The LED display brightness is fully adjustable from 0-100%. Use the rotary dimmer switch (located on the side/rear) to set your preferred brightness level. This allows for comfortable viewing day or night.

Brightness-Linear Rotary Switch

7 inch Display with 0-100% Brightness Adjustable



Image: The alarm clock display at different brightness settings, illustrating the full dimming range.

Night Light

The alarm clock features a night light at the rear. To turn it on or off, lightly touch the "SNOOZE/NIGHT LIGHT" button on the top of the clock. This provides a soft, ambient light.

USB & Type-C Charging Ports

The alarm clock is equipped with both a USB (5V/1A) and a Type-C (5V/1A) output port. These ports allow you to conveniently charge two digital devices, such as your smartphone or smartwatch, simultaneously.

Dual USB Charging Ports



USB 5V/1A



Type C 5V/1A



Image: The alarm clock providing power to a smartphone and a tablet via its integrated charging ports.

MAINTENANCE

To clean the alarm clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the finish. Keep the device away from excessive moisture and direct sunlight.

TROUBLESHOOTING

Problem	Solution
Display is blank.	Ensure the power adapter is securely plugged into both the clock and a working electrical outlet. If using battery backup, the display will be blank during a power outage, but the alarm function will still work.
Alarm does not sound.	Check if the alarm is activated (Alarm 1 or Alarm 2 indicator should be visible on the display). Verify the alarm volume is not set to the lowest level. Ensure the time is set correctly for AM/PM.

Problem	Solution
Cannot set time/alarm.	Follow the time/alarm setting instructions carefully. Ensure you are pressing the correct buttons ("TIME/DST", "ALARM 1", "ALARM 2") and using the "+" or "-" buttons for adjustment.
Charging ports not working.	Confirm the clock is connected to AC power. The charging ports require the main power supply to function. Check the charging cables for damage.

SPECIFICATIONS

Feature	Detail
Brand	PPLEE
Model Number	CR1023
Display Type	LED
Power Source	corded electric and battery backup
Battery Backup	2 x AAA (for settings memory only)
Charging Ports	1 x USB 5V/1A, 1 x Type-C 5V/1A
Alarm Type	Dual Alarms
Alarm Volume	7 levels (50dB to 120dB)
Snooze Duration	9 Minutes
Display Brightness	0-100% Adjustable
Dimensions	1.77" W x 3.03" H
Item Weight	9.9 ounces

WARRANTY AND SUPPORT

PPLEE provides an 18-month warranty, 12-month replacement, and 3-month refund policy for this product. For any questions or technical support, please contact the seller directly.

You can also refer to the official user manual PDF for more detailed information:

[Download User Manual \(PDF\)](#)

PRODUCT VIDEOS

PPLEE Digital Alarm clock with Big LED Number for Bedroom

Your browser does not support the video tag.

This video provides an overview of the PPLEE Digital Alarm Clock, highlighting its large LED display and suitability for bedrooms.

