

Classic World 50566

Classic World Wooden Dollhouse Treehouse

Model: 50566

Brand: Classic World

INTRODUCTION

Welcome to the Classic World Wooden Dollhouse Treehouse instruction manual. This unique 31-piece playset is designed to inspire imaginative play and creativity in children aged 3 years and up. Crafted from natural wood, it features a multi-level tree structure with various interactive accessories.

Please read this manual carefully before assembly and use to ensure safe and proper enjoyment of the product. Keep this manual for future reference.

Important Safety Information

- Adult assembly is required.
- Ensure all parts are securely fastened before allowing children to play.
- Regularly inspect the toy for any loose or damaged parts. Discontinue use if damage is found.
- This toy contains small parts before assembly and is not suitable for children under 3 years due to choking hazards.
- Use only as intended for play. Do not stand or climb on the treehouse.

PARTS LIST

The Classic World Wooden Dollhouse Treehouse set includes a total of 31 components. Before beginning assembly, please verify that all parts are present and undamaged by comparing them with the diagram provided on the product packaging or included assembly sheet.



Figure 1: Fully assembled Classic World Wooden Dollhouse Treehouse, showcasing the main structure, two dolls, and various accessories like a swing, bucket, and seesaw.

- Main tree structure components
- Two platform levels
- Dollhouse structure for upper platform
- Two wooden dolls
- Accessories: seesaw, tire swing, bucket with rope and pulley, ladder, small fences, table, chairs, and other decorative elements.

If any parts are missing or damaged, please contact Classic World customer support.

SETUP AND ASSEMBLY

Follow these general steps for assembling your Wooden Dollhouse Treehouse. Refer to the detailed assembly instructions and diagrams included in your product packaging for specific part identification and connection points.

1. **Prepare the Area:** Clear a spacious, flat, and clean area for assembly.
2. **Identify Main Tree Base:** Begin by assembling the base components of the tree structure. Ensure they are stable and interlock correctly.
3. **Attach Platforms:** Securely attach the lower and upper platforms to the main tree trunk according to the provided diagrams. Pay attention to the orientation of each platform.
4. **Assemble Dollhouse:** Construct the small dollhouse structure and place it on the upper platform.
5. **Add Fences and Railings:** Install the small fence pieces around the edges of the platforms for safety and aesthetic appeal.
6. **Attach Accessories:**
 - Attach the tire swing to the designated branch.
 - Assemble the bucket with its rope and pulley system and attach it to the appropriate point.
 - Position the ladder connecting the ground or lower platform to the upper levels.
 - Place the seesaw on a flat surface near the treehouse.
7. **Place Furniture and Dolls:** Arrange the small table, chairs, and other decorative elements on the platforms as desired. Place the two wooden dolls in their new treehouse home.
8. **Final Check:** Before play, double-check all connections to ensure they are tight and stable.



Figure 2: An alternative view of the assembled treehouse, highlighting the interior of the small house, the swing, and the bucket system.

OPERATING THE TREEHOUSE

The Classic World Wooden Dollhouse Treehouse is designed for open-ended imaginative play. Here are some ways to interact with its features:

- **Dolls:** Use the two included wooden dolls to populate the treehouse. They can move between levels using the ladder or interact with the various accessories.
- **Tire Swing:** Place a doll on the tire swing and gently swing it back and forth.
- **Bucket and Pulley:** Use the bucket and rope system to "lift" or "lower" small items between the ground and the lower platform.
- **Seesaw:** Place dolls on either end of the seesaw and gently rock it.
- **Role-Playing:** Encourage children to create their own stories and scenarios within the treehouse environment, fostering creativity and social skills.

MAINTENANCE AND CARE

Proper care will extend the life of your Classic World Wooden Dollhouse Treehouse:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Avoid excessive moisture.
- **Drying:** Allow the toy to air dry completely after cleaning.
- **Storage:** Store the treehouse in a dry place, away from direct sunlight and extreme temperatures, to prevent warping or fading of the wood.
- **Inspection:** Periodically check all connections and parts for looseness or wear. Tighten screws if necessary (if applicable) or replace worn parts.

TROUBLESHOOTING

If you encounter any issues with your Classic World Wooden Dollhouse Treehouse, please refer to the following common solutions:

- **Loose Connections:** If parts feel wobbly, re-check the assembly instructions and ensure all interlocking pieces are fully engaged.
- **Missing Parts:** If you discover a part is missing during assembly, refer to the "Parts List" section and contact Classic World customer support with your product model number and the specific missing part.
- **Damaged Parts:** If any part is damaged upon arrival or during assembly, do not attempt to force it. Contact customer support for a replacement.

SPECIFICATIONS

Attribute	Detail
Product Dimensions	15.75 x 13.78 x 19.69 inches
Item Weight	2.75 pounds
ASIN	B0BDS9DTLC
Item Model Number	50566
Manufacturer	Classic World
Material	Natural Wood
Number of Pieces	31
Recommended Age	3 years and up









Figure 3: The Classic World Wooden Dollhouse Treehouse displayed in a natural outdoor setting, emphasizing its wooden construction and play potential.

WARRANTY AND SUPPORT

Classic World products are manufactured with high-quality materials and craftsmanship. For information regarding warranty coverage, product support, or to order replacement parts, please visit the official Classic World website or contact their customer service department directly. Contact details can typically be found on the product packaging or the manufacturer's website.

For general inquiries, you may also visit the [Classic World Store on Amazon](#).

Related Documents - 50566

	<p>Lincoln Logs Classic Lodge Building Set Instructions</p> <p>Step-by-step instructions for building the Classic Lodge with Lincoln Logs, America's National Toy. Learn how to assemble this classic wooden building set from Hasbro.</p>
	<p>Classic World Fire Station Building Toy Assembly Instructions</p> <p>Step-by-step guide to assembling the Classic World Fire Station building toy. Includes age recommendations and piece counts for a fun construction experience.</p>
	<p>Lincoln Logs Redfield Ranch Building Set - 124 Pieces</p> <p>Build the classic Redfield Ranch with the Lincoln Logs building set. This 124-piece toy, suitable for ages 3+, features real wood logs and offers hours of creative construction play. Includes figures, accessories, and instructions.</p>
	<p>Classic WORLD Police Station Toy - Assembly Guide</p> <p>Step-by-step assembly instructions for the Classic WORLD Police Station toy. Suitable for children aged 3+, this guide details how to build the playset with included parts.</p>
	<p>Classic World House Building Blocks Assembly Guide</p> <p>Step-by-step assembly instructions for the Classic World House building block set, featuring detailed visual descriptions for each stage. Suitable for ages 3+.</p>
	<p>Classic World Hospital Building Toy Assembly Instructions</p> <p>Step-by-step assembly guide for the Classic World Hospital building toy, detailing the construction process for ages 3+.</p>

Documents - Classic World – 50566

no relevant documents