

Cellularline BTFINETWSO

Cellularline FINE Transparent TWS Wireless In-Ear Earbuds

Model: BTFINETWSO

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your Cellularline FINE Transparent TWS Wireless In-Ear Earbuds. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

The Cellularline FINE Transparent TWS Wireless In-Ear Earbuds feature a distinctive transparent design, showcasing the internal components of both the earbuds and their charging case. Designed for comfort and high-quality audio, these earbuds offer up to 3.5 hours of playtime per charge, extended to a total of 10 hours with the charging case. They include intuitive touch controls for managing calls and music, and an auto-pairing function for effortless connection. The Double Master function allows for independent use of either earbud.

SAFETY INFORMATION

- Do not expose the earbuds or charging case to extreme temperatures, humidity, or liquids.
- Avoid dropping, impacting, or disassembling the device. This may void the warranty.
- Keep out of reach of children and pets.
- Use only the provided charging cable or a certified equivalent.
- Listen at moderate volume levels to prevent hearing damage.
- Do not use the earbuds in situations where inability to hear ambient sounds could be dangerous (e.g., driving, cycling, walking in traffic).

PACKAGE CONTENTS

Please check the package for the following items:

- Cellularline FINE Transparent TWS Wireless In-Ear Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual

PRODUCT OVERVIEW

The Cellularline FINE earbuds are designed for ease of use and a distinctive aesthetic. Below is an overview of the main components.





Image: Cellularline FINE Transparent TWS Wireless In-Ear Earbuds in their charging case. The earbuds and case feature a transparent orange design, revealing internal circuitry.

TRANSPARENT DESIGN



Image: Close-up view highlighting the transparent design of the Cellularline FINE earbuds, showing the internal components.

Components:

- **Earbuds:** Left and Right, with touch control surfaces and microphones.
- **Charging Case:** Houses and charges the earbuds, with a charging port and LED indicator.
- **Touch Control Area:** Located on the outer surface of each earbud for various functions.
- **Microphone:** Integrated into each earbud for calls.

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and to a compatible USB power source (e.g., computer, wall adapter).
3. The LED indicator on the charging case will show the charging status. Once fully charged, the indicator will change or turn off.
4. A full charge provides approximately 3.5 hours of playtime for the earbuds, and the case can provide up to 4 additional charges, totaling 10 hours of playtime.

PLAY TIME



Image: Illustration showing the earbuds and charging case, indicating 3.5 hours of playtime per single charge and 10 hours of total playtime with the charging case.

2. Pairing with Your Device (Auto-Pairing)

The earbuds feature an auto-pairing function for quick and easy connection.

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case and remove both earbuds. They will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "Cellularline FINE" (or similar name) from the list.
4. Once connected, you will hear an audible confirmation, and the earbuds will be ready for use.
5. For subsequent uses, the earbuds will automatically connect to the last paired device when removed from the case.



Image: A smartphone displaying a music player interface, with the Cellularline FINE earbuds and charging case nearby, illustrating the fast Bluetooth pairing process.

3. Wearing the Earbuds

For optimal sound quality and comfort, ensure the earbuds are properly seated in your ears.

- Gently insert each earbud into the corresponding ear (L for left, R for right).

- Adjust the earbud until it feels secure and comfortable.

COMFORT & STABILITY



Image: A woman smiling while wearing the Cellularline FINE earbuds, demonstrating comfort and stability during use.

OPERATING INSTRUCTIONS

Touch Controls

The Cellularline FINE earbuds feature intuitive touch controls on each earbud. The specific functions may vary slightly depending on your device and operating system.

Action	Function
Single Tap (Left or Right Earbud)	Play/Pause music, Answer/End call
Double Tap (Right Earbud)	Next Track

Action	Function
Double Tap (Left Earbud)	Previous Track
Triple Tap (Left or Right Earbud)	Activate Voice Assistant
Long Press (Right Earbud)	Increase Volume
Long Press (Left Earbud)	Decrease Volume
Long Press (2 seconds) during incoming call	Reject Call

Single Earbud Use (Double Master Function)

The Double Master function allows you to use either the left or right earbud independently. This is useful for calls or when you need to be aware of your surroundings.

- Simply remove one earbud from the charging case. It will automatically connect to your device.
- The other earbud can remain in the case or be used later.
- To switch back to stereo mode, simply remove the second earbud from the case.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently remove any earwax or debris from the earbud tips and speaker mesh using a small, soft brush or cotton swab.
- Ensure the charging contacts on both the earbuds and the case are clean and free of dust.

Storage

- When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter any issues with your Cellularline FINE earbuds, refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing or connecting	<ul style="list-style-type: none"> ◦ Ensure both earbuds are charged. ◦ Turn off and on your device's Bluetooth. ◦ Forget "Cellularline FINE" from your device's Bluetooth list and try pairing again. ◦ Place earbuds back in the case, close it, wait a few seconds, then remove them to re-initiate auto-pairing.

Problem	Possible Solution
Only one earbud working	<ul style="list-style-type: none">◦ Ensure both earbuds are charged.◦ Place both earbuds back in the charging case, close the lid, then open it and remove both earbuds simultaneously.◦ Check if the earbud's charging contacts are clean.
Low volume or poor sound quality	<ul style="list-style-type: none">◦ Adjust the volume on both your device and using the earbud touch controls.◦ Ensure earbuds are properly seated in your ears.◦ Clean any debris from the earbud speaker mesh.◦ Try moving closer to your connected device to avoid interference.
Earbuds not charging	<ul style="list-style-type: none">◦ Ensure the charging cable is securely connected to both the case and the power source.◦ Check if the charging contacts on the earbuds and inside the case are clean.◦ Try a different USB charging cable or power adapter.

SPECIFICATIONS

Feature	Detail
Brand	Cellularline
Model Number	BTFINETWSO
Color	Transparent Orange
Ear Placement	In-Ear
Form Factor	In-Ear
Noise Isolation	Acoustic Isolation
Connectivity Technology	Wireless (Bluetooth)
Included Components	Earbuds
Rechargeable Battery	Yes (Lithium-ion)
Special Features	Volume Control, Microphone Included
Control Method	Touch
Recommended Uses	Music Listening, Phone Calls, Sports, Outdoor Leisure
Compatible Devices	Laptops, Tablets, Mobile Phones, Music Production Equipment
Material	Plastic
Earbud Playtime	Up to 3.5 hours

Feature	Detail
Total Playtime (with case)	Up to 10 hours

WARRANTY AND SUPPORT

Cellularline products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service, please refer to the official Cellularline website or contact their customer service directly. Keep your proof of purchase for warranty claims.
For further assistance, please visit: www.cellularline.com