

[Manuals.plus](#) /

› [Accutime](#) /

› Accutime GSM9005 Super Mario Kids Analog Watch Instruction Manual


Accutime GSM9005

Accutime GSM9005 Super Mario Kids Analog Watch Instruction Manual

Model: GSM9005

INTRODUCTION

This manual provides instructions for the Accutime GSM9005 Super Mario Kids Analog Watch. Designed to assist children in learning to tell time, this watch features clearly labeled hour and minute hands, an engaging Super Mario design, and a comfortable, adjustable strap.






Image: Front view of the Accutime GSM9005 Super Mario Kids Analog Watch, showcasing the blue strap and the Super Mario themed dial with labeled hour and minute hands.

SETUP

Setting the Time

1. **Pull out the Crown:** Locate the small knob (crown) on the right side of the watch case. Gently pull it outwards until you feel a click. The second hand may stop moving.
2. **Adjust the Hands:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
3. **Push in the Crown:** Once the time is set, push the crown back into its original position. The second hand should resume movement (if applicable).

Adjusting the Strap

The watch features an adjustable acrylic strap. To adjust the fit:

- Locate the buckle and the series of holes on the strap.

- Select the hole that provides a comfortable and secure fit on the child's wrist.
- Fasten the buckle through the chosen hole.

OPERATING THE WATCH

Learning to Tell Time (Time Teacher Feature)

This watch is designed as a "Time Teacher" to help children learn analog time. Key features include:

- **Labeled Hands:** The hour hand is labeled "HOUR" and the minute hand is labeled "MINUTE" for easy identification.
- **Numbered Dial:** The main dial displays hours 1-12.
- **Minute Markers:** The outer bezel features minute markers (05, 10, 15, etc.) to aid in reading minutes.
- **Super Mario Design:** The engaging Super Mario characters on the dial make learning more enjoyable.






Image: Close-up view of the watch dial, clearly showing the "HOUR" and "MINUTE" labels on the hands, the numbered hours, and the minute markers on the bezel.

MAINTENANCE

Cleaning

To clean the watch, gently wipe the case and strap with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.

Battery Replacement

The watch is powered by a non-rechargeable SR626SW (1.5V) button cell battery. When the watch stops or runs intermittently, the battery may need replacement. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and function.

Warning:

- Do not attempt to recharge the battery.
- Keep batteries out of reach of small children.
- Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running or running slowly	Depleted battery	Replace the SR626SW battery.

Problem	Possible Cause	Solution
Time is incorrect	Crown is pulled out; Time was not set correctly	Push the crown in completely. Re-set the time as per "Setting the Time" instructions.
Strap feels uncomfortable or too loose/tight	Incorrect strap adjustment	Adjust the strap to a suitable hole for a comfortable fit.

SPECIFICATIONS

- **Model Number:** GSM9005
- **Brand:** Accutime
- **Movement:** Analog Quartz
- **Case Material:** Stainless Steel
- **Case Diameter:** Approximately 3.2 cm
- **Strap Material:** Acrylic
- **Strap Length:** Approximately 20 cm (adjustable)
- **Battery Type:** SR626SW (1.5V) button cell (non-rechargeable)
- **Weight:** 32 grams

WARRANTY INFORMATION

Specific warranty details for the Accutime GSM9005 watch are not provided in the product description. Please refer to the packaging or contact Accutime customer support for warranty information.

SUPPORT

For further assistance or inquiries regarding your Accutime GSM9005 watch, please contact Accutime customer support. Contact information may be available on the product packaging or the official Accutime website.

© 2024 Accutime. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question