

[Manuals.plus](#) /

› [OVENTE](#) /

› OVENTE Steam Mop Replacement Pads for ST405 Series Instruction Manual

OVENTE ACPST4054

OVENTE Steam Mop Replacement Pads for ST405 Series Instruction Manual

Model: ACPST4054

Brand: OVENTE

INTRODUCTION

Thank you for choosing OVENTE Steam Mop Replacement Pads. These high-density microfiber cleaning pads are specifically designed for the OVENTE ST405 Series Steam Mop, providing an effective and convenient solution for maintaining clean floors. This manual provides essential information on the features, setup, operation, and maintenance of your replacement pads to ensure optimal performance and longevity.



Image: A pack of four white OVENTE steam mop replacement pads with blue striped patterns.

PRODUCT FEATURES

- **Affordable Set:** Includes 4 microfiber replacement pads for continuous cleaning.
- **Convenient & Effective:** Durable pads suitable for all hard-floor surfaces including hardwood, laminate, tile, and marble. Features Velcro straps for easy attachment and detachment.
- **Compatible with ST405 Series:** Specifically designed to fit OVENTE ST405 Series Steam Mops.
- **Effortless Cleaning:** Made of breathable microfiber with good water absorption, effectively removing dust, stains, dander, and hair.
- **Washable & Reusable:** Can be machine washed or hand washed and are quick to dry. Constructed from high-quality materials to prevent shedding, fluffing, or fading after repeated washing.



COMPATIBLE

*Design to use with Ovente
Steam Mop ST405 series*

Image: An OVENTE steam mop alongside three replacement pads, emphasizing their compatibility with the ST405 series.

SETUP INSTRUCTIONS

1. **Ensure Mop is Off and Cool:** Before attaching or detaching pads, ensure your OVENTE ST405 Series Steam Mop is unplugged and completely cool to prevent burns.
2. **Align Pad:** Place the microfiber replacement pad on a flat surface with the Velcro side facing up.
3. **Attach to Mop Head:** Carefully align the steam mop head with the pad, ensuring the Velcro strips on the mop head match those on the pad. Press firmly to secure the pad in place. The Velcro ensures a snug fit for effective cleaning.

4. **Optional Carpet Glider:** If cleaning carpets, attach the carpet glider over the mop head with the pad already attached.



Image: A close-up of a hand attaching a white microfiber replacement pad to the triangular head of a steam mop using Velcro fasteners.

OPERATING INSTRUCTIONS

Once the replacement pad is securely attached to your OVENTE ST405 Series Steam Mop, you can proceed with your cleaning tasks. These pads are designed to work seamlessly with the steam mop's cleaning action.

- Ensure the steam mop is filled with water according to its own instruction manual.
- Plug in the steam mop and allow it to heat up until steam is ready.
- Begin mopping your desired hard-floor surface. The microfiber pad will effectively capture dirt, grime, and dust as the steam loosens it.
- For thorough cleaning, move the mop slowly over the surface.

- Replace the pad when it becomes visibly soiled to maintain cleaning efficiency.

MAINTENANCE AND CARE

Proper maintenance of your OVENTE Steam Mop Replacement Pads will extend their lifespan and ensure continued cleaning performance.

1. **Detaching the Pad:** After use, ensure the steam mop is unplugged and cool. Gently peel the soiled pad off the mop head.
2. **Washing:** The pads are washable and reusable.
 - **Machine Wash:** Place the pads in a washing machine with similar colors. Use a mild detergent. Do not use bleach or fabric softeners, as these can degrade the microfiber.
 - **Hand Wash:** Wash the pads by hand using warm water and a mild detergent. Rinse thoroughly until all soap residue is removed.
3. **Drying:** Hang the pads to air dry. Do not tumble dry or iron, as high heat can damage the microfiber material. Ensure pads are completely dry before storing or reattaching to the mop.
4. **Storage:** Store clean, dry pads in a clean, dry place until ready for next use.

WASHABLE AND REUSABLE

*Simply detach the cleaning pad
and throw it in the washer*



Image: A hand is shown placing a white microfiber steam mop pad into the open drum of a washing machine, illustrating its washable and reusable nature.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Pad not attaching securely.	Velcro on pad or mop head is dirty or worn.	Clean Velcro strips on both the pad and mop head. If severely worn, replace the pad.
Pad not cleaning effectively.	Pad is too soiled or has residue from fabric softener.	Wash the pad thoroughly. Ensure no fabric softener is used during washing. Replace if heavily soiled or damaged.

Problem	Possible Cause	Solution
Pad shedding lint after washing.	Incorrect washing or drying method.	Ensure pads are air-dried and not tumble-dried. Avoid harsh detergents.

SPECIFICATIONS

Attribute	Detail
Brand	OVENTE
Model Name	ACPST4054
Compatible Mop Series	OVENTE ST405 Series Steam Mop
Material	High-density Microfiber
Color	White - Pack of 4
Item Weight	3.52 ounces (0.1 Kilograms)
Care Instructions	Hand Wash / Machine Wash (No Bleach, No Fabric Softener)
Country of Origin	China
UPC	814667028013




Image: A diagram showing the dimensions of a single OVENTE steam mop replacement pad, measuring approximately 11.38 inches in length and 7.38 inches in width.

WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the original OVENTE ST405 Series Steam Mop manual or visit the official OVENTE website. These replacement pads are designed to work with your OVENTE appliance and are covered under standard accessory terms.

For customer support, technical assistance, or to purchase additional replacement pads, please contact OVENTE customer service or visit their official website:

OVENTE Official Website: www.ovente.com

Amazon Brand Store: [OVENTE Store on Amazon](#)