

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GoSports](#) /

› [GoSports Premium Wooden Golf Bag Organizer and Storage Rack Single - Black Instruction Manual](#)

## GoSports GOLF-STORAGE-WD-SNGL-BLK

# GoSports Premium Wooden Golf Bag Organizer and Storage Rack Single - Black Instruction Manual

Model: GOLF-STORAGE-WD-SNGL-BLK

## INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your GoSports Premium Wooden Golf Bag Organizer and Storage Rack. Please read these instructions carefully before assembly and use to ensure proper function and longevity of your product.

The GoSports Premium Wooden Golf Bag Organizer is designed to provide a stylish and efficient storage solution for your golf equipment, including one full-size golf bag, golf shoes, and various accessories.

## SETUP AND ASSEMBLY

Assembly is required for this product. Please ensure all components are present before beginning. An illustrated step-by-step guide is included with the product for easy setup.

### Included Components:

- Wooden Golf Bag Organizer panels
- Hardware (screws, connectors, etc.)
- 1 Artificial Turf Mat

### Assembly Steps:

1. Unpack all components and verify against the included parts list.
2. Follow the step-by-step instructions provided in the packaging. It is recommended to have two people for assembly to hold parts steady.
3. Secure all connections firmly using the provided hardware.
4. Place the artificial turf mat in the designated golf bag compartment.



Image: Overview of the GoSports Premium Wooden Golf Bag Organizer components, including the bag compartment, shelves, and turf mat.

# ALL-IN-ONE GOLF STORAGE SOLUTION

INCLUDES SIMPLIFIED VIDEO ASSEMBLY GUIDE



Image: Diagram illustrating the assembled dimensions of the GoSports Premium Wooden Golf Bag Organizer: 29 inches (width) x 37 inches (height) x 17 inches (depth).

## OPERATION AND STORAGE

The organizer is designed for efficient and secure storage of your golf equipment.

### Storing Your Golf Bag:

- Place your golf bag into the large compartment on the left side of the organizer. The compartment is designed to accommodate one full-size golf bag.
- Utilize the optional safety cord (if included) to secure the golf bag in place, preventing accidental tipping or movement.

### Storing Accessories:

- The five shelves on the right side are suitable for storing 4-5 pairs of golf shoes.
- The top shelf and other available shelf space can be used for smaller accessories such as golf balls, tees, gloves, towels, and other personal items.



Image: The GoSports Premium Wooden Golf Bag Organizer fully loaded with a golf bag, clubs, shoes, and accessories, demonstrating its storage capacity.



**SECURE BAGS  
WITH INCLUDED  
SHOCK CORDS**

**PERFECT FOR AVID GOLFERS**

**FITS 1 GOLF BAG OF ALMOST ANY SIZE**

Image: A person securing a golf bag within the organizer using the included shock cords, highlighting the stability feature.

## MAINTENANCE

Proper care will ensure the longevity and appearance of your GoSports Golf Bag Organizer.

### Cleaning:

- Wipe down the wooden surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the black matte finish.
- For the artificial turf mat, shake out any debris or vacuum lightly.

### General Care:

- Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- Avoid placing excessively heavy items on the shelves to prevent damage.
- Keep the organizer in a dry environment to prevent moisture damage to the wood.

## TROUBLESHOOTING

If you encounter any issues with your GoSports Premium Wooden Golf Bag Organizer, please refer to the following common solutions or contact customer support.

## Stability Issues:

- Ensure all assembly hardware is securely tightened. Loose connections can affect stability.
- Verify the organizer is placed on a flat, level surface.

## Missing Parts:

- If any parts were missing upon delivery, please contact GoSports customer service immediately with your purchase details.

## SPECIFICATIONS

---

Feature	Detail
Brand	GoSports
Model Number	GOLF-STORAGE-WD-SNGL-BLK
Color	Black
Style	Single - Black
Material Type	Engineered Wood
Number of Items	1
Features	Lightweight
Sport	Golf
Included Components	Wooden Golf Bag Organizer, Hardware, 1 Artificial Turf Mat
Product Dimensions (Assembled)	43.18 cm (D) x 73.66 cm (W) x 93.98 cm (H) / 17 in (D) x 29 in (W) x 37 in (H)
Item Weight	18.01 kg
Number of Shelves	5
Assembly Required	Yes
Mounting Type	Floor Mount
Recommended Uses	Golf Accessories, Golf Bags, Golf Shoes

## WARRANTY INFORMATION

---

Specific warranty details for the GoSports Premium Wooden Golf Bag Organizer are typically provided with your purchase documentation or can be found on the official GoSports website. Please retain your proof of purchase for any warranty claims.

## **CUSTOMER SUPPORT**

---

For further assistance, missing parts, or any questions regarding your GoSports Premium Wooden Golf Bag Organizer, please contact GoSports customer service. GoSports offers US-backed customer service to assist you.

Please visit the official GoSports website for contact information and additional resources.