

[Manuals.plus](#) /

› [Karl home](#) /

› Karl home Large Kids Dress-Up Storage with Mirror - Assembly and Usage Manual

Karl home B0BF55JC9F

Karl home Large Kids Dress-Up Storage with Mirror - Instruction Manual

Model: B0BF55JC9F

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Karl home Large Kids Dress-Up Storage unit. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Carefully handle all components during assembly. Some edges may be sharp.
- Ensure the product is fully assembled and stable before allowing children to use it.
- Do not allow children to climb on the unit.
- Periodically check all fasteners to ensure they remain tight. Retighten as necessary.
- Keep small parts and assembly hardware away from young children to prevent choking hazards.
- Assemble on a soft, clean surface to prevent scratching the product finish.

3. PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- 1x Wardrobe Frame (MDF components)
- 1x Accessory Bag (containing all necessary hardware and tools)
- 3x Non-Woven Drawers

- 1x Full-Length Mirror (pre-attached or to be attached during assembly)



Image: Overview of the assembled Karl home Kids Dress-Up Storage unit, showing hanging space, top shelf, and three bottom drawers.

4. ASSEMBLY INSTRUCTIONS

Assembly is required. Follow the included assembly instructions carefully. A screwdriver is typically provided in the accessory bag. It is recommended to assemble the unit with two people for easier handling and stability.

1. **Unpack Components:** Lay out all wooden panels, hardware, and non-woven drawers on a clean, soft surface to prevent scratches. Identify each part using the provided diagrams in the separate assembly guide.
2. **Assemble Frame:** Connect the side panels to the base and top panels using the provided screws and cam locks. Ensure all connections are secure and flush.
3. **Install Hanging Rod and Hooks:** Attach the hanging rod and any additional hooks or beads to the designated areas on the side panels.
4. **Attach Mirror:** If the full-length mirror is not pre-attached, carefully secure it to the designated side panel using the

provided fasteners.

5. **Insert Drawers:** Place the three non-woven drawers into their respective compartments at the bottom of the unit.
6. **Final Check:** Once assembled, gently shake the unit to ensure it is stable. Retighten any loose fasteners.



Image: Dimensional diagram of the storage unit, indicating height, width, and depth.

5. OPERATING INSTRUCTIONS (USAGE)

The Karl home Dress-Up Storage unit is designed for organizing children's clothing, accessories, and toys.

- **Hanging Rod:** Use the hanging rod for dresses, costumes, and other garments.
- **Hook Beads:** Utilize the rear hook beads for hanging hats, bags, or other small accessories.
- **Top and Bottom Shelves:** The open shelves provide space for dolls, books, or other toys.
- **Non-Woven Drawers:** The three bottom drawers are suitable for storing shoes, socks, underwear, or smaller items.
- **Full-Length Mirror:** The integrated mirror allows children to view their outfits, promoting self-expression and organization.



Image: A child interacting with the storage unit, highlighting the full-length mirror feature.



Image: Detailed view of the three non-woven fabric drawers, demonstrating their use for storing various items.

6. MAINTENANCE

To maintain the appearance and longevity of your storage unit:

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the unit with a soft, dry cloth.
- **Hardware Check:** Periodically inspect all screws and fasteners. Tighten any that have become loose to ensure structural integrity.
- **Drawer Care:** The non-woven drawers can be spot cleaned with a mild detergent and air-dried.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit is wobbly or unstable.	Loose fasteners; uneven assembly.	Ensure all screws and cam locks are fully tightened. Verify that all panels are correctly aligned and flush. Assemble on a flat, level surface.
Parts do not fit together.	Incorrect orientation of parts; mislabeled parts; manufacturing defect.	Double-check the assembly diagrams to ensure parts are oriented correctly. If parts appear mislabeled or defective, contact customer support for replacements.
Strong odor from the unit.	New product off-gassing.	Place the unit in a well-ventilated area for several days to allow the odor to dissipate.
Mirror is not clear.	Protective film still on; mirror is not glass.	Check for a thin protective film that may need to be peeled off. Note that the mirror may be an acrylic safety mirror, which can have a slightly different reflection than glass.

8. SPECIFICATIONS

- Model:** B0BF55JC9F
- Brand:** Karl home
- Color:** White
- Material:** MDF (Medium-Density Fiberboard)
- Number of Drawers:** 3 (Non-Woven Fabric)
- Dimensions (L x W x H):** 23.62" x 11.81" x 42.13" (60 x 30 x 107 cm)
- Item Weight:** Approximately 28 pounds
- Included Components:** 1x Wardrobe, 1x Accessory Bag
- Care Instructions:** Wipe with Damp Cloth

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact Karl home directly through their official website or the retailer where the product was purchased.

Manufacturer: Karl home

UPC: 810176560594

