

[manuals.plus](#) /› [AWEI](#) /› [AWEI T35 Gaming Earbuds User Manual](#)**AWEI T35**

# AWEI T35 Gaming Earbuds User Manual

Model: T35

## 1. INTRODUCTION

Thank you for choosing the AWEI T35 Gaming Earbuds. These wireless Bluetooth earbuds are designed to provide a high-quality audio experience with features tailored for gaming, including low latency and dedicated game/music modes. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds.

## 2. PACKAGE CONTENTS

- AWEI T35 Gaming Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- Silicone Ear Tips (various sizes)
- User Manual

## 3. PRODUCT OVERVIEW

The AWEI T35 earbuds feature a compact design with touch controls and LED breath lights. The charging case provides portable power and also features LED indicators.




Image: The AWEI T35 Gaming Earbuds, red in color, are shown inside their matching charging case. The case is open, revealing the earbuds nestled within, with blue LED lights illuminating the interior.

## Earbud Components:

- **Touch Control Area:** Located on the outer surface of each earbud for various functions.
- **LED Indicator:** Displays pairing status, charging status, and operating mode.
- **Microphone:** Integrated for calls and voice commands.
- **Charging Contacts:** Located on the stem of each earbud.

## Charging Case Components:

- **Earbud Charging Slots:** Securely hold and charge the earbuds.
- **Type-C Charging Port:** For charging the case.
- **LED Indicators:** Show the charging status of the case and earbuds.

## 4. SETUP

### 4.1 Charging the Earbuds and Case

1. **Initial Charge:** Before first use, fully charge the earbuds and charging case.
2. **Charging the Case:** Connect the provided USB Type-C cable to the charging port on the case and to a USB power source (e.g., computer, wall adapter). The case's LED indicators will show charging progress.
3. **Charging the Earbuds:** Place the earbuds into the charging case. Ensure the charging contacts align. The earbuds will automatically begin charging. The LED indicators on the earbuds will show their charging status.

A full charge for the case typically takes approximately 1.5 hours. The earbuds can achieve 80% charge in about 35 minutes using quick charge technology.

# Type-C Fast Charging Port Recharge Quickly



Image: A white AWEI T35 charging case is shown connected to a USB Type-C charging cable, indicating its fast charging capability. The case has blue LED lights illuminated on its front.

## 4.2 Pairing with a Bluetooth Device

- Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode. The LED indicators on the earbuds will flash, typically alternating red and blue, or a similar pattern indicating pairing mode.
- Activate Bluetooth:** On your device (smartphone, tablet, computer, etc.), enable Bluetooth.
- Select Device:** Search for available Bluetooth devices and select "AWEI T35" from the list.
- Confirmation:** Once connected, the earbud LED indicators will stop flashing and may turn off or show a steady light. You will also hear an audio prompt confirming the connection.

The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

## 5. OPERATING INSTRUCTIONS

The AWEI T35 earbuds feature intuitive touch controls for various functions.



Image: The AWEI T35 charging case and earbuds are displayed, highlighting the touch control area on the earbuds with a glowing yellow fingerprint icon, indicating sensitive and simple one-touch operation.

## 5.1 Basic Functions

- **Power On:** Open the charging case or long-press the touch area for 3 seconds.
- **Power Off:** Place earbuds back into the charging case and close the lid, or long-press the touch area for 5 seconds.
- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Volume Up:** Triple tap the right earbud.
- **Volume Down:** Triple tap the left earbud.

## 5.2 Call Management

- **Answer/End Call:** Single tap on either earbud.

- **Reject Call:** Long-press the touch area for 2 seconds on either earbud.

## 5.3 Game/Music Mode Switching

- **Switch Mode:** Long-press the touch area on the **left** earbud for 2 seconds. You will hear an audio prompt indicating the mode change (e.g., "Game Mode" or "Music Mode").

## 5.4 Voice Assistant

- **Activate Voice Assistant:** Long-press the touch area on the **right** earbud for 2 seconds.

# 6. MAINTENANCE

---

## 6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Ensure charging contacts on both earbuds and case are clean and free of debris to ensure proper charging.

## 6.2 Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid storing in extreme temperatures or high humidity.

## 6.3 Water Resistance

The AWEI T35 earbuds are rated IPX5 waterproof, meaning they are resistant to sweat and light splashes of water. They are not designed for submersion in water. Avoid exposing them to heavy rain, showering, or swimming.

# IPX5 Waterproofness No Fear of Rain & Sweat



Image: Two AWEI T35 charging cases, one white with blue lights and one black with yellow lights, are shown with water droplets on them, illustrating their IPX5 waterproof rating and resistance to rain and sweat.

## 7. TROUBLESHOOTING

- **Earbuds not pairing:**
  - Ensure earbuds are charged.
  - Turn off Bluetooth on your device and turn it back on.
  - Forget "AWEI T35" from your device's Bluetooth list and try pairing again.
  - Place earbuds back in the case, close the lid, wait a few seconds, then open to reset.
- **Only one earbud working:**
  - Ensure both earbuds are charged.
  - Place both earbuds back in the charging case, close the lid, then open them again to re-establish the connection between them.
- **No sound:**

- Check the volume level on both your device and the earbuds.
- Ensure the earbuds are properly connected to your device.

• **Charging issues:**

- Verify the charging cable is securely connected to both the case and the power source.
- Clean the charging contacts on the earbuds and inside the case.
- Try a different USB Type-C cable or power adapter.

## 8. SPECIFICATIONS



### Parameters

Name	Bluetooth Version
T35 TWS E-Sport Earbuds	5.0
Drive Unit	Transmission Distance
Ø10mm	10M
Frequency Response Range	Standby Time
20Hz-22KHz	300h
Battery Capacity of Charging Case	Play Time
400mAh/3.7V	4.5h
Charging Voltage	Charging Port
DC 5V	Type-C

Image: A detailed graphic displaying the technical parameters of the AWEI T35 TWS E-Sport Earbuds, including Bluetooth version, drive unit size, transmission distance, frequency response range, standby time, battery capacity, play time, charging voltage, and charging port type.

Feature	Specification
Model	T35
Bluetooth Version	5.0
Audio Latency	45 ms
Drive Unit	10mm Dynamic Driver
Frequency Response Range	20Hz - 22KHz
Transmission Distance	Up to 10 meters (33 feet)
Earbud Battery Life	Approx. 7 hours (Play Time)
Charging Case Battery Capacity	400mAh / 3.7V

Charging Case Standby Time	Approx. 300 hours
Charging Port	USB Type-C
Water Resistance Rating	IPX5
Control Type	Touch Control
Product Dimensions	1.57 x 1.18 x 0.79 inches (approximate)
Item Weight	5.3 ounces

## 9. WARRANTY AND SUPPORT

---

AWEI products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the warranty card included in your package or contact AWEI customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.

© 2023 AWEI. All rights reserved.