Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Baby Born 834589

BABY born My First Mermaid Doll Instruction Manual

Model: 834589

Important Safety Information

Please read all instructions carefully before using the BABY born My First Mermaid doll. Retain this manual for future reference.

- **Age Recommendation:** This product is suitable for children aged 3 years and up.
- **Adult Supervision:** Always ensure adult supervision during water play to prevent accidents.
- **Water Type:** The doll is designed for use in fresh water (e.g., bathtub, pool). Avoid salt water or chlorinated water, as these may damage the doll's mechanisms or appearance over time.
- **Cleaning:** Refer to the 'Maintenance' section for proper cleaning instructions.
- **Small Parts:** This product does not contain small parts that pose a choking hazard for the recommended age group.

Package Contents

The BABY born My First Mermaid doll package includes the following items:

- 1 x BABY born My First Mermaid Doll (Model 834589)



Image: The BABY born My First Mermaid doll shown both inside its retail packaging and standing freely, illustrating the product as received.

Setup

Preparing the Doll for Water Play

1. **Unpack the Doll:** Carefully remove the doll from its packaging. Ensure all ties and plastic fasteners are removed.
2. **Inspect the Doll:** Before first use, check the doll for any visible damage or defects.
3. **No Batteries Required:** This doll operates mechanically in water and does not require batteries.



Image: The mermaid doll standing in an empty bathtub, ready for water play. The doll features a pink mermaid tail and a light-colored top.

Operating Instructions

Making the Mermaid Swim

The BABY born My First Mermaid doll is designed to swim independently when placed in water.

1. **Fill the Bathtub/Pool:** Ensure the water level is sufficient for the doll to float and move freely.
2. **Place Doll in Water:** Gently place the mermaid doll into the water. The doll's arms will automatically move, propelling it through the water.
3. **Observe Swimming Motion:** The doll's tail and arms are designed to create a realistic swimming motion.
4. **Retrieve Doll:** When play is complete, carefully remove the doll from the water.



Image: The mermaid doll floating on its back in a bathtub, demonstrating its ability to swim. The water is clear, and the doll's pink tail is visible.



Image: A young child interacting with the mermaid doll during bath time, showing the doll in active play.

Maintenance

Cleaning and Storage

- **Rinse After Use:** After each water play session, rinse the doll thoroughly with clean, fresh water to remove any soap residue or impurities.
- **Dry Thoroughly:** Gently shake off excess water. Allow the doll to air dry completely in a well-ventilated area before storing. Do not expose to direct sunlight or high heat.
- **Storage:** Store the doll in a clean, dry place away from direct sunlight and extreme temperatures.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals on the doll, as these can damage the material and paint.



Image: A detailed view of the mermaid doll's tail, showing its design and how it interacts with water. Proper drying is essential for longevity.

Troubleshooting

If you encounter any issues with your BABY born My First Mermaid doll, please refer to the following table:

Problem	Possible Cause	Solution
Doll does not swim	Insufficient water depth or obstruction.	Ensure the doll is fully submerged and has enough space to move its arms freely.
Doll's movement is sluggish	Residue build-up in joints.	Rinse the doll thoroughly with clean water and ensure all joints are free of debris.
Discoloration or damage to doll's surface	Exposure to harsh chemicals, salt water, or prolonged direct sunlight.	Avoid using harsh cleaning agents. Only use the doll in fresh water. Store away from direct sunlight.

Specifications

Feature	Detail
Model Number	834589
Product Dimensions	3.94 x 7.09 x 15.16 inches

Feature	Detail
Item Weight	1.25 pounds
Manufacturer Recommended Age	3 years and up
Power Source	Mechanical (no batteries required)

Warranty and Support

Information regarding product warranty and customer support contact details is not included within this instruction manual. Please refer to the product packaging or the manufacturer's official website for warranty claims and support inquiries.

For additional information, you may visit theBaby Born Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question