

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Weiser](#) /

› [Weiser Prague Matte Black Passage Door Knob Instruction Manual \(Model 9GA1010-154\)](#)

Weiser 9GA1010-154

Weiser Prague Matte Black Passage Door Knob Instruction Manual

Model: 9GA1010-154

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Weiser Prague Matte Black Passage Door Knob. This non-locking knob is designed for interior doors such as those for hallways and closets, where no locking mechanism is required. The sleek matte black finish and contemporary design enhance any home interior.

WHAT'S IN THE BOX

- 1 Set of Door Knobs (Interior and Exterior)
- 1 Latch
- 1 Strike Plate
- Mounting Screws
- Installation Manual

TOOLS REQUIRED

- Phillips Head Screwdriver (#2 recommended)

INSTALLATION INSTRUCTIONS

Follow these steps for proper installation of your Weiser Prague Passage Door Knob. For visual guidance, refer to the product overview video below.

Video: Product Overview - Demonstrates components and assembly process.

1. Prepare Door and Check Dimensions:

Ensure your door meets the following specifications: door thickness 1-3/8" to 1-3/4" (35mm-44mm); Latch Backset 2-3/8" (60mm) or 2-3/4" (70mm); Cross Bore 2-1/8" (54mm). If drilling a new door, use the supplied template and complete door drilling instructions.



Image: Weiser Prague Matte Black Passage Door Knob, front view.

2. Adjust the Backset of the Latch (if needed):

Hold the latch in front of the door hole with the latch face flush against the door edge. If the latch holes are centered in the door hole, no adjustment is required. If not centered, adjust the latch by moving the pin to extend the latch.



Image: All components of the door knob laid out, including the latch, knobs, and screws.

3. Install Latch:

Insert the latch into the door edge. Secure it with the provided screws. Ensure the slant bolt faces the door frame when the door is closed.

4. Install Knobs:

Press the latch bolt to install the exterior knob. Remove the interior knob. Loosen the pre-installed set screw on the interior knob base. Place the knob base on the center point and secure with screws.

Push up on the knob base while tightening screws to keep the latch horizontal and centered. Install the interior knob and tighten the set screw.



Image: The matte black door knob installed on a white door, with a clear view of the latch mechanism on the door edge.

5. Install Strike Plate on Door Frame:

Install the strike plate on the door frame using the provided screws. Close the door and test the latch operation. If the latch is loose in the strike, adjust the strike tab so it grips the latch bolt better when the door is closed.



Image: An exploded diagram showing the individual components of the door knob and their assembly order.

OPERATING INSTRUCTIONS

The Weiser Prague Passage Door Knob is a non-locking mechanism. To open the door, simply turn the knob in either direction. The latch will retract, allowing the door to open. To close, push the door shut, and the latch will automatically engage with the strike plate, holding the door in place.

MAINTENANCE

To maintain the finish and functionality of your door knob, follow these guidelines:

- Clean regularly with a soft, damp cloth. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- Do not use furniture polish or other household cleaners on the door knob.
- Periodically check and tighten any loose mounting screws to ensure secure operation.

TROUBLESHOOTING

If you encounter any issues with your door knob, consider the following common solutions:

- **Knob is Loose:** Check if the mounting screws are securely tightened. If the interior knob is loose, ensure the set screw (if applicable for your specific variant) is tightened.
- **Latch Not Engaging Properly:** Verify that the strike plate on the door frame is aligned correctly with the latch bolt. The strike tab can be adjusted to provide a better grip if the latch is loose.
- **Stiff Operation:** Ensure all components are installed without excessive force or misalignment. A small amount of silicone-based lubricant can be applied to the latch mechanism if needed, but avoid over-lubricating.

SPECIFICATIONS

Feature	Detail
Manufacturer	Weiser
Part Number	9GA1010-154
Product Dimensions	6.67 x 6.19 x 6.19 cm
Item Weight	744 g
Size	Knob
Colour	Matte Black
Style	Passage (Non-locking)
Finish	Powder Coated
Material	Metal
Shape	Round
Door Thickness Compatibility	1-3/8" - 1-3/4"
Latch Backset	2-3/8" - 2-3/4"
Cross Bore	2-1/8"
Special Features	Easy to Install

WARRANTY


This Weiser Prague Passage Door Knob comes with a **Limited Lifetime Mechanical and Finish Warranty**. For specific terms and conditions, please refer to the warranty information provided with your product packaging or contact Weiser customer support.

SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please visit the official Weiser website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.


Related Documents - 9GA1010-154

<small>User Manual of Product 1: Weiser Powerbolt 2 Matte Black Keyless Entry Door Lock/Deadbolt Lock, Single Cylinder Keyless Door Lock with Double Keypad (Up to 8 User Codes), Auto-Lock, Electronic Dead-Lock, and Power Failure Protection.</small> <small>User Manual of Product 2: Weiser Matte Black Door Handles, Removable Passage Lever, Invisible Door Handles for Hall and Closet Doors, Non-locking, Hardwood Door Handles, Modern Home Door</small>	<p>Weiser Powerbolt 2 Keyless Entry Door Lock Installation and User Guide</p> <p>Comprehensive guide for installing and using the Weiser Powerbolt 2 Matte Black Keyless Entry Door Lock/Deadbolt Lock. Includes instructions for setup, programming user codes, changing master codes, and troubleshooting.</p>
---	--



[Weiser Catalogue Complet de Quincaillerie de Porte et Serrures](#)

Explorez le catalogue Weiser pour une vaste sélection de quincaillerie de porte, serrures électroniques et mécaniques, incluant les technologies SmartKey et Microban. Trouvez spécifications, finitions et prix.



[Weiser Knob Installation Guide and SmartKey Rekeying Instructions](#)

Weiser door knob installation guide with SmartKey rekeying instructions. Learn how to install, adjust, and rekey your Weiser lock hardware with detailed steps and textual descriptions of diagrams.



[Weiser Product Catalog and Ordering Guide](#)

Explore the comprehensive Weiser product catalog, featuring a wide range of locks, handlesets, levers, and knobs. This guide provides detailed information on product specifications, ordering procedures, finishes, and keying options for both residential and commercial applications. Discover Weiser's commitment to security, style, and innovation.



[Weiser Halo & Aura Smart Lock Troubleshooting Guide](#)

Comprehensive troubleshooting guide for Weiser Halo and Aura smart locks, covering installation, app usage, connectivity issues, and common problems. Find solutions for door preparation, Bluetooth, Wi-Fi, and smart home integration.



[Weiser 2022 Price Book: Comprehensive Catalog of Locks and Hardware](#)

Explore the Weiser 2022 Price Book, featuring a wide range of door hardware including electronic locks, deadbolts, handlesets, levers, and knobs. Discover SmartKey security, Microban antimicrobial protection, and detailed product specifications.

