

[Manuals.plus](#) /

› [HEQET](#) /

› HEQET Cordless LED Table Lamp AU-HELAMP-009-FBA User Manual

HEQET AU-HELAMP-009-FBA

HEQET Cordless LED Table Lamp

Model: AU-HELAMP-009-FBA

INTRODUCTION

Thank you for choosing the HEQET Cordless LED Table Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read these instructions thoroughly before operation and retain them for future reference.



Image: The HEQET Cordless LED Table Lamp, featuring a gold base and a clear, fluted acrylic shade, emitting a warm light.

PRODUCT FEATURES

- **Cordless and Portable:** Designed for flexible placement indoors and outdoors.
- **Adjustable Lighting:** Offers 3 color temperatures (cold white, natural white, warm white) and a dimmable function.
- **Rechargeable Battery:** Built-in battery provides up to 8 hours of illumination on a full charge.
- **Durable Construction:** Features a brass base and a sturdy acrylic shade.
- **Protective Base:** Equipped with black rubber stoppers to prevent scratching surfaces.

SETUP

1. **Unpacking:** Carefully remove the lamp and all components from the packaging. Verify that all parts are present: lamp unit, USB charging cable.
2. **Initial Charge:** The lamp comes partially charged. For optimal performance, fully charge the lamp before first use. Connect the provided USB charging cable to the lamp's charging port (located on the base) and to a compatible USB power adapter (not included). A full charge typically takes approximately

3 hours.




Image: Detail of the lamp's brass base, highlighting the USB charging port and the touch control button.

3. **Placement:** Place the lamp on a stable, flat surface. The base is equipped with rubber stoppers to prevent sliding and protect furniture.



Black Rubber Stoppers at the Base That Prevent Scratching Furniture and Table Tops

Image: The black rubber stoppers on the underside of the lamp's base, designed to prevent scratches and provide stability.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Lightly tap the touch control button located on the lamp's base to turn the lamp on or off.
2. **Change Color Temperature:** With the lamp on, tap the touch control button repeatedly to cycle through the three available color temperatures: Cold White, Natural White, and Warm White.



Image: The lamp demonstrating its three distinct light color temperatures: Cold White, Natural White, and Warm White.

- 3. Adjust Brightness (Dimmer Function):** To adjust the brightness, press and hold the touch control button. The brightness will gradually change from 100% down to 10%. Release the button when the desired brightness level is reached. Repeat the process to adjust brightness in the opposite direction.

Dimmable



Image: Two lamps side-by-side, illustrating the dimmable function from bright to dim.

MAINTENANCE

- **Cleaning:** To clean the lamp, ensure it is turned off and disconnected from any charging source. Wipe the brass base and acrylic shade with a soft, dry, or slightly damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or material.
- **Battery Care:** For optimal battery longevity, avoid completely draining the battery frequently. Recharge the lamp when the light output noticeably diminishes. If storing the lamp for an extended period, charge it to approximately 50% every few months.
- **Storage:** Store the lamp in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted.	Charge the lamp for at least 3 hours using the provided USB cable.

Problem	Possible Cause	Solution
Lamp does not charge.	Charging cable or adapter is faulty; charging port is damaged.	Ensure the USB cable is securely connected. Try a different USB power adapter. If the charging port appears damaged, contact customer support.
Short battery life.	Incomplete charge; high brightness setting; aging battery.	Ensure the lamp is fully charged. Lower the brightness setting for longer illumination. Battery performance may decrease over time.
Light flickers or is inconsistent.	Low battery; internal component issue.	Recharge the lamp. If the issue persists after charging, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Name	Cordless lamp (AU-HELAMP-009-FBA)
Brand	HEQET
Dimensions (D x W x H)	<p>5.7" x 5.7" x 12" (14.5cm x 14.5cm x 30.5cm)</p>  <p>5.5" 14cm</p> <p>5" Diameter 12.5cm</p> <p>12" Tall 30.5cm</p> <p>Image: Visual representation of the lamp's height and diameter measurements.</p>
Item Weight	1.01 Pounds (approx. 0.46 kg)

Feature	Detail
Material	<p data-bbox="564 159 903 188">Brass (Base), Acrylic (Shade)</p> <div data-bbox="564 210 1394 1048">  <p data-bbox="1161 210 1394 488">Acrylic Lamp Shade (Not Glass)</p> </div> <p data-bbox="587 1072 1374 1133">Image: Close-up of the lamp's fluted shade, confirming it is made of acrylic, not glass.</p>
Light Source Type	LED
Wattage	3 watts
Voltage	220 Volts
Power Source	Built-in rechargeable battery
Control Method	Touch
Special Features	Color Changing, Dimmable, Waterproof
Indoor/Outdoor Usage	Indoor and Outdoor use

WARRANTY AND SUPPORT

Specific warranty details for this product are not provided in the available information. For warranty claims, technical support, or any inquiries regarding your HEQET Cordless LED Table Lamp, please contact the retailer or manufacturer directly through their official channels.

Manufacturer: HEQET

SAFETY INFORMATION

- Do not expose the lamp to extreme temperatures or direct sunlight for prolonged periods.
 - Keep out of reach of children and pets.
 - Do not attempt to disassemble or modify the lamp. This may void any potential warranty and poses a safety risk.
 - Use only the provided USB charging cable or a certified equivalent.
 - Despite being waterproof, avoid submerging the lamp in water.
-

© 2025 HEQET. All rights reserved.