



Universal Replacement Remote Control

User Manual

Universal Replacement Remote Control for Daikin AC Units

Model: Universal Replacement Remote Control

Brand: Generic

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your new universal replacement remote control. This remote is designed to be compatible with various Daikin AC Room Air Conditioner models, including but not limited to: FTXF25D5V1B, FTXF35D5V1B, FTXF42D5V1B, ATXF20D5V1B, ATXF25D5V1B, RKS18SL216, RKS24SL216, RXS09SL116, RXS09SL216, and RXS12SL116.

Please note that while this remote is a functional replacement, some advanced or specific functions of your original remote may not be fully supported. Refer to the original Daikin AC unit manual for comprehensive details on your air conditioner's features.

SETUP

1. Battery Installation

The remote control requires two (2) AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) ends align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Battery compartment with cover removed, showing slots for two AAA batteries.



Figure 2: Rear view of the remote control with the battery cover securely closed.

2. Initial Use

This remote control operates via infrared (IR) technology and typically does not require pairing. Once batteries are installed, point the remote directly at your Daikin AC unit's IR receiver and press the **ON/OFF** button to test functionality.

OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions as shown below:



Figure 3: Front view of the universal replacement remote control.

Button	Function
ON/OFF	Powers the AC unit on or off.
TEMP ▲ / ▼	Adjusts the temperature setting up or down. The display shows temperature in Celsius.
MODE	Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
FAN	Adjusts fan speed settings.
SWING	Activates or adjusts the louver swing function for air distribution.
TURBO	Engages maximum cooling/heating power for rapid temperature change.
SAVE	Activates energy-saving mode.
GOOD SLEEP	Initiates a specialized sleep mode, often adjusting temperature gradually.
TIMER ON / OFF / CANCEL	Sets a timer for the AC unit to turn on or off automatically. Use CANCEL to disable.

General Operation Tips:

- Ensure a clear line of sight between the remote control and the AC unit's infrared receiver.
- Avoid placing obstacles between the remote and the unit.
- The effective range of the remote control is typically up to 8 meters (26 feet).

MAINTENANCE

Battery Replacement

Replace batteries when the remote's display becomes dim or the remote becomes unresponsive. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding or AC unit not reacting.	<ul style="list-style-type: none">• Dead or low batteries.• Incorrect battery installation.• Obstruction between remote and AC unit.• Remote out of range.• AC unit's IR receiver is blocked or faulty.	<ul style="list-style-type: none">• Replace batteries with new ones.• Check battery polarity (+/-).• Remove any objects blocking the signal path.• Move closer to the AC unit (within 8 meters).• Ensure the AC unit's display/receiver is clean and unobstructed.
Some functions do not work.	<ul style="list-style-type: none">• The replacement remote may not support all original functions.• Specific AC unit model incompatibility for certain features.	<ul style="list-style-type: none">• This is expected for some universal replacement remotes.• Refer to your original AC unit manual for specific feature operation.

SPECIFICATIONS

- **Power Source:** 2 x AAA Batteries (not included)
- **Connectivity:** Infrared (IR)
- **Controller Type:** Button Control
- **Special Features:** Temperature display in Celsius, Direct replacement functionality
- **Compatible Models:** Daikin FTXF25D5V1B, FTXF35D5V1B, FTXF42D5V1B, ATXF20D5V1B, ATXF25D5V1B, RKS18SL216, RKS24SL216, RXS09SL116, RXS09SL216, RXS12SL116, and similar Daikin AC Room Air Conditioner models.

WARRANTY AND SUPPORT

This product is a replacement remote control. Specific warranty terms and support options are typically provided by the seller or manufacturer at the time of purchase. For any issues or inquiries regarding your remote control, please contact the seller directly through your purchase platform.

Manufacturer: Easytry

For further assistance, please refer to the product listing or your purchase documentation.