

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lifewit](#) /

› [Lifewit 24L Black Lunch Bag, Bundle with 15L Grey Cooler Bag User Manual](#)

Lifewit 24L Black Lunch Bag and 15L Grey Cooler Bag Bundle

Lifewit Insulated Lunch Bag & Cooler Bag User Manual

Model: 24L Black Lunch Bag & 15L Grey Cooler Bag Bundle

1. INTRODUCTION

Thank you for choosing the Lifewit Insulated Lunch Bag and Cooler Bag Bundle. This product is designed to keep your food and beverages at desired temperatures for extended periods, making it ideal for office, school, picnics, and travel. This manual provides essential information for the proper use and care of your new bags.



Image 1.1: Lifewit Insulated Lunch Bag banner, highlighting its purpose for enjoyable meal times.

2. SAFETY INFORMATION

- Do not place extremely sharp objects inside the bags that could puncture the lining.
- Keep away from open flames or excessive heat sources.
- Ensure zippers are fully closed to maintain insulation and prevent leaks.
- Do not use abrasive cleaners or harsh chemicals on the bags.
- Always transport the bags with handles or shoulder straps securely fastened.

3. PRODUCT OVERVIEW

The Lifewit bundle includes a 24L black lunch bag and a 15L grey cooler bag, both designed with insulation properties. Each bag features a main compartment, front pocket, and side mesh pockets for additional storage.



Image 3.1: The Lifewit 24L Black Lunch Bag and 15L Grey Cooler Bag, showcasing both items in the bundle.



Image 3.2: Close-up view of the durable Lifewit branded zippers.



Image 3.3: Detail of the comfortable and sturdy handle of the Lifewit bag.

4. SETUP

Your Lifewit lunch and cooler bags come ready for immediate use. No assembly is required.

- 1. Unpack:** Remove the bags from their packaging.
- 2. Initial Cleaning:** Wipe the interior and exterior with a damp cloth before first use. Allow to air dry completely.
- 3. Prepare for Use:** The bags are designed to stand upright. You can adjust the shoulder strap for comfortable carrying.

5. OPERATING INSTRUCTIONS

These bags are designed for efficient temperature retention. Follow these guidelines for best results:

- **Loading Contents:** Utilize the wide-open design to easily place food containers, drinks, and fruits horizontally.
- **For Cold Items:** For optimal cooling, place ice packs or ice directly into the PEVA-lined interior. The seamless hot pressing technology ensures a leakproof experience.
- **For Warm Items:** Place warm food containers directly into the bag. The insulated material helps maintain warmth.
- **Sealing:** Ensure the high-quality zipper is fully closed to maximize insulation and prevent temperature loss.



Image 5.1: The cooler bag filled with ice and beverages, illustrating its leakproof construction.



Image 5.2: Visual representation of the bag's insulation performance over 12 hours, showing ice retention.



Image 5.3: Diagram illustrating the dual function of the bag to keep contents either warm or fresh.



Image 5.4: The grey cooler bag demonstrating its large capacity with multiple food containers and drinks.

6. MAINTENANCE AND CARE

Proper care will extend the life of your Lifewit bags.

- **Cleaning:** Hand wash only. Wipe the interior lining with a damp cloth and mild soap if necessary. For the exterior, use a damp cloth to wipe away dirt.
- **Drying:** Air dry completely after cleaning to prevent mold or mildew. Do not machine wash or tumble dry.
- **Storage:** Store in a cool, dry place when not in use.
- **Stain Removal:** For stubborn stains on the interior, a gentle scrub with a soft brush and mild detergent can be used, followed by thorough wiping.



Image 6.1: Water droplets on the bag's exterior, demonstrating its water-resistant properties.



Image 6.2: A hand wiping a spill from the interior lining, showing ease of cleaning.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Poor insulation performance	Zipper not fully closed; insufficient ice/heat packs; bag overfilled.	Ensure zipper is completely closed. Use adequate ice packs for cold items or pre-warm containers for hot items. Do not overfill the bag.
Leakage from bag	Zipper not fully closed; damage to lining; excessive liquid.	Verify zipper is sealed. Inspect lining for tears; if damaged, contact support. Avoid placing excessive loose liquids without proper containers.
Unpleasant odor inside	Food residue; insufficient drying after cleaning.	Clean the interior thoroughly with mild soap and water. Ensure the bag is completely dry before storing. You can place an open box of baking soda inside overnight to absorb odors.

8. SPECIFICATIONS

Detailed specifications for the Lifewit 24L Black Lunch Bag and 15L Grey Cooler Bag bundle:



Image 8.1: Dimensions of the 24L black lunch bag (13.7" L x 11" W x 11" H).



Image 8.2: Visual representation of the 24L capacity, equivalent to 40 x 330ml cans, with dimensions.

Feature	Description
Brand	Lifewit
Model	24L Black Lunch Bag & 15L Grey Cooler Bag Bundle
Capacity (Lunch Bag)	24 Liters (approx. 13.8"L x 11"W x 11"H)
Capacity (Cooler Bag)	15 Liters (approx. 14.9"L x 8.6"W x 11"H)
Material	600D Water-resistant Dirt-proof Oxford Fabric (Exterior), Food-grade PEVA Foil (Interior Lining), 6mm EPE Foam (Insulation)
Insulation Performance	Maintains temperature for more than 5 hours
Closure Type	Zipper
Special Features	Insulated, Leakproof (seamless hot pressing technology), Wide-Open Design, Durable Handles & Zippers
Care Instructions	Hand Wash Only
Number of Items	2 (one 24L lunch bag, one 15L cooler bag)

9. WARRANTY AND SUPPORT

Lifewit products are manufactured with quality and durability in mind. For any questions, concerns, or support needs regarding your lunch and cooler bags, please refer to the seller's return policy or contact Lifewit customer service through the official channels provided at the point of purchase. Please retain your proof of purchase for any warranty claims.