Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DELTACO ARM-1400

DELTACO ARM-1400 TV Floor Stand User Manual

Model: ARM-1400

1. Introduction

The DELTACO ARM-1400 is a robust floor stand designed for televisions and screens ranging from 49 to 70 inches, supporting a maximum weight of 40 kg. Constructed entirely from steel, this stand ensures enhanced stability and durability. It features integrated cable management to maintain a tidy and organized appearance, along with rubberized feet that protect your floor from potential damage. For added safety, the stand is equipped with an anti-tip safety strap to prevent accidental tipping.




Image 1.1: Overview of DELTACO ARM-1400 features, including screen size compatibility (49"-70"), maximum weight (40 kg), non-slip rubber feet, anti-tip safety strap, VESA compatibility, cable management, and 5-year warranty.

2. Safety Information

- Ensure the stand is placed on a stable, level surface.
- Do not exceed the maximum weight capacity of 40 kg (88 lbs).
- Always use the provided anti-tip safety strap to secure the TV to the wall or furniture, preventing accidental tipping.
- Keep children and pets away from the stand during assembly and ensure all components are securely fastened.
- Periodically check all screws and connections to ensure they remain tight and secure.

3. Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged:

- TV Floor Stand components
- Anti-tip safety kit
- Mounting accessories (screws, washers, spacers)
- Instruction Manual

4. Setup and Assembly

Follow these steps carefully to assemble your DELTACO ARM-1400 TV Floor Stand.

4.1. Assemble the Base

1. Unpack all components and lay them out on a soft, clean surface to prevent scratches.
2. Connect the main vertical support to the three leg sections. Ensure all connections are firm and secure using the provided hardware.






Image 4.1: The DELTACO ARM-1400 TV Floor Stand fully assembled, viewed from the front-left angle, ready for TV mounting.

4.2. Attach VESA Brackets to Your TV

1. Identify the VESA mounting holes on the back of your television.
2. Select the appropriate screws, washers, and spacers from the mounting accessories kit that fit your TV's VESA pattern.
3. Attach the two vertical VESA brackets to the back of your TV. Ensure they are securely fastened and level.






Image 4.2: A direct front view of the DELTACO ARM-1400 TV Floor Stand, highlighting the VESA mounting arms where the television will attach.

4.3. Mount the TV to the Stand

1. With assistance, carefully lift your TV and hook the VESA brackets onto the horizontal bars of the stand's mounting plate.
2. Ensure the TV is centered and level. Secure the TV to the stand using any provided locking mechanisms or screws.



Image 4.3: The DELTACO ARM-1400 TV Floor Stand with a large television, positioned in a modern bedroom setting, demonstrating its aesthetic integration.

4.4. Cable Management

1. Route all TV and power cables neatly along the stand's legs using the integrated cable management clips.
2. Secure the cables to prevent them from dangling or becoming a tripping hazard.





Image 4.4: A close-up view illustrating the cable management clips integrated into the stand's leg, designed to keep cables organized and out of sight.

4.5. Install Anti-Tip Safety Strap

1. Attach one end of the anti-tip safety strap to the back of the TV or the stand, as instructed in the anti-tip kit.
2. Secure the other end of the strap to a wall stud or sturdy furniture using appropriate hardware. This step is crucial for preventing accidental tipping and ensuring safety.

5. Operating Instructions

The DELTACO ARM-1400 TV Floor Stand is designed for straightforward use once assembled.

- **Placement:** Position the stand in your desired location, ensuring it is on a flat, stable surface. The non-slip rubber feet provide stability and floor protection.
- **Viewing Angle:** The stand allows for a rotary movement, enabling you to adjust the TV's viewing angle slightly to suit your preference. Gently rotate the TV and stand as a single unit. Avoid excessive force.
- **Cable Management:** Regularly check and adjust cables within the integrated management system to maintain a neat appearance and prevent strain on connections.

6. Maintenance

To ensure the longevity and safe operation of your TV floor stand, follow these maintenance guidelines:

- **Cleaning:** Wipe the stand with a soft, dry cloth. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by drying thoroughly. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically inspect all connections, screws, and the anti-tip strap for any signs of loosening or wear. Tighten any loose fasteners immediately.
- **Stability Check:** Ensure the stand remains stable and level. If the stand appears wobbly, re-check assembly and placement.

7. Troubleshooting

If you encounter issues with your DELTACO ARM-1400 TV Floor Stand, refer to the following common troubleshooting tips:

- **Stand is Wobbly:**
  - Ensure all assembly screws are tightened securely.
  - Verify the stand is on a flat, level surface.

- Confirm the TV weight does not exceed 40 kg.

- **TV Not Attaching Securely:**
  - Check that the VESA pattern of your TV matches the supported VESA sizes (300x200 to 600x400).
  - Ensure the correct screws and spacers were used for your TV model.

- **Cables are Disorganized:**
  - Utilize the integrated cable management clips along the stand's legs to route and secure cables.

8. Specifications

Feature	Specification
Model	ARM-1400
Brand	DELTACO
Screen Size Compatibility	49" - 70"
Maximum Weight Capacity	40 kg (88 lbs)
VESA Compatibility	300×200, 300×300, 400×200, 400×300, 400×400, 600×400
Material	Alloy Steel
Movement Type	Rotary
Special Features	Cable Management, Non-slip Rubber Feet, Anti-tip Safety Strap




Image 8.1: Detailed technical drawing of the DELTACO ARM-1400 TV Floor Stand, showing key dimensions in millimeters for installation planning.

9. Warranty Information

The DELTACO ARM-1400 TV Floor Stand comes with a**5-year warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by improper installation, misuse, accidents, or unauthorized modifications.

10. Support

For further assistance, technical support, or warranty inquiries, please contact DELTACO customer service. Refer to the

official DELTACO website or your purchase documentation for contact details.

© 2023 DELTACO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BFBMZY6M

More documents and user manuals: **https://manuals.plus/**