

ZunVolt Fruice

ZunVolt Nutri-Fruice Juicer Blender Grinder 400W User Manual

Model: Fruice

1. INTRODUCTION

Thank you for choosing the ZunVolt Nutri-Fruice Juicer Blender Grinder. This appliance is designed for efficient blending, juicing, and grinding tasks in your kitchen. Please read this manual carefully before operating the appliance to ensure safe and optimal performance. Keep this manual for future reference.

Important Safety Instructions

- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils out of the jar while blending to reduce the risk of severe injury to persons or damage to the blender.
- Never operate the appliance with damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Ensure the lid is securely locked before operating the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use attachments not recommended or sold by the manufacturer.
- Avoid contact with moving parts.

2. PRODUCT COMPONENTS

The ZunVolt Nutri-Fruice Juicer Blender Grinder comes with the following components:



Image: The ZunVolt Nutri-Fruice Juicer Blender Grinder, showcasing the motor unit and two transparent jars.

- **Motor Unit:** The main power unit with a 400W motor and speed control knob.
- **2 Jars:** Unbreakable transparent plastic jars for blending and grinding.
- **1 Blade Assembly:** A 6-winged stainless steel blade for efficient processing.
- **Lid:** A twist and seal blade lid for leakproof functioning.
- **Strainer:** A special strainer lid for separating pulp from juice.
- **User Manual:** This instruction guide.

Prep, Serve, Store

*Special Strainer
and Air Tight Lids*



Image: Close-up view of the ZunVolt Nutri-Fruice jars, showing the pouring action and the separate strainer lid.

3. SETUP AND ASSEMBLY

Follow these steps to assemble your ZunVolt Nutri-Fruice Juicer Blender Grinder:

1. **Place the Motor Unit:** Position the motor unit on a stable, flat, and dry surface. Ensure the anti-skid feet are firmly placed.
2. **Attach the Blade:** Securely attach the 6-winged blade assembly to the bottom of the desired jar. Twist until it is tightly sealed.
3. **Add Ingredients:** Place your ingredients into the jar. Do not overfill; ensure ingredients are below the maximum fill line.
4. **Secure the Lid:** Place the twist and seal lid onto the jar and twist it clockwise until it locks securely. If using for juicing, you may use the strainer lid.
5. **Mount the Jar:** Invert the assembled jar onto the motor unit. Align the tabs on the jar with the slots on the motor unit and twist clockwise until it locks into place.
6. **Connect Power:** Plug the power cord into a suitable electrical outlet (230V AC).

4. OPERATING INSTRUCTIONS

General Operation

1. Ensure the appliance is correctly assembled and plugged in.
2. Turn the speed control knob to the desired setting (see 'Speed Settings' below).
3. Process ingredients until the desired consistency is achieved. Do not operate continuously for more than 1 minute to prevent overheating. Allow a 2-minute rest period between cycles.
4. Once finished, turn the speed control knob to the 'OFF' position and unplug the appliance.
5. Wait for the blades to stop completely before removing the jar from the motor unit.



Image: The ZunVolt Nutri-Fruice Juicer Blender Grinder actively blending ingredients in a jar.

Speed Settings

The ZunVolt Nutri-Fruice features three-speed settings for versatile processing:

- **Speed 1 (Low):** Ideal for soft ingredients, light blending, and mixing.

- **Speed 2 (Medium):** Suitable for general blending, making smoothies, and light grinding.
- **Speed 3 (High):** For tougher ingredients, quick processing, and fine grinding.

Safety Features

Your appliance is equipped with the following safety features:

- **Anti-Skid Feet:** Ensures stability during operation, preventing movement on the countertop.
- **Twist Lock Jars:** Jars securely lock onto the motor unit and blade assembly to prevent accidental spills and ensure safe operation.
- **ABS Shockproof Body:** The durable ABS plastic body provides protection and enhances product longevity.

All Round Safety.



Anti
Skid Feet



Twist
Lock Jars



ABS
Shockproof Body



Image: Visual representation of the ZunVolt Nutri-Fruice's safety features, including anti-skid feet, twist-lock jars, and the ABS shockproof body.

5. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your appliance.

Cleaning the Jars and Blades

- Unplug the appliance before cleaning.
- Remove the jar from the motor unit and detach the blade assembly.
- Wash the jars, lids, and blade assembly with warm, soapy water. Use a brush to safely clean around the blades.
- Rinse thoroughly and dry immediately.
- **Note:** The jars and blades are **not** dishwasher safe. Hand wash only.

Cleaning the Motor Unit

- Ensure the motor unit is unplugged.
- Wipe the exterior of the motor unit with a soft, damp cloth.
- Do not use abrasive cleaners or scourers.
- Never immerse the motor unit in water or any other liquid.

6. TROUBLESHOOTING

If you encounter any issues with your ZunVolt Nutri-Fruice, refer to the table below for common problems and solutions.

Problem	Possible Cause / Solution
Appliance does not start.	• Ensure the power cord is securely plugged into a working outlet. • Check if the jar is correctly assembled and locked onto the motor unit. • Verify the speed control knob is turned to a numbered setting (1, 2, or 3), not 'OFF'.
Motor stops during operation.	• The appliance may be overloaded. Reduce the amount of ingredients. • Hard ingredients may be jamming the blades. Unplug, remove jar, and clear obstruction. • The motor may have overheated. Turn off, unplug, and let it cool for at least 15-20 minutes before restarting.
Leakage from the jar.	• Ensure the blade assembly is tightly screwed onto the jar. • Check that the lid is securely twisted and sealed. • Do not overfill the jar beyond the maximum fill line.
Unusual noise or odor.	• Turn off and unplug immediately. • Check for any foreign objects or damage to the blades or motor unit. • If the issue persists, contact customer support.

7. TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	ZunVolt
Model Number	Fruice
Power Source	Electric
Wattage	400 Watts
Voltage	230 Volts (AC)
Number of Speeds	3
Control Type	Speed Knob
Capacity	600 Milliliters (per jar)
Product Dimensions (D x W x H)	17D x 17W x 37H Centimeters
Item Weight	1.95 Kilograms
Material	Food Grade ABS Plastic (Body), Plastic (Container), Stainless Steel (Blade)
Special Feature	Leakproof design
Recommended Uses	Grinding, Blending, Juicing
Country of Origin	India

8. WARRANTY AND CUSTOMER SUPPORT

Warranty Information

The ZunVolt Nutri-Fruice Juicer Blender Grinder comes with a **12 Months Manufacturer Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your purchase receipt for warranty claims. The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

Customer Support

For any queries, assistance, or warranty claims, please contact ZunVolt Customer Care:

Customer Care Number: 08047361947

Operating Hours: 10 am to 7 pm, Monday to Sunday

Manufacturer Address: ZunVolt, 6th Floor, Paras Trinity, Sector 63, Gurgaon, Haryana, 122011

