

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [HCDZ](#) /

> [HCDZ Replacement Remote Control for Innovair Prestige Air Conditioner User Manual](#)

HCDZ Replacement Remote Control (Compatible with Innovair Prestige VWM18H25B, VWM24H25B, VWM10H25F, VWM13H25F, VWM18H25F, VWM

HCDZ Replacement Remote Control for Innovair Prestige Air Conditioner User Manual

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your HCDZ Replacement Remote Control. This remote is designed to be compatible with various Innovair Prestige Inverter Mini Split Air Conditioner models, including VWM18H25B, VWM24H25B, VWM10H25F, VWM13H25F, VWM18H25F, and VWM24H25F. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your remote control.

PRODUCT OVERVIEW

The HCDZ Replacement Remote Control is an infrared (IR) device designed for convenient control of your compatible Innovair Prestige air conditioner. It features an ergonomic design and a clear button layout for ease of use.



Figure 1: Front view of the HCDZ Replacement Remote Control. This image displays the remote's ergonomic shape, the digital display screen at the top, and a grid of clearly labeled buttons for various air conditioner functions such as Mode, Fan, Temp, Swing, Sleep, and Timer.

SETUP

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Batteries are not included with the remote control. Please use fresh AAA batteries for optimal performance.



Figure 2: Back view of the remote control with the battery compartment open. This image clearly shows the two slots for AAA batteries and the battery polarity markings, along with a warning label regarding battery disposal.



Figure 3: Back view of the remote control with the battery cover closed. This image shows the sleek, black back panel of the remote with the battery compartment securely sealed, indicating readiness for use.

No programming is required for this replacement remote control. Once batteries are correctly installed, it is ready for immediate use with compatible Innovair Prestige air conditioners.

OPERATING INSTRUCTIONS

Point the remote control directly at the infrared receiver on your Innovair Prestige air conditioner unit. Ensure there are no obstructions between the remote and the air conditioner. Press the desired function button to operate the unit.

Button Functions

- **Power (●):** Turns the air conditioner unit ON or OFF.
- **MODE:** Cycles through operating modes such as Cool, Heat, Fan, Dry, Auto.
- **FAN:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TURBO:** Activates rapid cooling or heating for a short period.
- **SWING:** Controls the louver swing direction for air distribution.
- **TEMP (▲ / ▼):** Adjusts the desired temperature setting.
- **SLEEP:** Activates the sleep mode for comfortable nighttime operation.
- **IFEEL:** Activates the 'I Feel' function, which senses the temperature at the remote's location.
- **LIGHT:** Turns the display light on the air conditioner unit ON or OFF.
- **CLOCK:** Sets the current time.
- **TIMER ON/OFF:** Sets or cancels the automatic ON/OFF timer for the unit.

Important Note: This remote control displays temperature readings exclusively in Celsius.

MAINTENANCE

Battery Replacement

Replace batteries when the remote's display becomes dim or the remote fails to operate the air conditioner consistently. Always replace both AAA batteries simultaneously with new ones. Do not mix old and new batteries, or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new AAA batteries.
 - Ensure there is a clear line of sight between the remote control and the air conditioner's receiver.
 - Confirm the remote is pointed directly at the air conditioner unit.
- **Limited range:**
 - Replace batteries if they are low.
 - Remove any obstructions between the remote and the air conditioner.
- **Temperature display only in Celsius:**
 - This remote control is designed to display temperature exclusively in Celsius. There is no option to switch to Fahrenheit.

SPECIFICATIONS

- **Brand:** HCDZ

- **Model Compatibility:** Innovair Prestige VWM18H25B, VWM24H25B, VWM10H25F, VWM13H25F, VWM18H25F, VWM24H25F Inverter Mini Split Air Conditioners
- **Connectivity Technology:** Infrared (IR)
- **Controller Type:** Button Control
- **Power Source:** 2 x AAA Batteries (not included)
- **Special Feature:** Ergonomic design
- **Temperature Display:** Celsius only

WARRANTY AND SUPPORT

Information regarding specific warranty terms or direct customer support for this HCDZ Replacement Remote Control was not provided in the product details. For any issues or inquiries, please refer to the seller or your purchase documentation.