

Sharper Image 1015848

Sharper Image® Powerboost® Pro+ Hot & Cold Deep Tissue Massage Gun User Manual

Model: 1015848
Brand: Sharper Image

INTRODUCTION

The Sharper Image® Powerboost® Pro+ Hot & Cold Deep Tissue Massage Gun is designed to provide targeted muscle recovery and pain relief through percussion massage with dual-temperature therapy. This manual provides essential information for safe and effective use of your device.

SAFETY INFORMATION

WARNING:

- Avoid prolonged use on the same area to prevent burns.
- Do not use on broken skin or areas with inflammation.
- Keep away from water.
- Unplug and allow to cool before storing.
- Do not use while sleeping or unconscious.
- Consult a doctor before use if pregnant or have a medical condition.

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

WHAT'S INCLUDED

Your Sharper Image® Powerboost® Pro+ package includes the following components:

- Powerboost™ Pro+ Massage Gun
- 6 Custom Attachments (including Hot & Cold attachment)

- Charging Base
- Power Adapter
- Travel Case



Image: Sharper Image Powerboost Pro+ with its charging base, travel case, and all six attachments laid out.



FULL BODY MASSAGE

THE DEEP TISSUE MASSAGER FROM SHARPER IMAGE REPRESENTS THE FUTURE OF MASSAGE TECHNOLOGY, PROVIDING FOCUSED ATTENTION TO TARGETED MUSCLE GROUPS

#1 MASSAGE BRAND*

SHOULDERS

NECK

ARMS

BACK

THIGHS

CALVES

FEET




Image: A visual representation of all items included in the Powerboost Pro+ package, including the massage gun, charging base, power adapter, six distinct attachments, and the carrying case.

SETUP AND ASSEMBLY

Charging the Device

Before first use, fully charge the Powerboost® Pro+ massage gun. Place the device on the charging base and connect the power adapter. The battery indicator on the device will show charging status. A full charge provides up to 5 hours of continuous use.

Attaching and Removing Massage Heads

To attach a massage head, align the desired attachment with the opening on the device and push it in firmly until it clicks into place. For the Hot & Cold attachment, align the orange arrow with the Sharper Image logo and twist clockwise until locked. To remove, twist counterclockwise (for Hot & Cold) or pull firmly (for other attachments) while holding the device securely.

SHARPER IMAGE®




POWERBOOST™ PRO+

HOT+COLD PERCUSSION MASSAGER



38° F

115° F



ICE+HEAT
THERAPY

Dual-temperature attachment heats
or chills at the touch of a button

**+ QUIET-DRIVE
TECHNOLOGY**
Whisper quiet for
use anywhere

Image: The Powerboost Pro+ massage gun displayed with its array of interchangeable massage heads, including the specialized hot and cold attachment.



HOT+COLD
All Body Areas



ROUND
Large muscle
groups



BAR
Biceps and
shoulders



DUAL
Wide
Coverage



CONE
Trigger points
and knots




COMPRESSION
Sensitive
Points

Image: A detailed diagram illustrating the various massage attachments, such as Round, Bar, Dual, Cone, and Compression, along with their recommended muscle impact levels and suitable body areas.


**ROUND**

Constructed from durable foam but designed for more precision.

GOOD FOR
Forearms,
Biceps, Shins




MUSCLE IMPACT
Low


**PERCUSSION**

The hammer-like impact hits deeper into muscles.

GOOD FOR
Pecs, Quads,
Glutes, Calves



MUSCLE IMPACT
Medium


**DUAL**

Gently rock from side to side to work out knots and tense spots.

GOOD FOR
Traps, Quads,
Calves, Feet




MUSCLE IMPACT
High


**CONE**

This pinpoint head is designed for unsurpassed muscular penetration.

GOOD FOR
Feet, Scap,
Forearms




MUSCLE IMPACT
High



**BAR**

The curved edge provides comfort with surprising strength and precision.

GOOD FOR
Shoulders,
Biceps




MUSCLE IMPACT
High

**HOT+COLD**

Recover post-workout with a hot or cold deep tissue massage.

GOOD FOR
All body
areas



MUSCLE IMPACT
Low




Image: An in-depth guide to the six massage heads: Round (low impact, forearms, biceps, shins), Percussion (medium impact, pecs, quads, glutes, calves), Dual (high impact, traps, quads, calves, feet), Cone (high impact, trigger points, knots), Bar (high impact, shoulders, biceps), and Hot+Cold (low impact, all body areas).

OPERATING INSTRUCTIONS

Powering On/Off and Adjusting Speed

Press and hold the power button located on the handle to turn the device on or off. Once on, short press the power button to cycle through 6 intensity levels. The digital display will show the current speed setting.

Using Dual-Temperature Therapy

With the Hot & Cold attachment installed, power on the device. The "TEMP" indicator will light up in white. Use the dedicated temperature buttons on the display to select between 3 levels of heat (up to 115°F) or 3 levels of chill (down to 38°F). Allow a few moments for the attachment to reach the desired temperature.

SHARPER IMAGE®



UP TO
5
HOURS
ON ONE
CHARGE



INSTANT HEAT
OR COLD



WHISPER QUIET



6 SPEEDS



6 ATTACHMENTS



Image: The Powerboost Pro+ massage gun highlighting its dual-temperature capabilities, showing the digital display with temperature controls and indicators for hot (red) and cold (blue) settings.

Application

Apply the massage gun to the desired muscle group. The device is suitable for use on the thigh, shoulder, back, whole body, and arm. Adjust the speed and temperature settings according to your comfort and recovery needs. The whisper-quiet motor ensures discreet use.

SHARPER IMAGE®



BRUSHLESS MOTOR⁺

Depend on relief when you need it most thanks to a durable brushless motor featuring quiet-drive technology and a surprisingly compact size.

PELTIER⁺ TECHNOLOGY

Enjoy a revitalizing chill or heated comfort at the touch of a button – powered by advanced thermoelectric technology.

ANTI-STALL ELECTRONICS⁺

Experience interruption-free relaxation with smart electronics designed to keep the massage intensity up under the heaviest use.

LITHIUM ION BATTERIES⁺

Plug in and recharge the internal batteries for up to 5 hours of completely wireless massage – ideal for massage on the go.



Image: A man using the Powerboost Pro+ massage gun on his knee, demonstrating its application for muscle recovery.



Image: A human body diagram indicating various areas suitable for massage with the Powerboost Pro+, including neck, shoulders, arms, back, thighs, calves, and feet.

MAINTENANCE

Cleaning

Wipe the device and attachments with a damp cloth after each use. Do not submerge the device in water. Ensure the device is completely dry before storing.

Storage

Store the massage gun and its attachments in the provided travel case in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

Device Not Turning On

- Ensure the device is fully charged.
- Press and hold the power button for a few seconds to activate.

Temperature Feature Not Working

- Verify that the Hot & Cold attachment is correctly installed and locked in place.
- Ensure the device is powered on and the "TEMP" indicator is lit.
- Allow sufficient time (20-30 seconds) for the temperature to adjust.

Reduced Percussion Strength

- Check battery level and recharge if low.
- Ensure the attachment is securely fastened.

SPECIFICATIONS

Product Dimensions	12.25 x 4.19 x 5.91 inches
Item Weight	3 Pounds
Model Number	1015848
Power Source	Battery Powered (1 Lithium Ion battery included)
Battery Life	Up to 5 hours
Temperature Range	38°F (cooling) to 115°F (heating)
Intensity Levels	6 Speeds
Material	Plastic, Metal
Manufacturer	MerchSource
Country of Origin	China

OFFICIAL PRODUCT VIDEOS

Watch these official videos from Sharper Image for more information on your Powerboost® Pro+ massage gun:

Powerboost Hot + Cold 2

Your browser does not support the video tag.

Description: This video demonstrates the features and benefits of the Powerboost Hot + Cold massage gun, including its dual-temperature therapy and various attachments.

Powerboost Hot + Cold 1

Your browser does not support the video tag.

Description: An overview video showcasing the Powerboost Hot + Cold percussion massager, highlighting its ease of use and effectiveness for muscle relief.

Sharper Image Brand Video 2022

Your browser does not support the video tag.

Description: A brand video from Sharper Image, illustrating their commitment to innovative and functional products designed to enhance daily life.

Powerboost Hot and Cold

Your browser does not support the video tag.

Description: This video provides a concise demonstration of the Powerboost Hot and Cold massage gun's key features and benefits for muscle therapy.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the contact details provided in your product packaging or visit the official Sharper Image website. Keep your purchase receipt for warranty claims.

You can also find the official User Manual (PDF)[here](#).

© 2025 Sharper Image. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question