

[Manuals.plus](#) /

› [Ankbit](#) /

› Ankbit E700 Hybrid Active Noise Cancelling Headphones User Manual

Ankbit E700

Ankbit E700 Hybrid Active Noise Cancelling Headphones User Manual

Model: E700

INTRODUCTION

Thank you for choosing the Ankbit E700 Hybrid Active Noise Cancelling Headphones. These headphones are designed to provide a superior audio experience with advanced features such as LDAC technology for Hi-Res Wireless Audio, aptX HD & Low Latency codecs, and up to 60 hours of playtime. This manual will guide you through the setup, operation, and maintenance of your new headphones to ensure optimal performance and longevity.

長い寿命のバッテリー

一日中音楽再生時間を楽しむことができ、
電力不足を心配する必要はありません



バッテリーの使用時間： Bluetooth モードは**68H**
ANC モードは**45H**
BluetoothモードとANC モードを同時使用すると**28H**

Image: The Ankbit E700 headphones in Obsidian Blue, showcasing their sleek over-ear design.

SETUP

What's in the Box

Before you begin, please ensure all components are present:

- 1 x Ankbit E700 Active Noise Cancelling Headphones
- 1 x Carrying Case
- 1 x USB C to 3.5mm Audio Cable
- 1 x USB Charging Cable
- 1 x User Manual

高級快適の耳カバー

貴方に気持ちの良い使用体験を捧げます



伸縮可能



折りたたみ可



回転可能です



Image: The Anker E700 headphones, carrying case, USB charging cable, and audio cable laid out, representing the package contents.

Initial Charging

It is recommended to fully charge your headphones before first use. Connect the USB Charging Cable to the USB-C port on the headphones and to a standard USB power adapter (not included). The LED indicator will show charging status and turn off when fully charged. Avoid using high-voltage chargers (e.g., 65W laptop chargers) and opt for a regular phone charger to prevent potential damage.

Power On/Off

To power on, press and hold the Power button until the LED indicator lights up. To power off, press and hold the Power button until the LED indicator turns off.

Bluetooth Pairing

1. Ensure the headphones are powered off.

2. Press and hold the Power button for approximately 5 seconds until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "E700" from the list of devices.
5. Once connected, the LED indicator will flash blue slowly.

The headphones support dual connection, allowing you to connect to two devices simultaneously.



Image: An illustration depicting the dual connection capability of the Ankbit E700 headphones.

NFC Pairing (Near Field Communication)

If your device supports NFC, you can pair the headphones by simply tapping your NFC-enabled device against the NFC area on the left earcup of the headphones. Ensure NFC is enabled on your device.



Image: A visual representation of using NFC to pair the Ankbit E700 headphones with a smartphone.

Comfort and Fit

The Ankbit E700 headphones feature a retractable headband and rotatable earcups for a comfortable and customizable fit. Adjust the headband to fit your head size and rotate the earcups for optimal positioning over your ears. The headphones are also foldable for easy storage and portability.





Image: The Ankbit E700 headphones shown in their folded position, highlighting their portable design.

OPERATING INSTRUCTIONS

Controls Overview

The main controls are located on the earcups. Familiarize yourself with the buttons for power, volume, track control, and Active Noise Cancellation (ANC).

40mmのダイヤフラムドライバ

高解像度のオーディオサウンドを提供し、
ハイパフォーマンスで低音を生成する



Image: A close-up view of the right earcup of the Anker E700 headphones, showing the power, volume, and ANC buttons.

Music Playback

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.
- **Volume Up:** Short press the Volume Up (+) button.
- **Volume Down:** Short press the Volume Down (-) button.

Call Management

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Activate Voice Assistant:** Double-press the Multi-function button.

Image: An illustration highlighting the built-in microphone for clear call quality on the Ankbit E700 headphones.

Active Noise Cancellation (ANC)

The Ankbit E700 features Hybrid Active Noise Cancellation to reduce ambient noise. Press the dedicated ANC button to toggle ANC on or off. The LED indicator will confirm the ANC status.



Image: A graphic illustrating the noise reduction capabilities of the Ankbit E700's Active Noise Cancellation.

LDAC and aptX HD Audio

The E700 headphones support LDAC and aptX HD codecs for high-resolution wireless audio. Ensure your source device also supports these codecs for the best audio quality. LDAC transmits up to 3 times more data than standard Bluetooth codecs, providing incredible detail in your music.

Enjoy Incredible Detail

 aptX aptX HD
aptX Low Latency



Image: A visual emphasizing the LDAC technology for high-quality wireless audio on the Ankbit E700.



Image: An icon representing the aptX audio codec support in the Ankbit E700 headphones.

MAINTENANCE

Cleaning

Wipe the headphones with a soft, dry cloth. Do not use harsh chemicals or abrasive materials. Keep the charging port and audio jack free of dust and debris.

Storage

When not in use, store the headphones in the provided carrying case to protect them from dust, scratches, and impacts. Avoid storing them in extreme temperatures or high humidity.

Battery Care

To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, and as mentioned, use a standard phone charger instead of high-wattage adapters.



Image: An icon indicating the long battery life feature of the Ankbit E700 headphones.

TROUBLESHOOTING

- **Headphones not turning on:** Ensure the headphones are charged. If the issue persists, try a different charging cable or power adapter.
- **Cannot pair with device:** Make sure the headphones are in pairing mode (LED flashing blue and red). Ensure Bluetooth is enabled on your device and that the headphones are within range. Try forgetting the device on your phone and re-pairing.
- **Sound quality is poor or intermittent:** Check the distance between the headphones and your device. Ensure there are no obstructions. If using LDAC/aptX HD, verify your device supports these codecs.
- **Active Noise Cancellation not working:** Press the ANC button to ensure it is activated. Ensure the earcups form a good seal around your ears.
- **Microphone issues:** Ensure the headphones are selected as the input device in your call or meeting application settings.
- **Headphones randomly turning off:** This could be related to overcharging with high-wattage chargers. Use a standard phone charger. If the problem continues, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Ankbit
Model Number	E700
Ear Placement	Over Ear
Noise Control	Active Noise Cancellation
Connectivity Technology	Wireless (Bluetooth 5.1)
Audio Codecs	LDAC, aptX HD, aptX, AAC, SBC

Battery Average Life	60 Hours
Audio Driver Type	Planar Magnetic Driver
Headphone Jack	3.5 mm Jack (for wired connection)
Additional Features	Foldable, Microphone Included, NFC
Item Weight	8.8 ounces

WARRANTY

The Ankbit E700 headphones come with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

SUPPORT

For further assistance, technical support, or warranty inquiries, please refer to the contact information provided in the physical user manual included with your product or visit the official Ankbit website.

PRODUCT VIDEO

Watch this official video for an unboxing, overview of features, and connection guidance for your Ankbit E700 headphones.

Your browser does not support the video tag.

Video: An official unboxing and feature overview of the Ankbit E700 Hybrid Active Noise Cancelling LDAC Headphones by AnkbitDirect.

© 2023 Ankbit. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question