



[Manuals.plus](#) /

> [Transwon](#) /

> Transwon Kids Case Cover for 8 inch Sky Devices Elite OctaX/Elite T8Plus/ Sky PAD 8/ Pad 8 Pro Tablet - Black Instruction Manual

## Transwon Elite OctaX/Elite T8Plus/ Sky PAD 8/ Pad 8 Pro Tablet Case

# Transwon Kids Case Cover Instruction Manual

Model: Elite OctaX/Elite T8Plus/ Sky PAD 8/ Pad 8 Pro Tablet Case

Brand: Transwon

## INTRODUCTION

---

Thank you for choosing the Transwon Kids Case Cover. This case is designed to provide robust protection for your 8-inch Sky Devices Elite OctaX, Elite T8Plus, Sky PAD 8, or Pad 8 Pro Tablet. Constructed from durable, impact-resistant silicone rubber, it offers enhanced safeguarding against drops and impacts. Key features include a built-in foldable kickstand for versatile viewing angles and precise cutouts for full access to all tablet functions.

This manual will guide you through the installation, operation, and maintenance of your new tablet case, ensuring optimal use and longevity.

## SETUP AND INSTALLATION

---

Follow these steps to properly install the case on your compatible tablet:

1. Ensure your tablet is clean and free of dust or debris.
2. Carefully align the tablet with the case, starting with one corner.
3. Gently press the tablet into the case, working your way around the edges until the tablet is fully seated within the silicone cover. Ensure all corners are securely fitted.
4. Verify that all ports, buttons, and camera lenses align with the precise cutouts on the case.



Image: The Transwon Kids Case Cover securely installed on a compatible tablet, showcasing its protective design.

# Humanized Design

Special cutouts for dropdown control center.




Image: The case features humanized design with special cutouts for easy access to the tablet's dropdown control center and other functions.

## OPERATING THE KICKSTAND

The built-in foldable kickstand allows for convenient hands-free viewing. To use the kickstand:

1. Locate the foldable kickstand on the back of the case.
2. Gently pull the kickstand outwards until it clicks into place, forming a stable triangular support.
3. Place your tablet on a flat surface to enjoy a comfortable viewing angle for videos, games, or learning.
4. To fold the kickstand back, gently push it until it lies flat against the case.

# HOW TO USE THE KICKSTAND?




Image: Visual guide demonstrating the correct method for deploying the foldable kickstand for stable tablet support.

## MAINTENANCE AND CARE


---

To ensure the longevity and cleanliness of your Transwon Kids Case Cover, follow these maintenance guidelines:

- **Cleaning:** The premium silicone rubber material is washable. If the case gets dirty, it can be rinsed directly with water. Use mild soap if necessary, then air dry completely before re-installing your tablet.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to prevent material degradation.
- **Inspection:** Periodically inspect the case for any signs of wear or damage. While highly durable, extreme impacts can cause damage.

## Screen Protection

Wraparound frame defends the screen from impact.



## Camera Bumper

Raised bezel protects the camera from scratches.



Image: Detail showing the wraparound frame for screen protection (1.5mm raised) and the camera bumper (2.5mm raised bezel) designed to protect against scratches and impact.

## TROUBLESHOOTING

---

If you encounter any issues with your Transwon Kids Case Cover, consider the following:

- **Case does not fit:** Ensure your tablet model is one of the compatible devices: Sky Devices Elite OctaX, Elite T8Plus, Sky PAD 8, or Pad 8 Pro Tablet. This case is not designed for other models. Double-check your tablet's model number.
- **Buttons or ports are obstructed:** Re-seat the tablet firmly into the case, ensuring all edges are properly aligned. The precise cutouts should provide full access.
- **Kickstand is unstable:** Ensure the kickstand is fully extended and locked into its open position. It should form a stable triangular base.

For further assistance, please refer to the contact information provided in the Warranty and Support section.

## SPECIFICATIONS

---

Feature	Detail
Material	Premium Silicone Rubber
Color	Black
Compatible Devices	SKY Devices Elite OctaX, Elite T8Plus, Sky PAD 8, Pad 8 Pro Tablet (8 inch)
Form Factor	Case
Special Features	Built-in Foldable Kickstand, Raised Corners, Wraparound Frame (1.5mm), Camera Bumper (2.5mm), Precise Cutouts, Washable
Item Weight	9.1 ounces
Package Dimensions	8.86 x 7.8 x 0.91 inches

## WARRANTY AND SUPPORT

---

For any questions, concerns, or support regarding your Transwon Kids Case Cover, please contact the seller directly through the platform where you made your purchase. You can typically find a 'Contact Seller' or 'Ask a question' option on the product page or in your order history.

Please retain your proof of purchase for any warranty claims or support inquiries.