Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ODK B01XS011030JP-1

ODK L-Shaped Gaming/Computer Desk User Manual

Model: B01XS011030JP-1

1. Introduction

Thank you for choosing the ODK L-Shaped Gaming/Computer Desk. This versatile desk is designed to optimize your workspace, providing ample surface area for gaming, work, or study. Its L-shaped design fits perfectly into corners, maximizing room utility, while the integrated shelves offer convenient storage solutions. This manual will guide you through the assembly process, operational features, maintenance, and troubleshooting to ensure a long-lasting and satisfying experience with your new desk.

2. Safety Information

- **Weight Capacity:** Do not exceed the maximum load capacities: 60kg (132 lbs) for the main desktop, 10kg (22 lbs) for the monitor stand, and 25kg (55 lbs) per shelf. Overloading can cause damage or injury.
- **Stable Surface:** Always place the desk on a flat, stable, and level surface to prevent tipping. Use the adjustable feet to compensate for uneven floors.
- **Proper Assembly:** Follow all assembly instructions carefully. Ensure all screws and fasteners are securely tightened before use. Loose connections can lead to instability.
- **Child Safety:** Keep small parts and packaging materials away from children to prevent choking hazards.
- **Edge Design:** The desk features rounded (fillet) corners for safety. However, exercise caution to avoid impacts.

3. Package Contents

Please verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Desktop Panels (L-shaped main panel, monitor stand panel)
- Shelf Panels (2-3 depending on model)
- Steel Frame Components (legs, crossbars, support beams)
- Assembly Hardware (screws, bolts, nuts, washers)
- Assembly Tools (Allen wrench, screwdriver - usually included)
- Adjustable Foot Pads

- Headphone Hook
- Instruction Manual

4. Setup & Assembly

Assembly is designed to be straightforward. It is recommended to have a second person assist with larger components. Lay out all parts on a soft, clean surface to prevent scratches.

4.1. General Assembly Overview



Figure 4.1: Dimensions and Load Capacity. Note the overall dimensions (130x80x74cm) and the maximum weight limits for each section of the desk.



Figure 4.2: Ergonomic Fillet Design. The rounded corners enhance safety and provide a softer aesthetic.

4.2. Step-by-Step Assembly (General Guidance)

1. **Unpack and Identify:** Carefully unpack all components and compare them with the package contents list. Identify each part by its label or shape.
2. **Assemble the Main Frame:** Begin by connecting the main steel frame components according to the diagrams in your specific instruction manual. Ensure all screws are finger-tightened initially.
3. **Attach Desktop Panels:** Secure the L-shaped desktop panels to the assembled frame. Once aligned, fully tighten all screws using the provided tools.
4. **Install Shelf Unit:** Assemble the integrated shelf unit. Note that for this model (right shelf), the shelf can only be installed on the right side. Refer to the manual for specific shelf height adjustments.
5. **Attach Monitor Stand:** Secure the monitor stand to the designated area on the desktop.
6. **Install Accessories:** Attach the headphone hook to the desired location on the desk frame.

7. **Level the Desk:** Adjust the foot pads at the bottom of each leg to ensure the desk is stable and level on your floor.



Figure 4.3: Headphone Hook. A convenient hook for storing your headphones.



Figure 4.4: Adjustable Feet. Use these to stabilize the desk on uneven surfaces.

5. Operating Instructions

5.1. Utilizing the L-Shaped Design

The L-shaped design allows for efficient use of corner spaces, providing a large work surface without occupying excessive room. It's ideal for multi-monitor setups, separating work and gaming zones, or simply providing ample space for all your essentials.



Figure 5.1: Optimized for Dual Monitors. The spacious L-shaped top accommodates multiple screens and peripherals.



Figure 5.2: Gaming Setup Example. The desk provides dedicated space for gaming equipment and a PC tower on the shelf.

5.2. Adjusting the Shelf Height

The integrated shelf unit offers adjustable height options to suit your storage needs. To adjust, carefully remove the shelf, reposition the support pins to the desired height, and reinsert the shelf. Ensure it is securely seated before placing items on it.



Figure 5.3: Adjustable Shelf. Customize the shelf height to fit your PC tower, books, or other items.

5.3. Monitor Stand Usage

The elevated monitor stand helps raise your screen to an ergonomic viewing height, reducing neck and eye strain. Utilize the space underneath for keyboard storage or small accessories.



Figure 5.4: Monitor Stand. Elevates your screen for better ergonomics.

6. Maintenance

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the melamine finish.
- **Spills:** Immediately wipe up any spills to prevent water damage or staining.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Heat:** Do not place hot items directly on the desk surface. Use coasters or protective pads.
- **Sunlight Exposure:** Prolonged exposure to direct sunlight may cause discoloration over time.

7. Troubleshooting

Issue	Possible Cause	Solution
Desk wobbles or is unstable.	Uneven floor; loose screws; incorrect assembly.	Adjust the foot pads to level the desk. Check and tighten all assembly screws. Review assembly steps.
Parts do not align during assembly.	Incorrect orientation of parts; manufacturing defect.	Double-check part orientation against the manual diagrams. If parts are bent or damaged, contact customer support.
Scratches or damage on surface.	Rough handling; sharp objects; improper cleaning.	Use protective mats for sharp objects. Clean with soft cloths. Minor scratches may be concealed with furniture repair kits.
Shelf cannot be adjusted.	Support pins not fully removed or inserted; obstruction.	Ensure support pins are fully removed before repositioning. Clear any obstructions.

8. Specifications

Feature	Detail
Model Number	B01XS011030JP-1

Feature	Detail
Dimensions (L x W x H)	130 cm x 80 cm x 74 cm (51.2 x 31.5 x 29.1 inches)
Color	White
Material (Top)	Melamine Faced Particle Board
Material (Frame)	Alloy Steel
Finish Type	Powder Coated
Main Desktop Load Capacity	60 kg (132 lbs)
Monitor Stand Load Capacity	10 kg (22 lbs)
Shelf Load Capacity (per shelf)	25 kg (55 lbs)
Special Features	L-shaped design, Integrated storage shelves, Monitor stand, Headphone hook, Adjustable feet, Space-saving, Ergonomic fillet design

9. Warranty & Support

ODK provides a **1-year manufacturer's warranty** for this product, covering defects in materials and workmanship from the date of purchase. This warranty does not cover damage caused by improper assembly, misuse, accidents, or normal wear and tear.

For warranty claims, missing parts, or any other inquiries, please contact ODK customer support through the retailer's platform or the official ODK website. Please have your purchase receipt and model number ready when contacting support.

© 2024 ODK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BFPLNTJC

More documents and user manuals: **https://manuals.plus/**