Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOFII Green Colorful-A (B0BFQWQ1SY)

MOFII Wireless Keyboard and Mouse Combo

Instruction Manual

Introduction
Setup
Operating
Maintenance
Troubleshooting
Specifications
Warranty & Support

1. Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your MOFII Wireless Keyboard and Mouse Combo. This combo utilizes 2.4GHz RF wireless technology for a stable and reliable connection, offering a comfortable and efficient typing and navigation experience.



Image 1.1: The MOFII Wireless Keyboard and Mouse Combo in Green Colorful-A. This image displays the full keyboard with its round, retro-style keycaps and the matching ergonomic mouse, alongside the compact USB receiver.

2. Setup

2.1 Unpacking

Carefully remove all components from the packaging. Ensure you have the following items:

- MOFII Wireless Keyboard
- MOFII Wireless Mouse
- USB Nano Receiver (located in the mouse battery compartment)

2.2 Battery Installation

The keyboard requires 2 AAA batteries, and the mouse requires 1 AA battery. Batteries are not included and must be purchased separately.

1. **For the Keyboard:** Locate the battery compartment on the underside of the keyboard. Open the cover and insert 2 AAA batteries, ensuring correct polarity (+/-). Close the cover securely.
2. **For the Mouse:** Locate the battery compartment on the underside of the mouse. Open the cover and insert 1 AA battery, ensuring correct polarity (+/-). The USB Nano Receiver is stored within this compartment. Remove it before closing the cover.



Image 2.1: This image illustrates the battery compartments for both the keyboard (requiring 2 AAA batteries) and the mouse (requiring 1 AA battery). It also clearly shows the storage location of the USB Nano Receiver within the mouse's battery compartment.

2.3 Connecting the USB Nano Receiver

The keyboard and mouse share a single USB Nano Receiver for wireless connectivity.

1. Ensure your computer is powered on.
2. Insert the USB Nano Receiver into an available USB port on your computer.
3. The system will automatically detect and install the necessary drivers. This is a plug-and-play device, so no manual driver installation is typically required.



Image 2.2: This image demonstrates the 2.4G wireless connection setup, showing the USB receiver plugged into a laptop, indicating the simple plug-and-play process for connecting both the keyboard and mouse.

2.4 Powering On

After installing batteries and plugging in the receiver:

- Locate the ON/OFF switch on the underside of both the keyboard and the mouse.
- Slide the switches to the 'ON' position.
- The devices should now be connected and ready for use.

3. Operating Instructions

3.1 Basic Use

Once connected, the keyboard and mouse function as standard input devices. The keyboard features a full-size layout with a number pad and retro-style round keycaps for a unique typing experience. The mouse provides precise cursor control.

3.2 Multimedia Keys

The keyboard includes 12 multimedia keys (F1-F12) that provide quick access to various functions. These functions are typically activated by pressing the 'Fn' key simultaneously with the desired F-key. Refer to the keycap legends for specific functions such as volume control, media playback, and web browser shortcuts.

3.3 Universal Compatibility

The MOFII Wireless Keyboard and Mouse Combo is designed for broad compatibility with various operating systems.

- Compatible with Windows 98 / Me / 2000 / XP / Vista / Win 7 / Win8 / Win10 and later versions.
- Compatible with Mac OS.



Image 3.1: This image visually confirms the compatibility of the MOFII Wireless Keyboard and Mouse Combo with both Mac OS and

Windows operating systems, showing the devices connected to various computer setups.

3.4 Intelligent Energy Saving

To conserve battery life, both the keyboard and mouse feature an intelligent auto-sleep function. If left idle for a period, the devices will enter a low-power sleep mode. To wake them up, simply click any key on the keyboard or any button on the mouse. The devices will reconnect within seconds.

4. Maintenance

4.1 Cleaning

Regular cleaning helps maintain the performance and appearance of your keyboard and mouse.

- **Keyboard:** The keyboard features a removable keycap design, making it easy to clean. Gently pull keycaps upwards to remove them. Use a soft brush (a cleaning brush may be included in the package) or compressed air to remove dust, crumbs, and debris from underneath the keycaps. Wipe the keycaps and keyboard surface with a soft, damp cloth. Ensure all parts are dry before reattaching keycaps.
- **Mouse:** Wipe the surface of the mouse with a soft, damp cloth. Use a cotton swab to clean around the optical sensor if necessary.



Image 4.1: This image highlights the removable keycap design of the keyboard, showing a keycap detached and a cleaning brush, illustrating how easy it is to clean dust and debris from the keyboard's interior.

4.2 Battery Replacement

When the keyboard or mouse performance degrades (e.g., delayed response, intermittent connection), it is likely time to replace the batteries. Follow the battery installation steps in Section 2.2.

5. Troubleshooting

If you encounter issues with your MOFII Wireless Keyboard and Mouse Combo, please refer to the following common solutions:

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low or dead batteries	Replace batteries in both keyboard and mouse.

Problem	Possible Cause	Solution
No connection / Intermittent connection	USB receiver not properly inserted or loose	Unplug and re-insert the USB Nano Receiver firmly into a different USB port.
No connection / Intermittent connection	Devices are too far from the receiver or obstructed	Ensure the keyboard and mouse are within the 33ft (10m) operating range and there are no large metal objects between them and the receiver.
Mouse cursor erratic or not moving smoothly	Dirty optical sensor or unsuitable surface	Clean the optical sensor on the underside of the mouse. Use the mouse on a clean, non-reflective, opaque surface or a mouse pad.
Keyboard keys are sticky or unresponsive	Debris under keycaps	Refer to Section 4.1 for cleaning instructions, including removing keycaps.

If the problem persists after trying these solutions, please contact customer support.

6. Specifications

Key technical specifications for the MOFII Wireless Keyboard and Mouse Combo:

- **Connectivity Technology:** 2.4GHz RF Wireless
- **Wireless Range:** Up to 33 feet (10 meters)
- **Keyboard Dimensions (L x W x H):** 15.39 x 5.3 x 1.54 inches (39.1 x 13.5 x 3.9 cm)
- **Mouse Dimensions (L x W x H):** Approximately 3.9 x 2.7 x 1.46 inches (9.8 x 7 x 3.7 cm)
- **Item Weight:** 1.34 pounds (approximately 0.61 kg)
- **Keyboard Battery:** 2 x AAA batteries (not included)
- **Mouse Battery:** 1 x AA battery (not included)
- **Compatible Devices:** Laptop, PC
- **Operating System Compatibility:** Windows 98 / Me / 2000 / XP / Vista / Win 7 / Win8 / Win10/ Vista Mac OS or latest
- **Keyboard Style:** Retro with Round Keycaps
- **Special Features:** Plug & Play, Intelligent Energy Saving, Removable Keycaps




Image 6.1: This image provides a detailed diagram of the dimensions for both the MOFII Wireless Keyboard and Mouse, including length, width, and height measurements in both inches and centimeters.

7. Warranty and Support

7.1 Warranty Information

MOFII products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official MOFII website. Typically, the warranty covers defects in materials and workmanship under normal use.

7.2 Customer Support

If you require further assistance, have questions not covered in this manual, or need to report a defect, please contact MOFII customer support. You can usually find contact information (email, phone, or support portal) on the MOFII official website or on the product packaging.
When contacting support, please be prepared to provide your product model (Green Colorful-A, ASIN: B0BFQWQ1SY) and a detailed description of the issue.

© 2024 MOFII. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BFQWQ1SY

More documents and user manuals: **https://manuals.plus/**