

Phomemo Q30S

Phomemo Q30S Mini Label Maker User Manual

Model: Q30S

INTRODUCTION

The Phomemo Q30S Mini Label Maker is a compact, portable, and wireless label printer designed for ease of use and versatility. This device connects via Bluetooth to your smartphone or tablet, allowing you to create and print custom labels for various organizational needs. Its thermal printing technology ensures inkless operation, providing clear and durable labels for home, office, or travel use.

SETUP GUIDE

1. Package Contents

- Phomemo Q30S Mini Label Maker
- Type-C Charging Cable
- One roll of 12x40mm labels (pre-installed or included)
- User Manual (this document)

2. Powering the Device

The Phomemo Q30S supports two power methods: USB-C charging or AAA batteries.

- **USB-C Charging:** Connect the provided Type-C charging cable to the printer's charging port and a USB power adapter (not included). The device will charge automatically.
- **AAA Batteries:** Open the battery compartment and insert 4 AAA batteries (not included), ensuring correct polarity.

User-friendly Q30S Label



Waterproof

Scratch Resistant



Easy to Tear Off

Clear Print




Image: The Phomemo Q30S label maker can be powered via its Type-C charging port or by inserting 4 AAA batteries into its dedicated compartment.

3. App Installation and Bluetooth Connection

The Phomemo Q30S requires the "Print Master" application for operation. Do not connect via your phone's system Bluetooth settings directly.

1. **Download the App:** Search for "Print Master" on the Apple App Store (for iOS) or Google Play Store (for Android) and install it.

2. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone or tablet.
3. **Connect via App:** Open the "Print Master" app. The app will guide you to connect to the Q30S printer. Select "Q30S" from the list of found devices within the app to establish the connection.

Q30S Mini Label Maker

Palm-sized, like a Compact Powder



Image: Visual guide demonstrating the three steps to connect the Phomemo Q30S to your mobile device using the Print Master app, starting with enabling Bluetooth and then connecting within the app.

4. Loading Labels

The Phomemo Q30S uses thermal labels. Ensure the label roll is inserted correctly for proper printing.

- Open the printer's cover.
- Insert the label roll with the printing side facing upwards, ensuring the labels feed smoothly through the output slot.
- Close the cover securely.



Image: The Phomemo Q30S label maker with a label roll, illustrating how labels are dispensed from the device, alongside examples of printed labels including a barcode and text labels.

OPERATING INSTRUCTIONS

1. Designing Labels with Print Master App

The Print Master app offers extensive customization options for your labels.

- **Text:** Enter text and choose from over 22 fonts.
- **Icons & Borders:** Access a library of over 300 icons and 39 borders to enhance your labels.

- **Barcodes & QR Codes:** Generate and print barcodes and QR codes directly.
- **Date & Time:** Add current date or time to your labels.
- **Lines:** Incorporate lines for separation or design elements.
- **Label Size:** Compatible with label widths of 6mm, 12mm, 14mm, and 15mm.

Customize Your Labels



Border

57 Borders



QR code

Text/Number Conversion



Time


8 Date Display

12-29-2021



Icon

300+ Icons



Text

26 Fonts

Thank you!




1D code

Text/Number Conversion



4 Printing Size

6mm



12mm



14mm



15mm




Image: The Print Master app interface displaying various customization tools including borders, icons, fonts, and options for adding QR codes, barcodes, and dates, alongside examples of customized labels on food containers.

2. Printing Labels

Once your design is complete in the Print Master app, simply tap the print button. The Q30S will quickly print your label.

Inkless and BPA Free Caring for your family

Contains a roll of **12x40mm** labels



Jar Labels



Food Storage

Image: A Phomemo Q30S label maker actively printing a label, which is then applied to a jar of almond nuts, demonstrating its use for marking food items and dates.

3. Label Types and Features

The Phomemo Q30S is compatible with various label types and offers durable label properties.

- **Die-cut Labels:** Pre-cut labels for consistent sizing.
- **Continuous Labels:** Allows for custom label lengths, saving material.
- **Transparent & Color Labels:** Supports a range of aesthetic options.
- **Inkless & BPA Free:** Uses thermal printing, eliminating the need for ink and ensuring safety.
- **Waterproof & Scratch Resistant:** Labels are designed to withstand moisture and minor abrasions.
- **Easy to Tear Off:** Labels can be removed cleanly without leaving residue.
- **Clear Print:** Produces sharp and legible text and graphics.

Q30S

• Smart Label Maker •

Helps You Mark Food
Names and Dates



Image: Illustration of the Phomemo Q30S's capability to print both die-cut labels (shown as small, individual labels for jars) and continuous labels (shown as a long strip for custom lengths), highlighting their use in kitchen organization.

Support Die-cut & Continuous Labels



***Save time,
uniform label length***



Die-cut

Continuous Labels

Easily edit longer labels



Image: Examples of Phomemo Q30S labels applied to spice jars and food storage containers, emphasizing the inkless and BPA-free nature of the labels for family safety.

Bluetooth Connect




Image: A series of demonstrations showing the durability of Phomemo Q30S labels, including being waterproof (wiping a labeled bottle), scratch-resistant (scissors near a label), easy to tear off (peeling a label), and providing clear print (a labeled jar of black pepper).

MAINTENANCE

1. Cleaning the Printer

To ensure optimal print quality and longevity of your Phomemo Q30S, regular cleaning is recommended.

- Turn off the printer and disconnect any power cables.
- Open the label compartment.
- Gently wipe the thermal print head with a soft, lint-free cloth dampened with isopropyl alcohol. Allow it to dry completely before closing the cover.
- Clean the exterior of the printer with a dry, soft cloth.

2. Storing Labels

Store label rolls in a cool, dry place away from direct sunlight and extreme temperatures to preserve their adhesive and print quality.


TROUBLESHOOTING

Problem	Possible Cause	Solution
Printer does not turn on.	Low battery or no power.	Charge the printer using the Type-C cable or replace the AAA batteries.
Cannot connect via Bluetooth.	Incorrect connection method; Bluetooth not enabled; app issue.	Ensure Bluetooth is enabled on your device. Connect through the "Print Master" app, not directly via system settings. Restart the app and printer.
Poor print quality or blank labels.	Label roll inserted incorrectly; dirty print head; low battery.	Ensure the label roll is inserted with the printing side facing up. Clean the thermal print head. Charge the printer.
Labels not feeding properly.	Label jam; incorrect label type; sensor obstruction.	Open the cover and clear any jammed labels. Ensure you are using compatible Phomemo Q30S labels. Check for any debris obstructing the label path.
First label prints incorrectly (text in one spot).	Initial feed issue.	This can sometimes occur. Try printing a second label immediately after, or gently pull the label forward slightly before the first print.

For further assistance, refer to the "Operation Guide" within the Print Master app or contact Phomemo customer support.

SPECIFICATIONS

Feature	Detail
Model Name	Q30S
Connectivity Technology	Bluetooth
Printing Technology	Thermal
Maximum Media Size	15mm
Print Media	Labels
Compatible Devices	Smartphones (iOS, Android)
Maximum Print Resolution (B&W)	203 DPI



English


Chinese

Spanish

French

10. Label Maker Connection

Connect the printer to the smartphone via Bluetooth.



1. Turn on the printer and the smartphone.


2. Open the Phomemo app on the smartphone.

3. Tap the "Connect" button in the app.

4. Select the printer from the list of devices.

11. Confirm the Label Size

Check the label size settings in the app.




1. Tap the "Settings" button in the app.

2. Tap the "Label Size" button.

3. Select the label size from the list.

12. Printing Guide Select Edit Version

Select the label size and the content to print.




1. Tap the "Print" button in the app.

2. Select the label size and the content to print.

13. Printing Guide Lite Mode

Print labels in Lite Mode.




1. Tap the "Print" button in the app.

2. Select the label size and the content to print.

14. Printing Guide Creation Mode

Create custom labels in Creation Mode.




1. Tap the "Print" button in the app.

2. Select the label size and the content to print.

15. Daily Cleaning

Clean the printer daily.




1. Turn off the printer.

2. Clean the printer with a soft cloth.

16. Solutions for Common Problems

Solve common problems.




1. Check the printer settings.

2. Check the label size settings.

17. Product Warranty

Check the product warranty.




1. Check the product warranty.

2. Check the product warranty.

18. FCC Caution

Read the FCC Caution.




1. Read the FCC Caution.

2. Read the FCC Caution.

19. Warranty/Maintenance Card

Fill out the Warranty/Maintenance Card.



1. Fill out the Warranty/Maintenance Card.

2. Fill out the Warranty/Maintenance Card.

Thank you for choosing our products!


Phomemo D35 Wireless Bluetooth Label Maker: User Guide and Features

A comprehensive user guide for the Phomemo D35 wireless Bluetooth label maker. Learn how to set up, use the smartphone app, and print custom labels for home and office organization with this portable mini label printer.

Instruction


D30

Product Instruction



Please read the instruction carefully before using this product and keep it properly.

For more detailed information, please check the official website: www.phomemo.com



Operation guide QR code

Subtle: Please scan the QR code to get the printer operation guide.

Table of Contents

01

02

03

04



08. Printing Guide - Lite Mode

1 Click "Label"




2 Click to select the corresponding label size



3 Click the blank box to enter text



4 Add function description



Function	Operation method	Example
1	Click to insert time, date, and other content such as text, etc.	A → A
2	Add date	MON 2022/1/1
3	Add specific time point	MON 18:48 pm
4	Add symbol	MON 500ml

5 After editing, click to "Print"



6 After the printing is completed, tear off the label



08. Printing Guide - Creation Mode

1 Click the size box and select corresponding label size



2 Click to select the corresponding label size



3 If the corresponding size template is not selected correctly, there will be a red dashed border around the template, and the corresponding size will be displayed in red.



4 Click "12x48" to input text



5 Add function description



6 After editing, click to "Print"



7 After the printing is completed, tear off the label



Function	Description
1	Click to insert time, date, and other content such as text, etc.
2	Add date
3	Add specific time point
4	Add symbol
5	Click to insert time, date, and other content such as text, etc.
6	Add date
7	Add specific time point
8	Add symbol
9	Click to insert time, date, and other content such as text, etc.
10	Add date
11	Add specific time point
12	Add symbol

13 Click the print label after editing



14 After the printing is completed, tear off the label



09. Product Specifications

Product name	Small Label Printer
Product model	D30
Printing technology	Thermal printing
Effective printing width	12.5mm
Support materials	Pre-cut paper, blank paper, continuous paper
Printing density	1200 dpi
Printing resolution	1200 dpi
Print head service life	100000
Communication interface	Bluetooth 5.0
Product size	110mm x 70mm x 20mm
Power source	5V/1A
Power supply method	USB
Support operating system	Android, iOS

10. Daily Cleaning

1 Turn off the printer



2 Use a cotton swab dipped in a little alcohol



3 Wipe the print head gently



4 Do not touch the print head with hard objects, otherwise the print head will be damaged and cannot be repaired



11. Solutions for Common Problems

Not centered, misplaced, offset, skipped, etc.

Problem: Whether the paper roll is correctly placed in the machine?

Solution: Please make sure the label is placed correctly in the machine with printing side facing left. If it is placed incorrectly, printing will fail.

Problem: Whether the paper is selected correctly?

Solution: Please make sure the paper is selected correctly in the app. Please confirm the size and pattern in the label packaging, and select the matching template in the app.

Problem: Whether the machine is turned on, whether to click the power button?

Solution: Please make sure the machine is turned on, and click the power button. When turning on or printing, please make sure the power button is pressed. The power button for printing a label is on the back of the machine, and the power button for printing a label is on the back of the machine.

Printing blurry

Problem: Whether the power of machine is sufficient?

Solution: Please make sure the power of machine is sufficient. If the power is not sufficient, please use a power adapter to charge the power button. If the power button is not charged, the power button will not work.

Printer cannot be connected


Problem: Whether the printer is connected to the mobile phone correctly?

Solution: Please make sure the printer is connected to the mobile phone correctly. The printer needs to be connected to the mobile phone correctly.

Phomemo D30 Small Label Printer Instruction Manual

Comprehensive instruction manual for the Phomemo D30 Small Label Printer, covering setup, app download, paper installation, printer connection, printing guides (Lite and Creation modes), product specifications, daily cleaning, and troubleshooting common issues.

Is the mobile phone authorized?
Because of the security requirements, authorized phones will use your account when it is connected, and you need to turn on the mobile phone authorization before phone system don't need to turn on the function.




12. Product Warranty

Thank you for choosing the Small Label Printer

(1) We will provide customer with reliable "telephone/internet" support during the one year warranty period from the date of purchase.
(2) Please keep the necessary parts in safe place so that you can find it when needed.

✉ support@phomemo.com
🌐 www.phomemo.com

📄 Please scan the QR code to get the printer operation guide.



The manual has been carefully checked. There is printing error or color deviation in the content, please contact customer service.
Note: If the operating software is updated, it will be completed into the new version of the manual without notice.

13. FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If you notice that the equipment is causing interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to a different electrical outlet than that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

⚠ Warning for Portable device
The device has been evaluated to meet general RF exposure requirements.

13. Warranty/Maintenance Card

☐ Tablet ☐ Other

User Information	Name	Gender	Phone
Address			


Product Information	Serial Number
Product color number	
Production lot number	
Full description	

Reason for Return	Address/Phone
Address/Phone	

Thank you for choosing our products!

[Phomemo D30 Small Label Printer Instruction Manual](#)

Discover the Phomemo D30 Small Label Printer user manual, providing comprehensive instructions for setup, operation, app connectivity, paper installation, printing guides (Lite and Creation modes), product specifications, daily cleaning, and troubleshooting common issues. Optimize your labeling tasks with this portable thermal printer.



[Phomemo Portable Thermal Printer User Guide & Operation Manual](#)

Comprehensive user guide for Phomemo portable thermal printers, including models like M02S, D30, and Q30S. Learn about product features, power indicators, battery safety, app download, Bluetooth connection, and paper replacement. Discover official Phomemo consumables.



[Phomemo M200 Portable Label Maker Instruction Manual](#)

User guide for the Phomemo M200 portable label maker, detailing setup, specifications, parts, app installation, printing, and troubleshooting. Includes multilingual instructions and warranty information.



[Phomemo M200 Portable Label Printer: User Manual and Specifications](#)

Comprehensive guide to the Phomemo M200 portable label printer, covering product specifications, parts, installation, app connection, settings, and regulatory information. Includes multilingual support details.