

Vianté 100B

Vianté Electric Kettle with Infuser (Model 100B) Instruction Manual

Your Guide to Perfect Brewing

INTRODUCTION

Welcome to the world of precision brewing with your new Vianté Electric Kettle with Infuser. Designed in Italy, this versatile appliance allows you to achieve optimal temperatures for various teas and coffees, ensuring a perfect cup every time. Crafted from high-quality materials, it combines functionality with elegant design to enhance your beverage experience.

- **Precision Temperature Control:** Dial in exact ideal temperatures for various types of tea and coffee.
- **Integrated Infuser:** Use for steeping loose leaf or bagged tea, or remove for heating water for French press, pour-overs, and food prep.
- **Bespoke Brewing Programs:** Pre-set temperature controls for white, green, oolong, and black teas.
- **Keep Warm Function:** Enjoy hot beverages for longer with the 30-minute Keep Warm feature.
- **Durable Construction:** Made of 304 stainless steel, borosilicate glass, and BPA-free plastic for longevity and safety.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before first use to ensure safe operation and optimal performance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Compatibility:** This appliance is designed for 110-120V power outlets. Do not use with 230V mains power or in regions with different voltage requirements without a suitable converter, as this can be dangerous and damage the unit.
- **Hot Surfaces:** The kettle's exterior, especially the glass body and lid, can become hot during and after operation. Always use the handle when pouring. Avoid direct contact with hot steam.
- **Water Level:** Do not overfill the kettle beyond the MAX fill line to prevent boiling water from overflowing. Do not operate if the water level is below the MIN line.
- **Placement:** Always place the kettle on a stable, flat, heat-resistant surface away from the edge of the countertop.

- **Child Safety:** Keep the appliance out of reach of children. Close supervision is necessary when any appliance is used by or near children.
- **Power Cord:** Ensure the power cord does not hang over the edge of a table or counter, or touch hot surfaces.
- **Dry Boil Protection:** The kettle is equipped with dry boil protection, which automatically shuts off the heating element if the kettle is accidentally switched on without water or if the water boils dry.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Vianté Electric Kettle:

- **Glass Kettle Body:** Made from shatter-resistant borosilicate glass with clear measurement markings.
- **Stainless Steel Base:** Features intuitive controls for temperature selection and operation.
- **Removable Infuser Basket:** Stainless steel mesh for steeping loose leaf tea or fruit.
- **Lid:** Securely fits the kettle body, with a handle for easy removal.
- **Handle:** Ergonomically designed for comfortable and safe pouring.



Image: Detailed view of the Vianté Electric Kettle, highlighting its various components such as the glass body, stainless steel base with controls, removable infuser, and ergonomic handle.

SETUP AND FIRST USE

1. **Unpack:** Carefully remove all packaging materials and inspect the kettle for any damage.
2. **Clean:** Before first use, wash the kettle body, lid, and infuser basket with warm, soapy water. Rinse thoroughly and dry. Do not submerge the power base in water.
3. **Initial Boil:** Fill the kettle with water to the MAX line. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
4. **Placement:** Place the power base on a dry, flat, stable surface. Ensure the power cord is not obstructed.

OPERATING INSTRUCTIONS

Brewing Tea with Infuser

1. **Fill Kettle:** Fill the glass kettle body with fresh, cold water to your desired level, ensuring it is between the MIN and MAX markings.
2. **Add Tea:** Open the infuser basket and add your desired amount of loose leaf tea, tea bags, or fruit. Close the infuser and place it securely into the kettle.
3. **Select Temperature:** Place the kettle onto the power base. Use the temperature control buttons to select the appropriate temperature for your tea type (e.g., Green, White, Oolong, Black/Herbal). Refer to the markings on the base for recommended temperatures.
4. **Start Brewing:** Press the 'Start/Stop' button to begin the heating process. The kettle will automatically heat the water to the selected temperature.
5. **Keep Warm (Optional):** If you wish to keep your tea warm after brewing, press the 'Keep Warm' button. The kettle will maintain the temperature for up to 30 minutes.
6. **Serve:** Once brewing is complete, carefully lift the kettle from its cordless base and pour your freshly brewed tea.

Heating Water without Infuser

1. **Remove Infuser:** Ensure the infuser basket is removed from the kettle.
2. **Fill Kettle:** Fill the glass kettle body with fresh, cold water to your desired level.
3. **Select Temperature:** Place the kettle onto the power base. Select the desired temperature (e.g., 'Boil' for 212°F, or a specific temperature for French press).
4. **Start Heating:** Press the 'Start/Stop' button. The kettle will heat the water and automatically shut off once the target temperature is reached.
5. **Serve:** Carefully pour the hot water for your coffee, instant meals, or other needs.

Video: Demonstrates the general operation of an electric kettle with temperature control and infuser. This video shows filling the kettle, setting temperature, and brewing tea.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and performance of your kettle.

- **Daily Cleaning:** After each use, empty any remaining water and dry the interior of the kettle.

- **Hand Wash Only:** The kettle body, lid, and infuser basket should be hand washed with warm, soapy water. Rinse thoroughly. Do not use abrasive scrubbers or harsh chemicals.
- **Avoid Submerging:** Never submerge the power base or its cord in water or any other liquid.
- **Descaling:** Over time, mineral deposits (limescale) may build up, especially in hard water areas. To descale, fill the kettle with a mixture of equal parts white vinegar and water (or use a citric acid descaling agent). Boil the mixture, then let it sit for 15-30 minutes. Discard the mixture and rinse the kettle thoroughly several times with fresh water.

For maximum longevity



Big opening makes it easy to clean



Hand wash recommended



Avoid abrasive scrubbers



Empty and dry when not in use



Image: A hand washing the interior of the Vianté Electric Kettle, demonstrating its wide opening for easy cleaning and maintenance.

TROUBLESHOOTING

If you encounter any issues with your Vianté Electric Kettle, please refer to the following common solutions:

- **Kettle Not Heating:** Ensure the kettle is properly seated on the power base and the power cord is securely plugged into a working 110-120V outlet. Check if the 'Start/Stop' button has been pressed.
- **Water Not Reaching Desired Temperature:** Verify that the correct temperature setting has been selected. Allow sufficient time for the water to heat, especially for larger volumes.

- **Automatic Shut-Off Not Working:** If the kettle does not shut off automatically, immediately unplug it and contact customer support.
- **Unusual Taste/Odor:** Perform a thorough cleaning and descaling cycle. Ensure all cleaning solutions are rinsed out completely.

For further assistance, please consult your user manual or contact Vianté customer support.

SPECIFICATIONS

Brand	Vianté
Model Number	100B
Capacity	1.5 Liters
Material	Borosilicate Glass, 304 Stainless Steel, BPA Free Plastics
Product Dimensions	9.41"L x 7.8"W x 9.61"H
Item Weight	2.99 Pounds
Special Features	Automatic Shut-Off, Built-In Infuser, Digital Control, Rapid Boil, Temperature Control
Recommended Use	Boiling, Tea Brewing

WARRANTY AND SUPPORT

Vianté is committed to your complete satisfaction. Your electric kettle is backed by our commitment to quality and service.

- **Warranty:** Please refer to the warranty information provided in your product's physical user manual for specific terms and conditions.
- **Protection Plans:** Extended protection plans are available for purchase. Options include 3-Year and 4-Year Protection Plans.
- **Customer Support:** For any questions, troubleshooting, or warranty claims, please refer to the contact information in your user manual or visit the official Vianté website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question