

[manuals.plus](#) /› [SUPRENT](#) /› [SUPRENT PRO Professional Hair Clippers and T-Blade Trimmer Combo Instruction Manual](#)**SUPRENT SUPRENT PRO**

SUPRENT PRO Professional Hair Clippers and T-Blade Trimmer Combo Instruction Manual

Model: SUPRENT PRO

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the SUPRENT PRO Professional Hair Clippers and T-Blade Trimmer Combo. Keep this manual for future reference.

- Always unplug the clippers before changing or cleaning the blades.
- Avoid contact with eyes and face during operation.
- Keep out of reach of children.
- Do not ingest or inhale small parts.
- Dispose of hair trimmings responsibly.
- Do not immerse the unit in water.
- Use only the provided charging cables and accessories.

2. PRODUCT OVERVIEW AND WHAT'S IN THE BOX

The SUPRENT PRO Professional Hair Clippers and T-Blade Trimmer Combo is designed for precision hair cutting and detailing. This kit includes a powerful hair clipper and a zero-gap T-blade trimmer, along with essential accessories.



Image: The SUPRENT PRO Hair Clipper and T-Blade Trimmer.



Image: The SUPRENT PRO Hair Clipper and T-Blade Trimmer shown with included metal guide combs.

Your kit typically includes:

- SUPRENT PRO Hair Clipper
- SUPRENT PRO T-Blade Trimmer
- 6 Metal Guide Combs for Hair Clipper
- 3 Guide Combs for Detail Trimmer
- Charging Cables (USB)
- Cleaning Brush
- Blade Oil
- Hair Cutting Cape (style may vary)

Unboxing Video

Your browser does not support the video tag.

Video: An unboxing of the SUPRENT PRO clipper kit, showcasing all included components and their initial presentation.

3. SETUP

Charging the Clippers and Trimmer

Both the hair clipper and T-blade trimmer are equipped with long-life Li-ion batteries and support cord/cordless use. Before first use, fully charge both devices.

- Connect the charging cable to the device and a suitable USB power adapter (not included).
- The LED display on the clipper will show the battery status. The trimmer may have a blue light indicator.
- Charging time for the hair clipper is approximately 180 minutes for 5 hours of running time.
- Charging time for the detail trimmer is approximately 120 minutes for 3 hours of running time.



Image: The SUPRENT PRO Hair Clipper and T-Blade Trimmer connected to USB charging cables.

Attaching Guide Combs

Select the desired metal guide comb for your preferred hair length. Align the comb with the clipper or trimmer blade and snap it securely into place.

Adjusting the T-Blade for Zero Gap

The T-blade trimmer can be adjusted for a zero-gap cut, allowing for closer trimming and outlining. Refer to the video below for detailed instructions on how to perform this adjustment.

Your browser does not support the video tag.

Video: A demonstration on how to adjust the T-blade of the trimmer to achieve a zero-gap setting for precise cuts.

4. OPERATING INSTRUCTIONS

Ensure the device is fully charged before use. Turn on the clipper or trimmer using the power switch.

Hair Clipper Usage

- The hair clipper features a powerful rotary motor for smooth cutting, even through thick hair.
- Use the adjustable taper lever (0.5-2mm) to fine-tune cutting lengths for fading and blending.

- Attach the appropriate metal guide comb for bulk hair removal or desired length.

T-Blade Trimmer Usage

- The T-blade is ideal for carving, tapering, blending, and fading.
- Use the trimmer to shape precise edges and create detailed designs.
- For closest cuts, ensure the T-blade is zero-gapped (refer to Setup section).

LED Smart Display

The ultra-clear LED display on the clipper shows the remaining battery percentage, allowing you to monitor power levels during use.



Image: Close-up of the SUPRENT PRO Hair Clipper's powerful motor, LED multi-function display, and metal guide comb.

Operational Videos

Your browser does not support the video tag.

Video: A barber demonstrates the use of the SUPRENT PRO clipper and trimmer for a precise haircut.

Your browser does not support the video tag.

Video: Showcase of the SUPRENT PRO tools in action, creating various styles with ease and precision.

Your browser does not support the video tag.

Video: A demonstration of the SUPRENT Hair kit for achieving quality haircuts.

Your browser does not support the video tag.

Video: Professional barber demonstrating the SUPRENT PRO tools for various styles.

Your browser does not support the video tag.

Video: A professional overview of the SUPRENT Professional Hair Clippers for Men.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your SUPRENT PRO devices.

Cleaning the Blades

- Always turn off and unplug the device before cleaning.
- Use the provided cleaning brush to remove loose hair from the blades after each use.
- For a deeper clean, carefully detach the blade assembly (refer to the zero-gap adjustment video for guidance on blade removal) and rinse under running water. Ensure blades are completely dry before

reattaching.

Oiling the Blades

Regular oiling helps maintain blade sharpness and smooth operation. Apply a few drops of the included blade oil to the teeth of the blades after every few uses or as needed. Turn on the device for a few seconds to distribute the oil evenly.

6. TROUBLESHOOTING

If you encounter issues with your SUPRENT PRO devices, try the following troubleshooting steps:

- **Device not turning on:** Ensure the device is fully charged. Check the charging cable and adapter for damage.
- **Reduced cutting performance:** Clean the blades thoroughly to remove any hair buildup. Apply blade oil. Ensure the blades are properly aligned.
- **Unusual noise or vibration:** Turn off the device and inspect the blades for any foreign objects or damage. Ensure the blade assembly is securely attached.
- **Battery not holding charge:** Ensure you are using the original charging cable. If the issue persists, contact customer support.

7. SPECIFICATIONS

Feature	Specification
Product Dimensions	11.6 x 8.4 x 2.7 inches
Weight	2.54 Pounds
Battery Type	1 Lithium Ion battery required
Hair Clipper Motor Speed	5500 RPM
Hair Clipper Running Time	5 hours
Hair Clipper Charging Time	3 hours
Detail Trimmer Motor Speed	6000 RPM $\pm 10\%$
Detail Trimmer Running Time	3 hours
Detail Trimmer Charging Time	2 hours
Included Components	Hair Clipper, T-Blade Trimmer, Guide Combs, Charging Cables, Cleaning Brush, Blade Oil, Hair Cape

Feature	Specification
---------	---------------

8. WARRANTY AND SUPPORT

Your SUPRENT PRO Hair Clippers and T-Blade Trimmer Combo comes with a standard return policy allowing for refund or replacement within 30 days of purchase.

Protection Plans

Extended protection plans are available for purchase:

- **2-Year Protection Plan:** Available for \$8.99.
- **3-Year Protection Plan:** Available for \$11.99.
- **Complete Protect:** A monthly plan covering all eligible past and future purchases for \$16.99/month.

For further assistance, product support, or warranty claims, please refer to the contact information provided with your purchase or visit the official SUPRENT website.