

FLEXTAILGEAR FLEXT

FLEXTAILGEAR Portable Air Pump FLEXT Instruction Manual

Model: FLEXT

1. INTRODUCTION

Thank you for choosing the FLEXTAILGEAR Portable Air Pump. This compact and powerful electric pump is designed for quick inflation and deflation of various inflatable items, making it ideal for camping, travel, and home use. Please read this manual carefully before use to ensure proper operation and maintenance.

2. PRODUCT OVERVIEW AND FEATURES

The FLEXTAILGEAR Portable Air Pump is a lightweight and versatile device with a robust design. Its key features include:

- **Compact & Travel-Ready Design:** Weighing just 160 grams (5.6 oz) with dimensions of 2.1"L x 2.1"W x 3.1"H, it's easy to carry.
- **Powerful In/Deflation:** Features 300L/min wind speed and 2 kPa air pressure for rapid inflation/deflation.
- **Rechargeable Battery:** Equipped with a 3600mAh lithium battery, providing up to 45 minutes of operation on a full charge.
- **Versatile Nozzles:** Includes 5 different nozzles for compatibility with various inflatable products.
- **Durable & Water-Resistant:** Crafted with an ABS shell and well-sealed surface technology, offering IPX4 water-resistant rating.
- **Modern Type-C Charging:** Enables versatile charging compatibility.

IPX4 Water Resistance



Image: The FLEXTAILGEAR Portable Air Pump highlighting its deflation port, inflation port, pump switch, charging indicator, and Micro-USB charging port.

3. PACKAGE CONTENTS

Please check the package for the following items:

- FLEXTAILGEAR Portable Air Pump (Model: FLEXT)
- 5 x Different Nozzles
- USB Type-C Charging Cable
- Storage Pouch
- Instruction Manual

4. SPECIFICATIONS

Attribute	Value
Brand	FLEXTAILGEAR
Model Number	FLEXT

GTIN	641055647361
Color	White
Material	Acrylonitrile Butadiene Styrene
Item Weight	160 Grams (5.6 oz)
Product Dimensions	2.1"L x 2.1"W x 3.1"H
Power Source	Battery Powered (3600mAh Lithium Battery)
Air Flow Capacity	300 Liters Per Minute
Maximum Pressure	2.2 Kilopascal
Operation Mode	Automatic

5. SETUP

5.1 Charging the Air Pump

Before first use, fully charge the air pump. The device features a modern Type-C charging port for convenience.

- Connect the provided USB Type-C charging cable to the pump's charging port.
- Connect the other end of the cable to a compatible USB power source (e.g., wall adapter, power bank, computer).
- The charging indicator will show the battery status. A full charge allows up to 45 minutes of operation.

MAX PUMP PLUS

Your must-have air pump for outdoor



Image: The charging indicator on the FLEXTAILGEAR Portable Air Pump, illustrating different battery levels from 100% to 0-5% and the Micro-USB charging port.

5.2 Attaching Nozzles

Select the appropriate nozzle for your inflatable item. The pump comes with 5 different nozzles to fit various valve sizes.

- Identify the correct nozzle that fits snugly into the valve of your inflatable.
- Insert the chosen nozzle into the inflation or deflation port of the air pump.




Image: The FLEXTAILGEAR Portable Air Pump shown with a selection of different nozzles for various inflatable items.

6. OPERATING INSTRUCTIONS

6.1 Powering On/Off

- To turn on the air pump, **double-click** the power button.
- To turn off the air pump, **single-click** the power button.

6.2 Inflation

To inflate an item:

1. Select the appropriate nozzle and attach it to the **inflation port** of the pump.
2. Insert the nozzle firmly into the valve of the item you wish to inflate.
3. Double-click the power button to turn on the pump.
4. Monitor the inflation process and turn off the pump once the item is sufficiently inflated.

Video: Official FLEXTAILGEAR video demonstrating the MAX PUMP PULS in action, showing its use for inflating various items like sleeping pads, neck pillows, and swimming rings, as well as deflating vacuum bags.

Q
A

Can I bring this Max Pump Plus on the plane?
Our battery capacity is 3600 mah, it is generally allowed to be carried on the plane, but we recommend that you [check with the airline](#) in advance if it is OK to carry.

Q
A

Can I use the air pump while charging?
We recommend [not using it](#) while the air pump is charging. This helps ensure optimal battery health. If it is not used for a long time, it is recommended to charge it at least [once a month](#).

Q
A

Can this air pump be used to inflate the ball?
Please note that this air pump [cannot inflate](#) balloons, sports balls, tires and other inflatable products with high pressure requirements.

Q
A

Why can't I turn on this air pump?
In order to prevent the air pump from opening incorrectly, our product is designed to [double-click](#) to turn on the air pump and one-click to turn off the pump.

Image: A visual guide showing three steps for inflation: 1) Select appropriate nozzle, 2) Place nozzle at inflation port, 3) Double click to open the air pump.

6.3 Deflation

To deflate an item:

1. Select the appropriate nozzle and attach it to the **deflation port** of the pump.
2. Insert the nozzle firmly into the valve of the item you wish to deflate.
3. Double-click the power button to turn on the pump.
4. Allow the pump to extract air until the item is fully deflated.




Image: A visual guide showing three steps for deflation: 1) Select appropriate nozzle, 2) Place nozzle at deflation port, 3) Double click to open the air pump.

7. USAGE SCENARIOS AND COMPATIBILITY

The FLEXTAILGEAR Portable Air Pump is compatible with a wide range of inflatable products:

- Air mattresses
- Inflatable beds
- Pool floats
- Swim rings
- Inflatable sofas
- Sleeping pads
- Air pillows
- Vacuum storage bags (for deflation)

Not suitable for:

- Balloons
- Sports balls (e.g., basketballs, footballs, volleyballs)
- Tires (e.g., bike tires, car tires)

These items require higher pressure than the pump is designed to provide.

Product Features and Details



Image: The FLEXTAILGEAR Portable Air Pump demonstrating its ability to inflate sleeping pads, swimming rings, and air mattresses, and deflate vacuum bags. It also clearly indicates items not suitable for inflation, such as balloons, sports balls, and tires.

8. MAINTENANCE

- **Battery Care:** To maintain battery activity, recharge the pump at least once a month, especially if not used for a long time.
- **Continuous Use:** To protect the battery-powered air pump, do not use it constantly for over 10 minutes. Allow it to cool down before resuming use.
- **Cleaning:** The pump has an IPX4 water-resistant rating, meaning it can withstand splashes. Wipe the exterior with a damp cloth if needed. Do not submerge in water.

9. TROUBLESHOOTING

- **Pump not turning on:** Ensure the battery is charged. The pump requires a **double-click** to turn on to prevent accidental activation.
- **Item not inflating/deflating properly:** Check that the correct nozzle is securely attached and inserted firmly into the item's valve. Ensure there are no leaks in the inflatable item.
- **Pump stops working during use:** The pump may have overheated due to continuous use. Allow it

to cool down for a few minutes before attempting to use it again. Remember not to use it for more than 10 minutes continuously.

10. SAFETY INFORMATION

- Keep the device away from water and extreme temperatures.
- Do not attempt to disassemble or repair the pump yourself. Contact customer support if needed.
- Keep out of reach of children.
- Use only the provided charging cable and compatible power sources.

11. WARRANTY AND SUPPORT

For any questions or issues with your FLEXTAILGEAR Portable Air Pump, please refer to the product packaging for warranty details or contact FLEXTAILGEAR customer support directly. Your satisfaction is important to us.