

boAt Airdopes 173-cr**boAt Airdopes 173 Wireless Earbuds User Manual**

Model: Airdopes 173-cr

INTRODUCTION

Welcome to the user manual for your boAt Airdopes 173 True Wireless Earbuds. These earbuds are designed to provide an immersive audio experience with seamless connectivity and robust features. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your device, ensuring you get the most out of your Airdopes 173.

PACKAGE CONTENTS

Please verify that all the following items are included in your package:

- boAt Airdopes 173 Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- Additional Ear Cushions (various sizes)

PRODUCT OVERVIEW



Image: The boAt Airdopes 173 earbuds, one removed from the open charging case, showcasing their compact design and the charging case's interior.

The boAt Airdopes 173 consists of two true wireless earbuds and a portable charging case. Each earbud is equipped with a 6mm dynamic driver for powerful sound, a microphone for calls, and a multifunction button for controls. The charging case features a 380mAh battery and a Type-C port for convenient charging, providing extended playtime for your earbuds.

SETUP

Initial Charge

**PLEASE CHARGE
THE CASE & EARBUDS
BEFORE FIRST USAGE**



Image: A visual reminder to fully charge the earbuds and charging case before the first use, showing the earbuds and case.

Before using your boAt Airdopes 173 for the first time, it is recommended to fully charge both the earbuds and the charging case. Place the earbuds into their respective slots in the charging case. Connect the provided Type-C charging cable to the charging case and then to a USB power source. The indicator lights on the case will show the charging status. Ensure the earbuds are properly seated to initiate charging.

Pairing with Your Device



Image: A close-up of a single boAt Airdopes 173 earbud, highlighting its sleek design and the Bluetooth 5.0 connectivity feature.

1. Open the lid of the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your smartphone or Bluetooth-enabled device, navigate to the Bluetooth settings.
3. Search for available devices and select 'Airdopes 173' from the list.
4. Once connected, a voice prompt will confirm successful pairing.

The earbuds will automatically connect to the last paired device when removed from the case, provided Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** The earbuds power on automatically when removed from the charging case. Alternatively, long-press the multifunction button on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically. Alternatively, long-press the multifunction button on both earbuds for 5 seconds.

Music Playback

- **Play/Pause:** Single tap the multifunction button on either earbud.
- **Next Track:** Double tap the multifunction button on the right earbud.
- **Previous Track:** Double tap the multifunction button on the left earbud.

Call Management

- **Answer/End Call:** Single tap the multifunction button on either earbud.
- **Reject Call:** Long-press the multifunction button on either earbud for 2 seconds.

Voice Assistant

- **Activate Voice Assistant:** Single press the multifunction button on either earbud to activate your device's voice assistant (e.g., Google Assistant, Siri).

Wearing the Earbuds



Image: A person wearing a boAt Airdopes 173 earbud, demonstrating its ergonomic fit and discreet profile when worn.

For optimal sound quality and comfort, insert the earbuds into your ears and gently twist them until they fit securely. Experiment with the different sizes of ear cushions provided to find the best fit for your ears. A proper seal is crucial for bass response and noise isolation.

CHARGING



Image: The boAt Airdopes 173 earbuds and their open charging case, illustrating the extended playback time of up to 10 hours with the case.

Charging the Earbuds

Place the earbuds into their corresponding slots in the charging case. They will automatically begin charging. The earbuds provide up to 3 hours of playtime on a single charge.

Charging the Case

Connect the Type-C charging cable to the charging port on the case and the other end to a USB power adapter or computer. The charging case has a 380mAh battery, providing up to 3 additional charges for the earbuds, extending the total playtime to 10 hours.

MAINTENANCE

Cleaning

Regularly clean your earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or chemical solvents. Ensure the charging contacts on both the earbuds and the case are clean and free of debris.

Storage

When not in use, store the earbuds in their charging case. Keep the device in a cool, dry place, away from direct sunlight, extreme temperatures, and humidity.

Water Resistance

The boAt Airdopes 173 are rated IPX4, meaning they are resistant to sweat and light splashes of water. They are not waterproof and should not be submerged in water or exposed to heavy rain.

TROUBLESHOOTING

Issue	Solution
-------	----------

Issue	Solution
Earbuds not turning on	Ensure the earbuds and charging case have sufficient battery. Place earbuds in case, close lid, then reopen.
Earbuds not pairing	Ensure Bluetooth is enabled on your device. Forget 'Airdopes 173' from your device's Bluetooth list and re-pair. Ensure earbuds are in pairing mode.
No sound from earbuds	Check the volume level on your device. Ensure earbuds are properly connected. Try resetting the earbuds (refer to boAt support for specific reset instructions).
Only one earbud working	Place both earbuds back into the charging case, close the lid for a few seconds, then reopen. This often re-syncs them. Re-pair if necessary.
Charging issues	Verify the charging cable and power source are working correctly. Clean the charging contacts on both the earbuds and the case.

SPECIFICATIONS

Feature	Detail
Model Name	Airdopes 173-cr
Connectivity	Bluetooth v5.0
Driver Size	6mm Dynamic Drivers
Earbud Playtime	Up to 3 hours per charge
Total Playtime (with case)	Up to 10 hours
Earbud Battery Capacity	43mAh (each)
Charging Case Battery Capacity	380mAh
Water Resistance Rating	IPX4 (Sweat and Splash Resistant)
Control Type	Touch, Voice
Included Components	Earbuds, Charging Case, USB Type-C Cable, Ear Cushions
Item Weight	35 grams

WARRANTY AND SUPPORT

The boAt Airdopes 173 comes with a **6-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures your product functions as intended under normal use.

For any technical assistance, warranty claims, or further inquiries, please visit the official boAt website or contact their customer support. Keep your purchase receipt as proof of purchase for warranty services.

