

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Fossil](#) /

> [Fossil Men's Everett Quartz Stainless Steel Watch \(Model FS5965\) - Instruction Manual](#)

Fossil FS5965

Fossil Men's Everett Quartz Stainless Steel Watch (Model FS5965) - Instruction Manual

Your guide to setting up, operating, and maintaining your Fossil Everett watch.

1. PRODUCT OVERVIEW

The Fossil Men's Everett Quartz Stainless Steel Watch, Model FS5965, is an analog wristwatch designed for accurate timekeeping and style. It features a durable stainless steel construction, a quartz movement, and a three-hand date display. This manual provides essential information for its proper use and care.




Image 1.1: Front view of the Fossil Everett Gold Stainless Steel Watch.

Key features include a 42mm gold stainless steel case, a gold sunray and textured dial with gold accents, and a matching gold stainless steel bracelet. The watch is equipped with a hardened mineral crystal lens for scratch resistance and is water-resistant up to 50 meters (165 feet).

Your browser does not support the video tag.

Video 1.1: Official product video showcasing the Fossil Everett Men's Watch, Model FS5965, from various angles.

2. SETUP

2.1 Setting the Time

1. Pull the crown (the small knob on the side of the watch case) out to position 2.
2. Rotate the crown clockwise or counter-clockwise to move the hands to the correct time.
3. Once the time is set, push the crown back into position 0.

2.2 Setting the Date

1. Pull the crown out to position 1 (first click).
2. Rotate the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.

3. Once the date is set, push the crown back into position 0.





Image 2.1: Side view of the watch, highlighting the crown for time and date adjustment.

2.3 Adjusting the Bracelet Band

The stainless steel bracelet band is designed for a custom fit. If the band is too loose or too tight, links can be removed or added. It is recommended to have this adjustment performed by a professional jeweler or an authorized Fossil service center to prevent damage to the watch or band.





Image 2.2: Rear view of the watch, showing the fold-over clasp mechanism.




Image 2.3: A case size guide illustrating various round watch sizes, including 42mm.

3. OPERATING THE WATCH

Your Fossil Everett watch features a standard three-hand analog display (hour, minute, second) and a date window. Once the time and date are set as described in Section 2, the watch operates continuously using its quartz movement, powered by an included product-specific battery.



Image 3.1: Close-up view of the watch dial, showing the three hands and date window.

4. MAINTENANCE

4.1 Cleaning

To maintain the appearance of your watch, regularly wipe the case and bracelet with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

4.2 Water Resistance

This watch is water-resistant up to 50 meters (165 feet), or 5 ATM. This rating means the watch is suitable

for brief recreational swimming or showering. It is **not** suitable for diving, snorkeling, or high-impact water sports. Ensure the crown is fully pushed in before any contact with water.

4.3 Battery Replacement

The watch is powered by a product-specific battery. When the watch stops running, it indicates the battery needs replacement. It is recommended to have the battery replaced by an authorized Fossil service center or a professional watchmaker to ensure proper sealing and maintain water resistance.

5. TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed into position 0. If it is, the battery may need replacement.
- **Time is incorrect:** Refer to Section 2.1 to reset the time. Ensure the crown is fully pushed in after setting.
- **Date is incorrect or not changing:** Refer to Section 2.2 to reset the date. Ensure the time is set correctly, as the date changes automatically around midnight.
- **Bracelet feels loose or tight:** The bracelet may require adjustment by adding or removing links. Consult a professional jeweler or authorized service center.

6. SPECIFICATIONS

Feature	Detail
Model Number	FS5965
Brand	Fossil
Movement Type	Quartz
Display Type	Analog (Three-Hand Date)
Case Material	Stainless Steel
Case Diameter	42 Millimeters
Case Thickness	11.2 Millimeters
Band Material	Stainless Steel
Band Width	18 Millimeters
Band Length	200 Millimeters
Dial Color	Gold
Band Color	Gold
Crystal Material	Mineral Glass
Water Resistance Depth	50 Meters (165 Feet / 5 ATM)
Clasp Type	Push Button Foldover Clasp With Safety
Item Weight	100 Grams (3.53 Ounces)

Battery	1 Product Specific battery (included)
---------	---------------------------------------

7. WARRANTY AND SUPPORT

Your Fossil Everett watch comes with a limited warranty. For specific warranty terms, conditions, and duration, please refer to the warranty information provided with your purchase or visit the official Fossil website. For service, repairs, or further assistance, please contact an authorized Fossil service center or visit the [Fossil Store on Amazon](#).