

[Manuals.plus](#) /

› [Mueller](#) /

› Mueller Ultragroom Hair Clipper and Trimmer (Model MUUC-12002) User Manual

Mueller MUUC-12002

Mueller Ultragroom Hair Clipper and Trimmer

Model: MUUC-12002

INTRODUCTION

The Mueller Ultragroom Hair Clipper and Trimmer is a professional haircutting kit designed for both men and women. This all-in-one trimmer is suitable for hair, beards, head, body, and face, offering precise clipping with its high-performance motor and ergonomic design. It features 12 guide combs and an adjustable taper lever for versatile styling.

SAFETY INFORMATION

WARNING: Keep away from children and use as directed. Always ensure the appliance is switched off before cleaning or maintenance. Do not immerse the appliance in water. Do not use if the power cord or plug is damaged. Do not use on wet hair or skin to avoid electrical shock.

PACKAGE CONTENTS

Your Mueller Ultragroom Hair Clipper and Trimmer kit includes:

- Mueller Ultragroom Hair Clipper
- 12 Guide Combs (various lengths)
- 3 Barber Combs
- 3 Hair Clips
- Scissors
- Neck Brush
- Blade Guard

- Cleaning Brush
- Blade Oil
- Charging Cable
- User Manual

PRODUCT FEATURES

- **Self-Sharpening Carbon Steel Blades:** Designed for durability and precision, ensuring smooth, snag-free cuts.
- **Powerful Motor:** Innovative motor technology provides optimum power for efficient cutting with low noise and vibration.
- **Corded/Cordless Operation:** Offers flexibility for use with or without the cord.
- **Long-Lasting Battery:** Max power battery provides extended running time (up to 3 hours) on a full charge (2-3 hours).
- **Digital Display:** Shows remaining battery percentage for convenient monitoring.
- **Adjustable Taper Lever:** Allows for fine-tuning cutting length between 0.8mm and 2.5mm for blending and precise styling.
- **Color-Coded Guide Combs:** Easily identify and select desired cutting lengths from 1/16" to 1" (1.5mm to 25mm).
- **Versatile Use:** Ideal for trimming hair, beards, head, body, and face.

SETUP

Initial Charging

Before first use, fully charge the clipper. Connect the charging cable to the clipper and a suitable power adapter. The digital display will show the charging progress. A full charge typically takes 2-3 hours and provides up to 3 hours of running time.

Oiling the Blades

For optimal performance and longevity, it is essential to oil the blades before each use. Apply a few drops of the provided blade oil across the top of the blades. Turn on the clipper for a few seconds to distribute the oil evenly, then wipe off any excess with a clean cloth.

Premium Self-Sharpening High-Carbon Steel Blades for Ultimate Precision



Cuts Through
All Hair Types



Image: Close-up of the clipper's self-sharpening high-carbon steel blades, designed for ultimate precision and cutting through all hair types.

OPERATING INSTRUCTIONS

Attaching Guide Combs

Select the desired guide comb based on the hair length you wish to achieve. The kit includes 12 color-coded guide combs ranging from 1/16" (1.5mm) to 1" (25mm). Align the comb with the clipper blade and snap it securely into place. Ensure it is firmly attached before use.

12 Guide Combs for Endless Hair-Styling Options



Image: The Mueller Ultragroom clipper with its array of 12 guide combs, illustrating the range of hair-styling options available.

Adjusting the Taper Lever

The adjustable taper lever on the side of the clipper allows for precise control over cutting length, ranging from 0.8mm (closest cut) to 2.5mm (longest cut) without a guide comb. This feature is ideal for blending, fading, and achieving seamless transitions in your haircut.



Image: The Mueller Ultragroom clipper highlighting its color-coded comb chart and the adjustable taper lever for precise length control.

General Haircutting Tips

- Always start with a longer guide comb than you think you need, and gradually work your way down to shorter lengths.
- Cut against the direction of hair growth for an even cut.
- Use the included hair clips to section off hair, making it easier to manage.
- For fading, use the taper lever to create smooth transitions between different hair lengths.
- The clipper is designed for use on dry hair for best results.



Mueller

- ✓ Closer Cutting
- ✓ Soft Line Fading
- ✓ Seamless Blending




Image: A visual representation of the Mueller Ultragroom clipper's capabilities, including closer cutting, soft line fading, and seamless blending.



Image: The Mueller Ultragroom clipper demonstrating its versatility for all-in-one trimming of hair, beards, head, body, and face.

MAINTENANCE

Cleaning the Blades

After each use, turn off the clipper and remove any attached guide comb. Use the provided cleaning brush to remove loose hairs from the blades. For a more thorough cleaning, you can carefully detach the blade set (refer to the user manual for specific instructions) and rinse it under running water, ensuring the main body of the clipper does not get wet. Allow blades to air dry completely before reattaching.

Oiling the Blades

Regular oiling is crucial for maintaining blade sharpness and preventing rust. Apply a few drops of the included blade oil to the blades before and after each use. This ensures smooth operation and extends the life of your clipper.

Storage

Store the clipper and all accessories in a dry, safe place away from moisture and extreme temperatures. Ensure the

blade guard is in place to protect the blades when not in use.

TROUBLESHOOTING

- **Clipper is pulling hair:** This often indicates low battery or dull/un-oiled blades. Ensure the clipper is fully charged and the blades are clean and properly oiled.
- **Clipper not turning on:** Check if the battery is charged. If not, connect to the charger. Ensure the power button is pressed firmly.
- **Uneven cut:** Ensure the guide comb is securely attached and that you are cutting against the direction of hair growth. Clean any hair buildup from the blades and comb.
- **Excessive noise or vibration:** Ensure the blades are clean and properly oiled. If the issue persists, contact customer support.

SPECIFICATIONS

Model Number	MUUC-12002
Brand	Mueller
Power Source	Corded Electric / Battery (Cordless)
Battery Type	1 Lithium Ion battery (included)
Full Charge Time	2-3 Hours
Running Time	Up to 3 Hours
Adjustable Cutting Length	0.8mm - 2.5mm (without comb)
Guide Comb Lengths	1/16" to 1" (1.5mm to 25mm)
Item Weight	0.17 Kilograms (approx. 5.93 ounces)
Color	Black

OFFICIAL PRODUCT VIDEOS

Mueller Cordless Hair Clippers Overview

Your browser does not support the video tag.

Video: A detailed overview of the Mueller Ultragroom Cordless Hair Clippers, showcasing its features and components. (Source: Hoff Media)

Mueller Cordless Clippers in Action

Your browser does not support the video tag.

Video: Demonstrating the effective performance of the Mueller Cordless Clippers during a haircut. (Source: Just Bill & Danielle)

WARRANTY AND SUPPORT

Mueller is committed to providing high-quality products. For specific warranty details, please refer to the product packaging or visit the official Mueller website. If you require any assistance or have questions regarding your Ultragroom Hair Clipper, please contact our customer support team. Our unparalleled 24/7 live telephone customer support is available to assist you.