Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 0643/00

Ariete Party Time Ice Cream Maker

Model: 0643/00

1. Introduction

Thank you for choosing the Ariete Party Time Ice Cream Maker. This appliance is designed to help you create delicious homemade ice cream, sorbet, and frozen yogurt quickly and easily. With its 1.5-liter capacity and efficient design, you can enjoy fresh desserts in approximately 30 minutes. Please read this manual carefully before first use to ensure safe and optimal operation of your ice cream maker.



The Ariete Party Time Ice Cream Maker, showcasing its compact and stylish design.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the appliance.
- Do not immerse the motor base in water or other liquids.
- Always unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts. Keep hands, hair, clothing, as well as spatulas and other utensils away from the mixing paddle during operation to prevent injury and/or damage to the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use appliance for other than intended household use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. Product Components

Familiarize yourself with the parts of your Ariete Party Time Ice Cream Maker:

1. Motor Base
2. Transparent Lid with Ingredient Chute
3. Mixing Paddle
4. Double-Insulated Freezer Bowl (1.5 Liter Capacity)
5. Mixing Spatula



Overview of the Ariete Party Time Ice Cream Maker's main components.

4. Setup

Before first use, wash all parts that will come into contact with food (freezer bowl, lid, mixing paddle, spatula) in warm, soapy water. Rinse thoroughly and dry completely. The motor base should only be wiped clean with a damp cloth.

Preparing the Freezer Bowl:

The double-insulated freezer bowl is crucial for making ice cream. It contains a special cooling liquid between its double walls that must be completely frozen before use.

1. Place the freezer bowl in the coldest part of your freezer for at least 8-12 hours, or until completely frozen. For best results, store the bowl in the freezer at all times so it's ready for use.
2. Ensure your freezer temperature is -18°C (0°F) or colder.

5. Operating Instructions

Follow these steps to make delicious ice cream:

1. Prepare your ice cream mixture according to your recipe. Ensure the mixture is chilled before adding it to the machine for best results.
2. Remove the frozen freezer bowl from the freezer.
3. Place the freezer bowl securely into the motor base.
4. Insert the mixing paddle into the center hole of the freezer bowl, ensuring it sits correctly.
5. Place the transparent lid onto the motor base, aligning it properly and twisting to lock if applicable.
6. Plug the appliance into a suitable electrical outlet.
7. Turn on the ice cream maker. The mixing paddle will begin to rotate.
8. Slowly pour your chilled ice cream mixture through the ingredient chute in the lid while the machine is running.
9. Allow the machine to churn for approximately 20-30 minutes, or until the mixture reaches your desired consistency. The churning time may vary depending on the recipe and ambient temperature.
10. Once the ice cream is ready, turn off the machine and unplug it.
11. Use the provided mixing spatula or a plastic/wooden utensil to scoop the ice cream out of the bowl. Avoid using metal utensils, as they can damage the freezer bowl.
12. For a firmer consistency, transfer the ice cream to an airtight container and place it in the freezer for an additional 1-2 hours.



The ice cream maker set up with fresh ingredients, ready for operation.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your ice cream maker.

- Always unplug the appliance before cleaning.
- Wash the freezer bowl, lid, mixing paddle, and spatula in warm, soapy water. Rinse thoroughly and dry completely. These parts are not dishwasher safe.
- Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
- Ensure all parts are completely dry before storing.
- Store the freezer bowl in the freezer for convenience, or in a dry place if not frequently used.

7. Troubleshooting

If you encounter issues with your ice cream maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Ice cream is not firm enough.	Freezer bowl not sufficiently frozen; mixture not cold enough; churning time too short.	Ensure freezer bowl is frozen for 8-12 hours; chill mixture thoroughly before adding; extend churning time.
Mixing paddle stops during operation.	Mixture is too thick; too much mixture in the bowl.	Ensure mixture consistency is appropriate; do not overfill the bowl (max 1.5 liters).
Appliance does not turn on.	Not plugged in; power outlet issue.	Check power cord connection; try a different outlet.

8. Specifications

Feature	Detail
Brand	Ariete
Model	0643/00
Color	Red
Capacity	1.5 Liters
Power	12 Watt
Key Features	Transparent Lid, Non-slip Base, Double-insulated Freezer Bowl
Material	Aluminum (Freezer Bowl)
Preparation Time	Approx. 30 minutes

9. Warranty and Support

For information regarding warranty, repairs, or customer support, please refer to the warranty card included with your product or contact Ariete customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BG2F8559

More documents and user manuals: **https://manuals.plus/**