Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave B0BG2X5XYD

Bellemave Triple L-Shape Bunk Bed with Slide and Desk (Twin Over Full)

Model: B0BG2X5XYD

Brand: Bellemave

1. Introduction

This instruction manual provides comprehensive guidance for the assembly, safe operation, and proper maintenance of your Bellemave Triple L-Shape Bunk Bed with Slide and Desk. This versatile bed system is designed to maximize space, featuring a low twin over full bunk bed and an attached loft bed with a desk and slide, ideal for corner placement in children's rooms.
Please read this manual thoroughly before assembly and use to ensure safety and product longevity. Keep this manual for future reference.

2. Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- **Supervise children when using the ladders and slide.** Ensure children understand safe usage.
- **Top bunk is not recommended for children under 6 years of age.**
- **Do not exceed the weight capacity:** 220 lbs (100 kg) for each upper bed and 320 lbs (145 kg) for the down bed.
- **Guardrails are essential.** Always use the guardrails on the upper bunks.
- **Prevent falls.** Prohibit horseplay on or under the bed. Always use the ladder for entering and exiting the upper bunk.
- **Mattress thickness.** Ensure the mattress on the upper bunk does not exceed 6 inches (15 cm) in thickness to maintain adequate guardrail height. The mattress for the lower bunk should be 8-10 inches (20-25 cm) thick.
- **Check fasteners regularly.** Periodically check and ensure that all fasteners are tight.
- **Be cautious of sharp edges during assembly.** Wear appropriate protective gear if necessary.
- **Keep small parts away from children** during assembly to prevent choking hazards.

3. Package Contents

Your Bellemave Triple L-Shape Bunk Bed is shipped in two separate boxes. Please ensure you have received both packages before beginning assembly. In the event that the boxes arrive on different dates, please allow 2-3 additional days for delivery or contact customer support.
Carefully unpack all components and verify against the parts list (typically included in Box 1). Common components include:

- Metal bed frames (for twin over full bunk and loft bed)
- Mattress support slats
- Ladders
- Slide components
- Desk components
- Hardware pack (screws, bolts, nuts, washers, hex key)
- Instruction manual

If any parts are missing or damaged, do not proceed with assembly. Contact Bellemave customer service immediately for assistance.

4. Setup and Assembly

Assembly typically requires two adults. For moving the assembled bed, three adults are recommended due to its size and weight.

1. **Prepare the Area:** Choose a clear, spacious area for assembly. Lay down a blanket or cardboard to protect your floor and the bed components.
2. **Identify All Parts:** Refer to the parts list and hardware diagram. Group similar components and hardware.
3. **Initial Frame Assembly:** Begin by assembling the main frames for the twin over full bunk bed and the loft bed according to the step-by-step diagrams provided in your package.
4. **Attach Connecting Pieces:** Connect the twin over full bunk bed to the loft bed frame to form the L-shape configuration. Ensure all parts are correctly aligned before tightening fasteners. If holes do not align, re-check part orientation.
5. **Install Ladders:** Securely attach the ladders to the designated access points for the upper bunks. Exercise care during assembly, especially when attaching ladder components, to prevent damage. Do not overtighten fasteners.
6. **Assemble and Attach Slide:** Assemble the slide components and securely attach the slide to the loft bed frame.
7. **Install Desk:** Assemble and attach the desk unit under the loft bed.
8. **Insert Slats:** Place the mattress support slats into their designated slots on all bed frames. Ensure they are securely seated before proceeding.
9. **Final Tightening:** Once all components are in place and aligned, systematically tighten all bolts and screws using the provided hex key. Do not overtighten to avoid stripping threads or damaging components.
10. **Inspect:** Before use, thoroughly inspect the assembled bed to ensure all connections are secure and stable.



Figure 1: Overall dimensions of the Bellemave Triple L-Shape Bunk Bed with Slide and Desk. Dimensions are provided in inches for length, width, and height of each section, including bed platforms, slide, and desk area.




Figure 2: Front view of the assembled Bellemave Triple L-Shape Bunk Bed, showcasing the twin over full bunk bed, the attached loft bed with desk, and the slide.

5. Operating Instructions

This bunk bed system offers multiple sleeping and activity zones:

- **Upper Twin Bunk:** Accessed via the ladder. Ensure the mattress does not exceed 6 inches in thickness.
- **Lower Full Bunk:** Provides a spacious sleeping area.
- **Loft Twin Bed:** Accessed via its dedicated ladder. Ensure the mattress does not exceed 6 inches in thickness.
- **Slide:** For recreational use from the loft bed. Ensure the area around the slide is clear before use.
- **Desk:** Located under the loft bed, providing a dedicated workspace or play area.

Always adhere to the weight limits for each bed and ensure children are supervised, especially when using the upper bunks and slide.

6. Maintenance

- **Regular Inspection:** Periodically (e.g., monthly) inspect all structural components, bolts, and screws to ensure they remain tight. Tighten any loose fasteners immediately.
- **Cleaning:** Clean the metal surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Check for Wear:** Examine the ladders, slide, and bed frames for any signs of wear, damage, or structural fatigue. Replace damaged parts promptly.
- **Mattress Care:** Follow the manufacturer's guidelines for mattress care. Rotate and flip mattresses as recommended to prolong their life.

7. Troubleshooting

- **Squeaking Noises:** If the bed makes squeaking noises, identify the source. Often, this is due to loose connections. Re-tighten all bolts and screws.
- **Wobbling or Instability:** Ensure the bed is placed on a level surface. Check all frame connections and tighten any loose fasteners.
- **Parts Not Aligning During Assembly:** Double-check the instruction manual and part numbers. Ensure components are oriented correctly. Sometimes, loosening adjacent bolts slightly can help align a stubborn piece before re-tightening everything.
- **Missing or Damaged Parts:** Do not attempt to substitute parts. Contact Bellemave customer service for replacements.

8. Specifications

Feature	Specification
Overall Product Dimension	117.4"L x 77.6"W x 53"H

Upper Bed Dimension (Twin)	75.2"L x 39"W
Down Bed Dimension (Full)	75.2"L x 54"W
Total Height	53"
Number of Each Bed Slats	20 PCS
Overall Product Weight	179.5 lbs
Upper Bed Weight Capacity	220 lbs
Down Bed Weight Capacity	320 lbs
Upper Bed Mattress Thickness	Max 6"
Down Bed Mattress Thickness	8-10"
Material	Metal + MDF
Color	Black
Assembly Required	Yes
Included Components	Desk, Slats

9. Warranty and Support

For warranty information, please refer to the documentation included with your purchase or contact Bellemave customer service directly. If you encounter any issues, problems, or have questions regarding your Bellemave Triple L-Shape Bunk Bed, please do not hesitate to contact our support team for assistance.
Contact information can typically be found on the Bellemave official website or through your retailer's customer service portal.

© 2026 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BG2X5XYD

More documents and user manuals: **https://manuals.plus/**