

[Manuals.plus](#) /

› [Oprunsy](#) /

› Oprunsy PTC Ceramic Space Heater User Manual - Model PTC-SH002

Oprunsy PTC-SH002


Oprunsy PTC Ceramic Space Heater User Manual

MODEL: PTC-SH002

Important Safety Instructions

Please read and understand all safety instructions before using this heater. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 meters) from the front, sides, and rear of the heater.
- Do not use the heater in bathrooms, laundry areas, or similar wet locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not use outdoors.
- Do not run power cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Do not insert or allow foreign objects into any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- Unplug the heater when not in use.
- Close supervision is necessary when any heater is used by or near children or invalids.
- This heater is equipped with a tip-over safety switch and overheat protection. If the heater tips over or overheats, it will automatically shut off. Ensure the heater is placed on a firm, level surface and allow it to cool down before restarting.
- The Oprunsy PTC Ceramic Space Heater is ETL certified, ensuring compliance with recognized safety standards.



Tip-Over Protection

shut off when accidentally
tip-over occurs



Over-Heat Protection

shut off when the parts
of the heater overheat



This image illustrates the heater's built-in tip-over protection, which automatically shuts off the unit if it is accidentally knocked over, and overheat protection, which activates if internal components reach an unsafe temperature.

Product Overview

The Oprunsky PTC Ceramic Space Heater (Model PTC-SH002) is a compact and efficient heating solution designed for indoor use. It utilizes advanced PTC ceramic heating technology to provide rapid warmth, featuring multiple operating modes and essential safety mechanisms.



A front view of the Oprunsky PTC Ceramic Space Heater, highlighting its compact design and the visible heating element behind the protective grille.

Key Features:

- **PTC Ceramic Heating Element:** Provides efficient and rapid heating.
- **Multiple Heating Modes:** Offers High Heat (1500W), Low Heat (900W), and Natural Wind (Fan Only) settings.
- **Adjustable Thermostat:** Allows for precise temperature control to maintain desired warmth.
- **Safety Protections:** Equipped with automatic tip-over and overheat shut-off features.
- **Compact and Portable Design:** Lightweight and easy to move between rooms.
- **ETL Certified:** Meets stringent safety standards.

**Compact design
easy to move**



This image displays the compact dimensions of the heater, measuring 6.3 inches in length, 4.73 inches in width, and 8.66 inches in height, illustrating its suitability for various spaces.

Setup

1. **Unpack:** Carefully remove the heater from its packaging and ensure all packing materials are discarded properly. Verify that all components, including the heater and instruction manual, are present.
2. **Placement:** Place the heater on a firm, level, and stable surface. Ensure there is adequate clearance around the heater. Maintain a minimum distance of 3 feet (0.9 meters) from any walls, furniture, curtains, or other combustible materials.
3. **Power Connection:** Plug the power cord directly into a standard 120V AC, 60Hz electrical outlet. Do not use extension cords, power strips, or surge protectors with this heater.



The heater is shown on a desk, demonstrating a typical and appropriate placement for use in an office or personal workspace, ensuring clear space around the unit.

Operating Instructions

The Oprunsky PTC Ceramic Space Heater features two control knobs on the top panel for easy operation.



This image provides a detailed view of the heater's control panel, indicating the manual temperature control knob and the mode selector for fan, low heat, and high heat settings.

1. **Power On/Off:** To turn the heater on, rotate the right-side **Mode Control Knob** from the 'OFF' position to your desired setting. To turn off, rotate the knob back to 'OFF'.
2. **Mode Selection:** Use the **Mode Control Knob** to select one of the following operating modes:
 - **FAN (Natural Wind):** The heater operates as a fan, circulating air without heat.
 - **I (Low Heat):** Provides 900 watts of heating power for moderate warmth.
 - **II (High Heat):** Provides 1500 watts of heating power for maximum warmth.
3. **Thermostat Adjustment:** Use the left-side **Manual Temperature Control Knob** to set your desired room temperature. Rotate the knob clockwise to increase the temperature setting and counter-clockwise to decrease it. The heater will cycle on and off automatically to maintain the set temperature.

Maintenance

Regular maintenance ensures optimal performance and longevity of your heater.

1. **Cleaning:**

- Always unplug the heater from the power outlet and allow it to cool completely before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners, waxes, or solvents, as these may damage the finish.
- Gently vacuum or wipe dust from the air intake and exhaust grilles to ensure unobstructed airflow.
- Do not immerse the heater in water or allow water to drip into the interior of the heater.

2. **Storage:**

- When not in use, store the heater in its original packaging or a suitable container in a cool, dry place.
- Ensure the power cord is neatly wrapped and secured to prevent damage.

Troubleshooting

If you encounter issues with your Oprunsy space heater, refer to the following common problems and solutions:

- **Heater does not operate:**
 - Ensure the power cord is securely plugged into a functional 120V electrical outlet.
 - Verify that the Mode Control Knob is set to 'I' (Low Heat), 'II' (High Heat), or 'FAN'.
 - Check if the thermostat knob is set higher than the current room temperature.
 - Confirm the heater is on a flat, stable surface. The tip-over safety switch may have been activated.
 - If the heater recently shut off, it might be due to overheat protection. Unplug the unit and allow it to cool for at least 30 minutes before attempting to restart.
- **Heater shuts off unexpectedly:**
 - This indicates that the built-in overheat protection or tip-over safety switch has been activated.
 - Unplug the heater immediately.
 - Allow the heater to cool down for at least 30 minutes.
 - Check for any obstructions to the air intake or exhaust grilles and remove them.
 - Ensure the heater is placed on a stable, level surface.
 - Plug the heater back in and attempt to restart. If the problem persists, contact customer support.

Specifications

Feature	Specification
Brand	Oprunsy
Model Number	PTC-SH002
Power Settings	900W (Low Heat), 1500W (High Heat)
Voltage	120 Volts
Heating Element	PTC Ceramic
Product Dimensions (D x W x H)	6.3" x 4.73" x 8.66"
Item Weight	2.43 lbs
Heating Coverage	Up to 300 square feet

Safety Features	Overheat Protection, Tip-Over Protection, Flame Retardant Material
Certifications	ETL Listed

Warranty and Support

Warranty information for your Oprunsky PTC Ceramic Space Heater is typically included with the product packaging. Please refer to the documentation provided at the time of purchase for specific warranty terms and conditions.

For technical support, troubleshooting assistance, or any product-related inquiries, please consult the contact information provided in your product documentation or visit the official Oprunsky website for further assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0BG4533TG>

More documents and user manuals: <https://manuals.plus/>