

OYIB MD058A

OYIB Wireless Earbuds User Manual

Model: MD058A

Brand: OYIB

INTRODUCTION

Thank you for choosing OYIB Wireless Earbuds, Model MD058A. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.3 connectivity, Environmental Noise Reduction (ENC) for clear calls, intuitive touch controls, and a long-lasting battery. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new earbuds to ensure optimal performance and enjoyment.



Image: OYIB Wireless Earbuds (MD058A) in their charging case, displaying battery levels.

WHAT'S IN THE BOX

Your OYIB Wireless Earbuds package includes the following items:

- 2x Wireless Headphones (Left/Right)
- 1x Lightweight USB-C Charging Case
- 1x USB-C Cable




Image: Contents of the OYIB Wireless Earbuds package, including the earbuds, charging case, and USB-C cable.

PRODUCT FEATURES

4-Mic and ENC Call Noise Reduction

Each earbud is equipped with two built-in microphones and Environmental Noise Reduction (ENC) technology. This system effectively suppresses up to 80% of background noise, intelligently enhancing your voice for clear and lossless calls. This ensures efficient communication even in noisy environments.



Image: Illustration of the 4-microphone system and ENC technology for enhanced call clarity.

Bluetooth 5.3 and Fast Auto Pairing

Utilizing the latest Bluetooth 5.3 technology, these earbuds offer lower latency and stronger anti-interference capabilities. Audio delays are significantly reduced, and disconnections in complex environments (e.g., crowded places) are minimized. Thanks to the hall switch, the earbuds will automatically connect to your device as soon as the charging case is opened after the initial pairing.



Image: Visual representation of Bluetooth 5.3 technology and the internal speaker structure for bass stereo sound.

USB-C Efficient Charge for 25H Impressive Hi-Fi Stereo Music

The earbuds feature a powerful 13mm speaker driver and a semi-in-ear acoustic structure, delivering incredible sound quality with clear treble. The charging case supports USB-C fast charging, fully charging in just one hour. With a single charge, the earbuds provide five hours of playback, extendable up to 25 hours using the portable charging case.

Touch Control Switch Easily between Single and Double Mode

The MD058A wireless earphones offer intuitive touch controls, allowing seamless switching between single and double earbud modes. You can control various functions such as music playback (play/pause, previous/next song), volume adjustment, phone calls (answer/hang up), and voice assistant activation directly from either earbud, eliminating the need to access your mobile phone.




Image: Visual guide to the one-step pairing process and the various smart touch control gestures for the earbuds.

IP7 Waterproof and Ultra-Light Earbuds (4g)

Designed for comfort and durability, these earbuds weigh only 4 grams each, providing a secure and comfortable fit. The pocket-sized charging case is highly portable. With IP7 nano-coated waterproof material, the earbuds are protected against splash damage from sweat and rain, making them ideal for sports, workouts, and daily use.




Image: Demonstrates the lightweight and comfortable design of the earbuds, highlighting their 4g weight.

SETUP

1. Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged.

- Connect the provided USB-C cable to the charging port on the case and plug the other end into a USB power source (e.g., wall adapter, computer USB port).
- The LED power display on the charging case will show the current battery percentage.
- The charging case takes approximately 1 hour to fully charge.
- Place the earbuds into the charging case. They will begin charging automatically. The earbuds also take approximately 1 hour to fully charge.
- A fully charged case provides up to 25 hours of additional playback time for the earbuds.

2. Initial Pairing with Your Device

Follow these steps for the first-time pairing:

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, PC), go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. You should see "MD058A" in the list.
5. Select "MD058A" to connect. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

After the initial pairing, the earbuds will automatically connect to the last paired device when you open the charging case, thanks to the hall switch feature.

Video: An official product video demonstrating the features of the OYIB Wireless Earbuds, including pairing and sound quality.

OPERATING INSTRUCTIONS

Touch Controls

The OYIB MD058A earbuds feature intuitive touch controls on both the left (L) and right (R) earbuds. Refer to the diagram below for specific functions:



Image: A comprehensive guide to the touch control functions on the OYIB Wireless Earbuds.

- **Play/Pause:** Double Tap R/L
- **Previous Song:** Long Tap 3s L
- **Next Song:** Long Tap 3s R
- **Volume Up:** One Tap R
- **Volume Down:** One Tap L
- **Answer Call:** One Tap R/L
- **Hang Up Call:** Long Tap 2s R/L
- **Activate Voice Assistant (Siri):** Triple Tap R/L

Single and Dual Earbud Mode

The earbuds can be used individually (Single Ear Mode) or together (Double Mode). You can seamlessly switch between these modes during operation. Simply take one earbud out of the case to use it in single mode, or take both out for stereo sound.

Making and Receiving Calls

With the 4-mic ENC technology, your calls will be clear. Use the touch controls to manage calls:

- **Answer Incoming Call:** One Tap on either earbud.
- **End Call:** Long Tap (2 seconds) on either earbud.

Video: An official product video showcasing the Bluetooth 5.3 headphones in use, highlighting their features and performance.

MAINTENANCE

Cleaning

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case:

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, aerosols, or abrasive cleaners.
- Ensure charging contacts on both earbuds and case are clean and dry to prevent charging issues.

Water Resistance (IP7)

The earbuds are IP7 waterproof, meaning they are protected against the effects of temporary immersion in water (up to 1 meter for 30 minutes). This makes them suitable for workouts and light rain. However, they are not designed for swimming or prolonged submersion. Always ensure the earbuds are dry before placing them back into the charging case to prevent damage.

TROUBLESHOOTING

If you encounter any issues with your OYIB Wireless Earbuds, refer to the following common problems and solutions:

Earbuds Not Pairing or Connecting

- Ensure both earbuds are charged.
- Turn off Bluetooth on your device, then turn it back on.
- Forget/delete "MD058A" from your device's Bluetooth list and try pairing again.
- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid to re-initiate pairing mode.
- Ensure your device is within the 10-meter Bluetooth range.

No Sound or Low Volume

- Check the volume level on both your device and the earbuds (using touch controls).
- Ensure the earbuds are properly seated in your ears.
- Try playing different audio sources to rule out a problem with the media file.
- Reconnect the earbuds to your device.

Poor Call Quality

- Ensure the microphones are not obstructed.
- Move to a quieter environment to reduce background noise interference.
- Check your device's network signal.

Earbuds Not Charging

- Ensure the USB-C cable is securely connected to both the case and the power source.
- Check if the charging contacts on the earbuds and inside the case are clean and free of debris.
- Try a different USB-C cable or power adapter.

Touch Controls Not Responding

- Ensure your fingers are clean and dry when touching the control area.
- Try restarting the earbuds by placing them in the case and closing the lid for a few seconds.

SPECIFICATIONS

Feature	Specification
Model Name	MD058A
Connectivity Technology	Wireless (Bluetooth 5.3)
Wireless Communication Technology	Bluetooth
Included Components	2x Wireless Headphones (L/R), 1x lightweight USB-C Charging Case, 1x USB-C Cable
Material	Plastic
Specific Uses For Product	Music
Charging Time (Earbuds)	1 Hour
Charging Time (Case)	1 Hour
Compatible Devices	Android, iOS smartphones, PCs, tablets, TVs
Control Type	Touch Control
Item Weight (Earbuds)	4g (each)
Water Resistance Level	IP7 Waterproof
Battery Life (Earbuds)	5 Hours (single charge)
Battery Life (with Case)	Up to 25 Hours
Audio Driver Type	Dynamic Driver
Audio Driver Size	13 Millimeters
Bluetooth Range	10 Meters
Audio Latency	65 Milliseconds
Product Dimensions	3.94 x 3.15 x 1.97 inches
Manufacturer	OYIB
UPC	799460896901



Image: The product parameter box detailing key specifications of the OYIB MD058A earbuds.

WARRANTY & SUPPORT

OYIB Wireless Earbuds are covered by a standard manufacturer's warranty. For detailed warranty information, technical support, or further assistance, please refer to the official user manual PDF or contact OYIB customer service.

You can download the comprehensive User Manual (PDF) for additional details and support:

[Download User Manual
\(PDF\)](#)

© 2025 OYIB. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question