

[Manuals.plus](#) /

› [Barcalounger](#) /

› Barcalounger Montville Power Recliner 9PHL-1189 User Manual

Barcalounger 9PHL-1189

Barcalounger Montville Power Recliner 9PHL-1189 User Manual

Model: 9PHL-1189 | Color: Rainer Walnut

1. INTRODUCTION

Thank you for choosing the Barcalounger Montville Power Recliner. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your new recliner. Please read these instructions thoroughly before assembly and use, and retain them for future reference.



Image 1.1: Front view of the Barcalounger Montville Power Recliner.

Product Features:

- Power Headrest, Power Lumbar, and Power Recline functions.
- Lay-flat mechanism for extended comfort.
- 3-inch footrest extension.
- Hidden cup holders and cell phone charger in armrests.
- USB charging port located on the outside arm controller.
- Durable construction with furniture-grade plywood frame and steel seat box.
- Upholstered in top-grain leather with matching vinyl on sides and back.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Keep hands and feet clear of the reclining mechanism during operation.
- Do not allow children or pets to play on or around the recliner, especially when it is in motion.
- Ensure the power cord is not pinched or damaged. Do not operate the recliner with a damaged cord or plug.
- Do not sit on the arms or footrest of the recliner.
- Maximum weight capacity for this recliner is 300 pounds. Do not exceed this limit.
- Always unplug the recliner from the power outlet before cleaning or performing maintenance.

3. SETUP

3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Place all parts on a soft, clean surface to prevent scratching.
3. Verify that all components are present according to the packing list (not provided in this manual, refer to product packaging).

3.2 Assembly

The Barcalounger Montville Power Recliner typically arrives in two main sections: the base and the backrest. Assembly is generally straightforward:

1. Align the metal receivers on the backrest with the posts on the base of the recliner.
2. Slide the backrest firmly down onto the posts until it locks into place. You may hear a click.
3. Connect any electrical cables between the backrest and the base. Ensure connections are secure.

3.3 Power Connection

1. Locate the power cord extending from the recliner.
2. Plug the power cord into a standard 120V AC wall outlet.
3. Ensure the cord is routed safely to avoid tripping hazards and is not compressed by the recliner or other furniture.

4. OPERATING INSTRUCTIONS

The Montville Power Recliner features an intuitive control panel located on the outside armrest.



Image 4.1: Side view of the recliner, highlighting the control panel and USB port.

4.1 Power Recline, Headrest, and Lumbar Adjustment

The control panel typically consists of several buttons for independent adjustment:

- **Recline Button:** Press and hold to recline the chair backward or return it to an upright position. Release the button at your desired angle.
- **Headrest Button:** Press and hold to adjust the headrest angle forward or backward. Release when the headrest is in the desired position.
- **Lumbar Button:** Press and hold to adjust the lumbar support in or out. Release when the lumbar support is comfortable.
- **Home Button:** (If present) Press to return the recliner to its original, upright position.



Image 4.2: The recliner in a fully reclined position, demonstrating the lay-flat mechanism and footrest extension.

4.2 USB Charging Port

A USB port is integrated into the outside arm controller for convenient charging of compatible electronic devices. Simply plug your device's USB cable into the port.

4.3 Hidden Cup Holders and Cell Phone Charger

The armrests feature hidden compartments. Gently lift the top section of the armrest to reveal the cup holder and a dedicated space for a cell phone, which may include an additional charging option (check specific model features).



Image 4.3: Recliner with hidden cup holders in the armrests opened.

5. MAINTENANCE

5.1 Cleaning the Leather Upholstery

- For general cleaning, wipe the leather surface with a soft, damp cloth.
- For spot cleaning, use a mild soap solution on a clean cloth, then wipe with a damp cloth to remove soap residue. Dry immediately with a clean, soft cloth.
- Avoid harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the leather.
- Keep the recliner away from direct sunlight and heat sources to prevent fading and drying of the leather.

5.2 Mechanism Care

- Periodically inspect all bolts and screws to ensure they are tight. Tighten if necessary.
- Keep the reclining mechanism free of obstructions.
- Do not lubricate the mechanism unless specifically instructed by the manufacturer, as this can attract dust and debris.

5.3 Electrical Components

- Regularly check the power cord and plug for any signs of damage.
- Ensure all electrical connections are secure.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Recliner does not operate.	No power supply.	Ensure the power cord is securely plugged into a working wall outlet. Check the circuit breaker.
Recliner operates slowly or with difficulty.	Obstruction in mechanism; low power.	Check for any objects obstructing the mechanism. Ensure the power connection is stable.
USB port not charging device.	Device incompatibility; loose connection.	Ensure your device is compatible with USB charging. Check the USB cable and connection. Try a different device.
Unusual noises during operation.	Loose components; mechanism issue.	Inspect for loose bolts. If noise persists, discontinue use and contact customer support.

If you encounter problems not listed here or if solutions do not resolve the issue, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	9PHL-1189
Color	Rainer Walnut
Dimensions (D x W x H)	37.5" x 42" x 42"
Material	Top Grain Leather, Vinyl, Wood Frame, Foam Fill
Weight Capacity	300 lbs
Power Features	Power Recline, Power Headrest, Power Lumbar, USB Charging Port
Additional Features	Lay-flat mechanism, 3" footrest extension, hidden cup holders, hidden cell phone charger



Image 7.1: Product dimensions of the Barcalounger Montville Power Recliner.

8. WARRANTY AND SUPPORT

For specific warranty information regarding your Barcalounger Montville Power Recliner, please refer to the documentation provided at the time of purchase or contact your retailer. Warranty terms and conditions may vary.

If you require technical assistance, have questions about your product, or need to report a defect, please contact the retailer where you purchased the recliner or the Barcalounger customer service directly. Please have your model number (9PHL-1189) and proof of purchase available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question