Arcmira HB-B68K

Arcmira Automatic Nut Milk Maker (Model HB-B68K)

Instruction Manual

1. Introduction

This manual provides essential information for the safe and efficient operation of your Arcmira Automatic Nut Milk Maker, Model HB-B68K. This appliance is designed to simplify the process of creating fresh, homemade plant-based beverages from nuts, seeds, grains, and beans. Please read all instructions carefully before first use and retain this manual for future reference.



Image: Arcmira Automatic Nut Milk Maker, Model HB-B68K.

2. Safety Instructions

- Always unplug the appliance from the power outlet before cleaning or when not in use.
- Do not immerse the main unit in water or any other liquid.
- Keep hands and utensils away from moving blades during operation to prevent injury.
- Ensure the lid is securely closed before starting any program. The appliance will display an 'E2' error if the lid is not properly placed.
- Do not overfill the appliance beyond the maximum fill line to prevent spillage and potential hazards.
- Use only the provided accessories or those specifically recommended by Arcmira.
- Keep out of reach of children.

3. Package Contents

Upon unpacking, please ensure all the following items are present:

- 1 x Arcmira Automatic Nut Milk Maker (Main Unit)
- 1 x Measuring Spoon
- 1 x Nut Milk Bag
- 1 x Cleaning Brush
- 1 x User Manual (this document)
- 1 x Recipe Book



Image: Included accessories with the Arcmira Nut Milk Maker.

4. Product Overview

The Arcmira Automatic Nut Milk Maker features a robust design with a stainless steel interior and a user-friendly LED control panel.



Image: Product Structure Diagram.

Key Components:

- **Lid:** Features magnetic control induction for safety and a steam vent to prevent splashing.
- **Handle:** Anti-scald design for comfortable and safe handling.
- **Stainless Steel Liner:** Ensures food safety and durability.
- **Blender Blades:** Six strong cross stainless steel blades, including two shark blades, designed for smooth blending and nutrient extraction.
- **LED Control Panel:** Intuitive interface for selecting functions and monitoring progress.

5. Setup

1. Place the nut milk maker on a stable, flat, and dry surface.
2. Ensure the appliance is unplugged before adding ingredients.
3. Remove the lid by twisting and lifting.
4. Add your desired ingredients (nuts, seeds, grains) into the stainless steel liner. Refer to the included recipe book for specific quantities.
5. Add water between the minimum and maximum fill lines indicated inside the liner. Do not exceed the maximum line.
6. Securely place the lid back onto the unit, ensuring it clicks into place.
7. Plug the power cord into the back of the appliance and then into a suitable power outlet. The LED display will illuminate.



Image: Basic steps for using the nut milk maker.

6. Operating Instructions

The Arcmira Nut Milk Maker features a one-touch automatic program with various functions:



Image: LED Control Panel.

Function Selection:

Press the 'Menu/Cancel' button to cycle through the available functions. The selected function's indicator light will illuminate, and the LED display will show the estimated time.

- **Room Temp:** Ideal for almond milk and other chilled nut milks, without heating.
- **Warm (140°F):** For warm beverages.
- **Hot (212°F):** Recommended for making soy and rice milk, which require boiling.
- **Boil Water:** Heats water to boiling temperature.
- **Keep Warm:** Maintains the temperature of your beverage for up to 6 hours.
- **Delay Start:** Allows you to set a delayed start time for up to 18 hours.
- **Self Clean:** A 60-second rinse cycle for easy cleaning.

Starting a Program:

After selecting your desired function, the program will automatically begin after a few seconds. The appliance will

beep when the program is complete.



Image: Versatility of the Arcmira Nut Milk Maker for various plant-based milks.

7. Maintenance and Cleaning

Regular cleaning ensures the longevity and hygiene of your appliance.

Self Clean Function:

1. After use, rinse the interior with water.
2. Fill the liner with clean water up to the maximum line.
3. Secure the lid and plug in the appliance.
4. Select the 'Self Clean' function using the 'Menu/Cancel' button.
5. The 60-second cleaning cycle will begin automatically.
6. Once complete, unplug the appliance and carefully empty the water.

Manual Cleaning:

- For thorough cleaning, hand wash the stainless steel liner and blades using the provided cleaning brush and mild detergent.
- Wipe the exterior of the appliance with a damp cloth. Do not use abrasive cleaners or scourers.
- Ensure all parts are completely dry before storing.

8. Troubleshooting

Issue	Possible Cause	Resolution
Appliance does not start / Displays 'E2'	Lid not properly closed.	Ensure the lid is securely placed and aligned with the main unit.
Liquid overflows during operation	Overfilling beyond the MAX line.	Reduce the amount of ingredients and/or water to below the MAX line.
Unusual noise or vibration	Appliance not on a stable surface; ingredients too hard/large.	Place on a flat, stable surface. Ensure ingredients are appropriately sized or pre-soaked if necessary.
Milk is not smooth enough	Insufficient blending time or ingredient ratio.	Adjust blending time or refer to recipe book for optimal ingredient ratios. Strain using the nut milk bag if desired.

9. Specifications

- **Brand:** Arcmira
- **Model Name:** HB-B68K
- **Capacity:** 20 oz (600 mL)
- **Material:** Stainless Steel
- **Product Dimensions:** 7.4"W x 11.8"H
- **Item Weight:** 4 Pounds
- **Power Source:** Corded Electric
- **Wattage:** 600 watts
- **Special Features:** Auto Shut-Off, Keep Warm Setting, Delay Start, Self Clean

10. Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or the official Arcmira website. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question