Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Defunc /
- Defunc Home 40W Multiroom Smart Speaker Instruction Manual

Defunc D2072

Defunc Home 40W Multiroom Smart Speaker Instruction Manual

Model: D2072 | Brand: Defunc

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Defunc Home 40W Multiroom Smart Speaker. Please read these instructions carefully before using the product to ensure optimal performance and longevity.

PRODUCT OVERVIEW

Components Included

- · Defunc Home 40W Speaker
- Power Adapter
- Base Stand
- User Manual (this document)
- · Warranty Card

Key Features

- Seamless Connectivity: Connect and control up to 32 speakers using the Defunc HOME app. Stream the same audio everywhere or select different tracks for each room.
- **Uninterrupted Playback:** Enjoy continuous playback via Wi-Fi, ensuring phone calls do not interrupt your audio.
- Versatile Compatibility: Supports Wi-Fi, Bluetooth 5.0, and AUX IN for flexible connection options.
- **Customizable Design:** Adapt the speaker's appearance with interchangeable front covers (available separately) or personalize with your own image.
- Advanced App Functions: The Defunc HOME app allows volume adjustment, equalizer configuration, speaker grouping/ungrouping, and easy switching between stereo/mono modes.
- Smart Assistant Integration: Compatible with Alexa and Airplay2.

1. Unpacking and Placement

Carefully remove all components from the packaging. Place the speaker on a stable, flat surface or mount it using a compatible wall or floor stand (sold separately). Ensure adequate ventilation around the speaker.



Image: Defunc Home speaker with its stand.

2. Power Connection

- 1. Connect the power adapter to the DC input port on the back of the speaker.
- 2. Plug the power adapter into a wall outlet. The speaker will power on automatically or enter standby mode.



Image: Rear view of the Defunc Home speaker, highlighting connection ports.

3. Initial App Setup (Recommended)

- 1. Download the **Defunc HOME** app from your device's app store.
- 2. Open the app and follow the on-screen instructions to connect your speaker to your Wi-Fi network. This step is crucial for multiroom functionality and smart assistant integration.
- 3. During setup, you may be prompted to link your Alexa or Airplay2 accounts.

OPERATING INSTRUCTIONS

Power On/Off

The speaker powers on when connected to an electrical outlet. To put it into standby mode or fully power off, use the Defunc HOME app or refer to the specific power button instructions if available on your model.

Volume Control

- Via Defunc HOME App: Adjust the volume precisely within the application.
- Via Source Device: Control volume from your connected smartphone, tablet, or computer.
- On Speaker: Use the physical volume buttons located on the top of the speaker (if present).



Image: Top view of the Defunc Home speaker, displaying control buttons.

Playback Control

Playback (play, pause, skip tracks) can be controlled through the Defunc HOME app, your streaming application, or the physical controls on the speaker.

CONNECTIVITY

Wi-Fi Connection (Defunc HOME App)

For multiroom audio, Alexa, and Airplay2 functionality, connect your speaker to your home Wi-Fi network using the Defunc HOME app. This provides the most stable and feature-rich experience.

Bluetooth Pairing

- 1. Ensure the speaker is powered on.
- 2. Press and hold the Bluetooth pairing button on the speaker (refer to the diagram in the app or on the speaker for exact location) until the indicator light flashes, indicating pairing mode.
- 3. On your device (smartphone, tablet), go to Bluetooth settings and select "Defunc Home" from the list of available devices.
- 4. Once paired, the indicator light will become solid.

AUX IN Connection

Connect an external audio source (e.g., MP3 player, CD player) to the AUX IN port on the speaker using a 3.5mm audio cable. The speaker will automatically switch to AUX mode or you may need to select it via the app or speaker controls.

DEFUNC HOME APP FUNCTIONALITY

The Defunc HOME app is central to managing your speaker system. It allows you to:

- Multiroom Control: Group up to 32 speakers for synchronized audio or assign different audio to individual speakers.
- Equalizer Settings: Customize audio profiles to suit your preferences.
- Stereo/Mono Mode: Switch between stereo and mono playback for individual speakers or grouped pairs.
- Source Selection: Easily switch between Wi-Fi, Bluetooth, and AUX input.
- Firmware Updates: Receive and install updates to enhance speaker performance and features.
- Smart Assistant Integration: Manage Alexa and Airplay2 settings.

MAINTENANCE

Cleaning

Wipe the speaker's exterior with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the finish. Ensure the speaker is unplugged before cleaning.

Storage

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No Power	Power cable not connected; outlet not active.	Ensure power cable is securely connected to speaker and a working electrical outlet.
No Sound	Volume too low; incorrect input source; device not paired/connected.	Increase volume. Check selected input source (Wi-Fi, Bluetooth, AUX). Re-pair Bluetooth device or check Wi-Fi connection in app.
Bluetooth Disconnection	Device out of range; interference.	Move device closer to speaker. Avoid obstacles. Re-pair if necessary.
Wi-Fi Connectivity Issues	Incorrect Wi-Fi password; router issues; speaker too far from router.	Verify Wi-Fi password in the Defunc HOME app. Restart your router. Move speaker closer to router.
Alexa/Airplay2 Not Responding	Not properly linked; network issues.	Check account linking in the Defunc HOME app. Ensure stable Wi-Fi connection.

SPECIFICATIONS

Feature	Detail
Brand	Defunc
Model Number	D2072
Product Dimensions	8.5D x 20W x 20H centimeters
Item Weight	2 Kilograms
Color	Black
Connectivity Technology	Bluetooth, Wi-Fi
Wireless Communication Technology	Wi-Fi
Speaker Output Power	40 Watts (for this model)
Frequency Response	20 GHz
Audio Output Mode	Stereo
Control Method	Application
Compatible Devices	Smartphone
Recommended Uses	Home Audio
Power Source	Corded Electric
Material	Plastic
Special Features	Bluetooth, Multi-room capability, Alexa, Airplay2

WARRANTY AND SUPPORT

Warranty Information

Your Defunc Home speaker comes with a standard manufacturer's warranty. Please refer to the included Warranty Card for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please visit the official Defunc website or contact their customer support. Contact details can typically be found on the warranty card or the Defunc website.

Related Documents - D2072



Defunc TRUE MUSIC Wireless Earbuds User Manual

A comprehensive guide to the Defunc TRUE MUSIC wireless earbuds, covering setup, features, technical specifications, usage instructions, and warranty information from The Art of Utility AB.



Defunc TRUE PLUS Wireless Earbuds User Manual and Guide

Explore the features, specifications, and usage guide for the Defunc TRUE PLUS wireless earbuds. Learn how to set up, operate, and care for your audio device.



Defunc TRUE TALK True Wireless Earbuds User Manual & Features

Explore the Defunc TRUE TALK true wireless earbuds. This guide covers setup, technical specifications, Pure Voice™ Bone Conductor Sensor Technology, touch controls, charging, warranty, and compliance information for an optimal user experience.



Defunc TRUE MUTE Active Noise Cancellation Earbuds User Manual

Explore the Defunc TRUE MUTE wireless earbuds with active noise cancellation. This manual provides comprehensive details on features, technical specifications, setup, operation, charging, touch controls, warranty, and FCC compliance.



Defunc TRUE AUDIO: True Wireless Earbuds with App Control & Low Latency

Explore the Defunc TRUE AUDIO true wireless earbuds. Learn about their app-controlled features, 50 MS low latency, 30-hour battery life, Bluetooth 5.3 connectivity, and user guide.



Defunc TRUE AUDIO User Manual

Comprehensive user manual for Defunc TRUE AUDIO wireless earbuds, covering setup, features, technical specifications, and troubleshooting. Learn how to optimize your app-controlled audio experience.

Documents - Defunc - D2072



XOOPAR Product Catalog 2024: Cables, Chargers, Speakers, and Accessories

Comprehensive product catalog from XOOPAR featuring a wide range of electronic accessories including multi-cables, Bluetooth speakers, power banks, chargers, headphones, and bags, with detailed specifications and pricing.

lang:fr score:19 filesize: 206 K page_count: 6 document date: 2024-10-11



[pdf] Diagram

Vtech Electronics Ltd User Cover letter The Art of Utility AB D207 Defunc HOME LARGE 2AKFED207 d207

The Art of Utility AB I, the undersigned, Johan Wahlback: The following models have the same technic ... t the different model numberappearance color. 1 Model No.:

2AKFED207 Sincerely, Client's signature: Client's name / title:...

lang:nl score:16 filesize: 142.21 K page_count: 1 document date: 2022-04-22

D2071 2 Model No.: D2091 3 Model No.: D2072 4 Model No.: D2092 FCC ID: