

[Manuals.plus](#) /

> [Bosch](#) /

> Bosch AdvancedGlue 18V Cordless Glue Gun Instruction Manual

Bosch 0603264800

Bosch AdvancedGlue 18V Cordless Glue Gun Instruction Manual

Model: 0603264800

INTRODUCTION

The Bosch AdvancedGlue 18V is a powerful cordless glue gun designed for various DIY, crafting, and repair tasks. It offers the performance of corded devices with the flexibility of an 18V battery system. Key features include a dual-temperature mode for different materials, rapid heating, and an intelligent auto-off function for energy saving and safety.

SAFETY INFORMATION

Always observe the following safety precautions when using the glue gun:

- **Hot Surfaces:** The nozzle and melted glue become very hot. Avoid direct contact with skin to prevent burns.
- **Ventilation:** Use in a well-ventilated area to disperse any fumes.
- **Children and Pets:** Keep the device out of reach of children and pets.
- **Power Source:** Use only with compatible Bosch 18V batteries. Ensure the battery is correctly inserted.
- **Storage:** Allow the glue gun to cool completely before storing.
- **Maintenance:** Do not attempt to disassemble or repair the tool yourself. Refer to authorized service personnel.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Bosch AdvancedGlue 18V Cordless Glue Gun
- 4 x Glue Sticks (11 mm diameter)
- Instruction Manual (this document)

Note: Battery and charger are not included and must be purchased separately.



Image: The Bosch AdvancedGlue 18V Cordless Glue Gun, shown with its retail packaging and included glue sticks. The battery is not included and is depicted with a dashed outline.

SETUP

1. **Insert Battery:** Ensure the battery is fully charged. Slide a compatible Bosch 18V battery into the battery slot at the base of the glue gun until it clicks into place.
2. **Insert Glue Stick:** Insert an 11 mm diameter glue stick into the opening at the rear of the glue gun. Push it gently until it stops.

OPERATING INSTRUCTIONS

1. **Power On:** Press the power button (usually located near the battery) to turn on the glue gun. An indicator light will illuminate.
2. **Select Temperature:** The AdvancedGlue 18V features a dual-temperature mode.
 - o **200 °C:** For strong bonds and materials resistant to heat.

- **130 °C:** For heat-sensitive materials.

Refer to the diagram below for temperature selection.

3. **Heating Time:** The glue gun heats up and is ready for use in approximately 90 seconds. The indicator light will change or stop flashing when the desired temperature is reached.
4. **Apply Glue:** Once heated, gently press the trigger to dispense melted glue from the nozzle. The extra-long nozzle provides improved visibility for precise application, even in tight spaces.
5. **Auto-Off Function:** The intelligent auto-off technology automatically switches off the glue gun after 10 minutes of inactivity to conserve energy and enhance safety.
6. **Power Off:** When finished, press the power button again to turn off the device. Remove the battery if storing for an extended period.

AdvancedGlue 18V

Buse longue

La buse extra longue assure une bonne visibilité et permet une application de colle précise sur de petites surfaces.

Dual temperature

Deux températures au choix : 200 °C pour une adhérence maximale avec des matériaux résistants et 130 °C pour les matériaux sensibles à la chaleur

Fonction Auto-Off

Économie d'énergie et sécurité assurée par mise hors tension de l'outil lorsqu'il est inactif



Image: A detailed view of the Bosch AdvancedGlue 18V, highlighting its extra-long nozzle for precision, the dual-temperature selection switch, and the location of the auto-off function indicator.

Démarrage rapide

Après un temps de chauffe de 90 secondes seulement, le pistolet à colle est prêt à l'emploi.



Image: Demonstrates the rapid startup of the glue gun, showing a user applying hot glue to a wooden surface shortly after powering on.



Image: A man using the Bosch AdvancedGlue 18V to assemble a piece of furniture, showcasing its application in DIY projects.



Collages puissants

Grâce au système haute température régulant une température constante, le pistolet à colle réalise des collages parfaits.

Image: Illustrates the powerful and precise bonding capabilities of the Bosch AdvancedGlue 18V, showing a strong adhesive joint on a material.



Fonction Auto-Off

La fonction Auto-Off intelligente fait économiser de l'énergie et assure la sécurité en éteignant automatiquement le pistolet à colle en cas d'inactivité.

Image: A user engaged in a crafting activity with the Bosch AdvancedGlue 18V, illustrating the convenience and safety of the intelligent auto-off function during periods of inactivity.

MAINTENANCE

- **Cleaning:** Ensure the glue gun is unplugged (battery removed) and completely cool before cleaning. Wipe the exterior with a damp cloth. Do not use abrasive cleaners or solvents.
- **Nozzle Care:** Do not attempt to clean the nozzle while hot. Any dried glue around the nozzle can be carefully removed once the tool is cool.
- **Storage:** Store the glue gun in a dry, safe place, away from direct sunlight and extreme temperatures. Ensure no glue sticks are left protruding from the rear if storing for long periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Glue gun does not heat up.	Battery not inserted correctly or discharged.	Ensure battery is fully charged and properly seated.
No glue dispenses.	No glue stick inserted or glue gun not hot enough.	Insert an 11mm glue stick. Allow sufficient heating time (90 seconds).
Glue drips from nozzle.	Normal for hot glue guns, especially when very hot.	Place a protective mat under the nozzle when not in use. Ensure correct temperature for material.
Glue gun turns off unexpectedly.	Auto-off function activated due to inactivity.	Press the power button to restart. This is a safety feature.

SPECIFICATIONS

Feature	Detail
Model Number	0603264800
Battery Voltage	18 V
Heating Time	Approx. 90 seconds
Glue Stick Diameter	11 mm
Glue Stick Length	45-200 mm
Adhesive Output	20 g/min
Dual Temperature Mode	130 °C / 200 °C
Weight (without battery)	0.315 kg
Compatible Battery System	Bosch 18V POWER FOR ALL Alliance
Country of Origin	Romania



Image: The Bosch POWER FOR ALL 18V Alliance logo, illustrating the compatibility of the 18V battery with a wide range of tools from Bosch and partner brands.

WARRANTY AND SUPPORT

For warranty information, service, or technical support, please refer to the official Bosch website or contact your local Bosch service center. Keep your purchase receipt as proof of purchase.

You can visit the official Bosch store for more information and products: [Bosch DIY Store](#)