

[Manuals.plus](#) /

› [NPET](#) /

› NPET WF210 Automatic Cat Water Fountain User Manual

NPET WF210

NPET WF210 Automatic Cat Water Fountain

USER INSTRUCTION MANUAL

INTRODUCTION

Thank you for choosing the NPET WF210 Automatic Cat Water Fountain. This stainless steel fountain is designed to provide your pet with fresh, clean, and circulating water, encouraging healthy hydration habits. Its 1.5-liter capacity, quiet operation, and easy-to-clean design make it an ideal choice for pet owners. Please read this manual carefully before use to ensure proper setup, operation, and maintenance.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before operating the fountain.
- Do not immerse the electrical adapter or pump in water.
- Always unplug the fountain when not in use, before assembling or disassembling parts, and before cleaning.
- Do not allow pets to chew on the power cord. If the cord is damaged, discontinue use immediately.
- Use only original NPET replacement parts and accessories.
- This product is for indoor use only.
- Keep the fountain away from direct sunlight and heat sources.
- Ensure the fountain is placed on a level, stable surface.
- Regularly inspect the fountain for any damage or wear.

PACKAGE CONTENTS

Please check to ensure all items are included in your package:

- Stainless Steel Fountain Body (1)
- Water Pump (1)
- Filter Tray (1)
- Filter (1)
- Faucet Kit (1)

- Cleaning Brush (1)
- Power Adapter (1)
- User Manual (1)

Tutto quello che ottieni nel pacchetto



Image: All components included in the NPET WF210 package.

SETUP INSTRUCTIONS

Follow these steps for the initial setup of your NPET WF210 fountain:

1. **Clean Components:** Wash all parts of the fountain (stainless steel body, filter tray, faucet kit) with soap and water before first use. Rinse thoroughly. The stainless steel bowl and lid are dishwasher safe.
2. **Assemble Pump:** Disassemble the pump and clean its components. Reassemble the pump.
3. **Place Pump:** Place the cleaned water pump into the designated area at the bottom of the stainless steel fountain body. Ensure the power cord is routed through the groove.

4. **Install Filter:** Rinse the filter under running water for 30 seconds to remove any loose carbon dust. Place the filter into the filter tray.
5. **Place Filter Tray:** Place the filter tray with the installed filter onto the fountain body, aligning it properly.
6. **Install Faucet Kit:** Insert the faucet kit into the opening on the filter tray.
7. **Fill with Water:** Fill the fountain with water up to the MAX level indicated on the water level window. Do not overfill.
8. **Connect Power:** Connect the power adapter to the fountain's power cord and then plug it into a wall outlet. The fountain will start operating.

Mantieni l'acqua pulita e fresca




Image: Exploded view of fountain components for assembly.

OPERATING INSTRUCTIONS

The NPET WF210 fountain is designed for continuous operation, providing fresh water for your pet.

- **Water Level Monitoring:** The fountain features a transparent water level window with MIN and MAX indicators. Regularly

check the water level and refill as needed to ensure the pump is always submerged. This prevents the pump from running dry and extends its lifespan.

- **LED Light:** The fountain includes an LED light, which can help pets locate the water in low light conditions and adds a pleasant glow.
- **Quiet Operation:** The pump is designed for ultra-quiet operation, ensuring it does not disturb your pet or household.

Livello dell'acqua visibile

Facile da monitorare il livello dell'acqua a colpo d'occhio




Image: Visible water level window on the fountain.

Pompa ultra silenziosa



Ultra Silenzioso
<40dB



Luce
a led



Basso
consumo



Image: Fountain demonstrating ultra-quiet operation and LED light.

MAINTENANCE

Regular cleaning and maintenance are crucial for the longevity of your fountain and the health of your pet.

- **Daily:** Check water level and refill as needed.
- **Weekly:** Clean the fountain body, filter tray, and faucet kit. The stainless steel bowl and lid are dishwasher safe for easy cleaning.
- **Monthly (or every 2-4 weeks):** Replace the filter. The filter provides triple purification: ion exchange resin to soften tap water, activated carbon to remove odors and impurities, and KDF55 filter to inhibit bacteria and remove heavy metals.
- **Pump Cleaning:** Disassemble and clean the pump regularly (every 2-4 weeks) to prevent mineral buildup and ensure optimal performance. Use the provided cleaning brush to clean the impeller and pump housing.

Lavabile in lavastoviglie

La ciotola e il coperchio della ciotola in acciaio inossidabile sono lavabili in lavastoviglie, non mettere le altre parti in lavastoviglie.




Image: Dishwasher safe components of the fountain.

Tripla funzione di purificazione



Resina a scambio ionico

Ammorbidire l'acqua del rubinetto e migliorare il gusto



Carbone Attivo

Rimuovere batteri e odori



KDF55 Filtro

KDF55 può inibire i batteri e rimuovere i metalli pesanti




Image: Triple purification filter details.



Image: Disassembled pump for cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fountain not working	No power; Pump clogged; Impeller stuck.	Check power connection; Clean pump and impeller; Ensure water level is sufficient.
Water flow is weak	Low water level; Clogged filter; Dirty pump.	Add water; Replace filter; Clean pump.
Fountain is noisy	Low water level; Dirty pump/impeller; Improper assembly.	Add water to MAX level; Clean pump and impeller; Reassemble all parts correctly.
Water tastes or smells bad	Filter needs replacement; Fountain needs cleaning.	Replace filter; Thoroughly clean all fountain components.

SPECIFICATIONS

Feature	Detail
Model Number	WF210
Brand	NPET
Material	Stainless Steel
Capacity	1.5 Liters
Dimensions (approx.)	18.9 x 18.8 x 14.4 cm
Item Weight	800 grams
Voltage	2.3E+2 Volts (AC)
Special Features	LED Light, Visible Water Level, Ultra Quiet Pump, Dishwasher Safe (bowl & lid)

WARRANTY AND SUPPORT

NPET is committed to providing quality products and excellent customer service. If you encounter any issues with your

NPET WF210 fountain, please refer to the troubleshooting section first. If the problem persists or for any other inquiries, please contact NPET customer support.

For support, please visit the official NPET website or contact the seller directly through your purchase platform. NPET strives to offer 24-hour service to address your concerns promptly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question