

[Manuals.plus](#) /

› [RYGHT](#) /

› RYGHT R483461 MINO Semi-Intra Wireless Earbuds User Manual

RYGHT R483461

RYGHT R483461 MINO Semi-Intra Wireless Earbuds User Manual

Model: R483461

INTRODUCTION

This manual provides detailed instructions for the RYGHT MINO Semi-Intra Wireless Earbuds (Model R483461). Please read this manual thoroughly before using the product to ensure proper operation and to maximize your listening experience. Keep this manual for future reference.

PACKAGE CONTENTS

Verify that all items are present in the package:

- RYGHT MINO Semi-Intra Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual (this document)




Image: Contents of the RYGH T MINO package, including earbuds, charging case, and USB-C cable.

PRODUCT OVERVIEW

The RYGH T MINO earbuds are designed for comfortable semi-intra-auricular wear, offering a balanced audio experience and extended battery life. They feature touch controls and dual microphones for clear communication.



Image: Detailed view of the RYGH T MINO earbuds, highlighting their semi-intra design.



Image: The RYGHY MINO charging case with earbuds, illustrating how they fit for charging.



Image: Top and side views of the RYGHY MINO charging case, featuring the USB-C charging port.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the supplied USB-C cable to the charging port on the case and to a compatible USB power source. The indicator lights on the case will show the charging status. A full charge provides up to 7 hours of listening time for the earbuds, with an additional 35 hours from the charging case, totaling 42 hours.



SON STÉRÉO HD
HD STEREO SOUND



7H + 35H
7H + 35H



DOUBLE MICROS
DUAL MIC



JUMELAGE AUTO
AUTO-PAIRING



TACTILE
TOUCH CONTROL



ASSISTANT VOCAL
VOICE ASSISTANT

Image: Infographic detailing key features including battery life and charging.

2. Pairing with a Device

1. **Initial Pairing:** Open the charging case and remove both earbuds. They will automatically enter pairing mode, indicated by flashing red and blue lights.
2. **Activate Bluetooth:** On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings and ensure Bluetooth is turned on.
3. **Select Device:** Look for "Ryght MINO" in the list of available devices and select it to connect.
4. **Confirmation:** Once connected, the earbud lights will stop flashing, and you may hear an audio prompt. The earbuds will automatically reconnect to the last paired device when removed from the case.

Note: If only one earbud connects initially, place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and try the pairing process again.

OPERATING INSTRUCTIONS

Touch Controls

The RYGHT MINO earbuds feature intuitive touch controls on each earbud. Specific functions may vary slightly depending on your device and application. Common controls include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold on either earbud.
- **Activate Voice Assistant:** Triple tap on either earbud (e.g., Siri, Google Assistant).

Making and Receiving Calls

The earbuds are equipped with dual digital microphones to optimize call quality. When a call comes in, you can answer or reject it using the touch controls as described above. Audio will be routed through the earbuds.

Audio Experience

The 10mm drivers deliver clear and balanced HD stereo sound. The semi-intra design provides passive noise isolation for an immersive listening experience.

MAINTENANCE

To ensure the longevity and optimal performance of your RYGHT MINO earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Charging Contacts:** Ensure the charging contacts on both the earbuds and inside the case are clean and free of debris to maintain proper charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Avoid extreme temperatures and humidity.
- **Water Resistance:** The earbuds are water-resistant. However, they are not designed for swimming or prolonged submersion. Dry them thoroughly if they get wet.

TROUBLESHOOTING

If you encounter issues with your RYGHT MINO earbuds, refer to the following common solutions:

Problem	Possible Solution
Earbuds do not turn on or charge.	Ensure the charging case is charged. Place earbuds correctly in the case. Clean charging contacts. Try a different USB-C cable or power source.
Only one earbud is working.	Place both earbuds back into the charging case, close the lid, wait 5 seconds, then open and remove them to re-establish the connection. Re-pair with your device if necessary.
Earbuds disconnect frequently or have unstable connection.	Ensure your device is within the Bluetooth range (typically 10 meters/33 feet) and there are no major obstructions. Disconnect and re-pair the earbuds. Ensure no other devices are interfering with the Bluetooth signal.
Poor sound quality.	Check the volume level on both your device and the earbuds. Ensure earbuds are clean and properly seated in your ears. Try playing audio from a different source.
Touch controls are unresponsive.	Ensure your fingers are clean and dry. Try restarting the earbuds by placing them in the case and taking them out again.

SPECIFICATIONS

Feature	Detail
Model Name	MINO
Model Number	R483461
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.0
Earbud Placement	Semi-Intra-auricular
Control Type	Touch Controls
Audio Driver Type	Dynamic (10mm)
Impedance	39 Ohms
Frequency Range	20 Hz - 20,000 Hz
Noise Control	Active Noise Suppression
Microphones	Dual Digital Microphones
Battery Life (Earbuds)	Up to 7 hours
Total Battery Life (with Case)	Up to 42 hours
Charging Port	USB-C
Water Resistance Level	Waterproof
Earbud Weight	8 Grams
Case Weight	120 Grams
Compatible Devices	Computer, Laptop, Phone, Cell Phone, Tablet, Gaming Console

SAFETY INFORMATION

Please observe the following safety precautions:

- Do not disassemble, repair, or modify the product.
- Avoid exposing the product to extreme temperatures, direct sunlight, or fire.
- Do not immerse the charging case in water. While earbuds are water-resistant, avoid prolonged exposure to water.
- Keep out of reach of children and pets.
- Avoid listening at high volume levels for extended periods to prevent hearing damage.
- Use only the provided USB-C cable for charging.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the point of purchase or visit the official RYGHT website. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0BGCCVPZY>

More documents and user manuals: <https://manuals.plus/>