Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY A2-2022092401A22

YING RAY Replacement Remote Control Instruction Manual

For Daikin RKS, RXS, and FT-N Series Inverter Wall Mounted Type Air Conditioners (Model A2-2022092401A22)

1. Product Overview

This manual provides instructions for the YING RAY replacement remote control, designed for specific Daikin RKS, RXS, and FT-N series inverter wall-mounted air conditioner models. This remote control offers essential functions for operating your air conditioning unit.

Important Note: This is not a universal remote control. Please verify compatibility with your specific air conditioner model or original remote control model before use. The temperature display on this remote is in Celsius only.

2. Package Contents

- 1 x Replacement Remote Control
- 1 x Wall Mount Case



Image 1: The YING RAY replacement remote control shown alongside its accompanying wall mount case. The remote is white with a display screen and various function buttons. The wall mount is also white, designed to securely hold the remote.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Replace batteries when the remote control's display becomes dim or its operating range decreases.

3.2 Wall Mount Case Installation

The included wall mount case allows for convenient storage of your remote control. Use appropriate screws (not included) to secure the case to a wall at a desired location. Ensure the mounting surface is stable.

4. Operating Instructions

Point the remote control directly at the indoor unit of your air conditioner when operating. Ensure there are no obstructions between the remote and the unit.

Button Functions:

ON/OFF: Press to turn the air conditioner unit on or off.

MODE: Press repeatedly to cycle through available operating modes (e.g., Cool, Heat, Fan, Dry, Auto).

TEMP ▲ / ▼: Use these buttons to increase or decrease the desired temperature setting.

FAN: Press to adjust the fan speed (e.g., Low, Medium, High, Auto).

SWING: Activates or deactivates the automatic louver swing function, directing airflow.

TURBO: Initiates rapid cooling or heating for a quick change in room temperature.

SAVE: Activates an energy-saving operation mode.

GOOD SLEEP: Engages the sleep mode, which adjusts temperature and fan speed for comfortable sleep.

TIMER (OFF / CANCEL / ON):

- **OFF:** Sets a timer for the unit to turn off automatically.
- **ON:** Sets a timer for the unit to turn on automatically.
- **CANCEL:** Cancels any active timer setting.

5. Specifications

Feature	Detail
Brand	YING RAY
Model Number	A2-2022092401A22
Compatible Air Conditioner Models	Daikin RKS12SL216, RKS18SL216, RKS24SL216, RXS09SL116, RXS09SL216, RXS12SL116, RXS12SL216, RXS18SL216, RXS24SL216, FT-N09CL116
Controller Type	Button Control
Special Feature	Replacement for specific Daikin models
Temperature Display	Celsius Only
Item Weight	1.06 ounces (approx. 30 grams)
Package Dimensions	0.39 x 0.2 x 0.08 inches (approx. 1 x 0.5 x 0.2 cm)
Manufacturer	ZHUHAI YINGRAY TRADING CO., LTD.

6. Maintenance

6.1 Cleaning the Remote Control

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical sprays, as these may damage the remote's surface or internal components.

6.2 Battery Care

- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.
- Do not mix old and new batteries, or different types of batteries.

7. Troubleshooting

Remote Control Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace with fresh AAA batteries if necessary.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the air conditioner's indoor unit.
- **Operating Range:** Ensure you are within the effective operating range of the air conditioner unit.
- **Compatibility:** Double-check that this remote control is compatible with your specific Daikin air conditioner model as listed in the product overview.

8. Warranty and Support

This product comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.
For technical support, warranty claims, or further assistance, please contact your retailer or the manufacturer, ZHUHAI YINGRAY TRADING CO., LTD., through the platform where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BGG7NJZ9

More documents and user manuals: **https://manuals.plus/**